

任意波形信号发生器

AFG-3021, 3022, 3031 & AFG-3032

使用手册

固纬料号 NO.



ISO-9001 认证企业

GW INSTEK

2016.2

本手册所含资料受到版权保护，未经固纬电子实业股份有限公司预先授权，不得将手册内任何章节影印、复制或翻译成其它语言。

本手册所含资料在印制之前已经过校正，但因固纬电子实业股份有限公司不断改善产品，所以保留未来修改产品规格、特性以及保养维修程序的权利，不必事前通知。

目录

安全说明..... 7

产品介绍..... 12

 主要特点 12

 面板介绍 14

 设置信号发生器 22

快速操作..... 24

 如何使用数字输入 27

 如何使用帮助菜单 28

 选择波形 31

 调制 35

 扫描 40

 Burst 41

 ARB 43

 Utility 菜单..... 47

 菜单树 51

 默认设置 68

操作..... 70

 选择通道 71

 选择波形 72

调制	90
幅值调制(AM)	93
频率调制(FM)	104
频移键控(FSK)调制	114
相位调制(PM)	121
SUM 调制	130
脉冲宽度调制.....	139
扫描.....	147
Burst 模式	158
 辅助系统功能设置	 171
存储、调取或删除	172
选择远程接口	176
系统和设置	182
 双通道&多台操作	 191
双通道设置	192
多台同步	200
 任意波形	 204
插入内置波形	206
显示任意波形	214
编辑任意波形	222
输出任意波形	232

存储/调取任意波形	239
远程接口.....	248
建立远程连接	249
浏览器控制接口	256
指令语法	259
指令列表	265
488.2 常见指令	273
状态寄存器指令	276
系统指令	283
应用指令	286
输出指令	295
脉冲设置指令	306
谐波指令	310
幅值调制(AM)指令	315
AM 介绍	315
频率调制(FM)指令	321
FM 介绍	321
频移键控(FSK)指令	328
FSK 介绍	328
相位调制(PM)指令	332
PM 介绍	332
SUM 调制指令	337
SUM 介绍	337
脉宽调制(PWM)指令	343

PWM 介绍	343
频率扫描指令	349
扫描介绍	349
Burst 模式指令	363
Burst 模式介绍	363
任意波形指令	376
任意波形介绍	376
追踪指令	428
参考指令	433
存储和调取指令	435
错误信息	438
SCPI 状态寄存器	452
附录.....	458
保险丝更换	458
AFG-3021, AFG-3022, AFG-3031 & AFG-3032 规格....	459
EC Declaration of Conformity	468
ARB 内置波形	469
索引.....	477

安全说明

本章节包含操作和存储信号发生器时必须遵照的重要安全说明。在操作前请详细阅读以下内容，确保安全和最佳化的使用。

安全符号

这些安全符号会出现在本使用手册或仪器上。



警告：产品在某一特定情况下或实际应用中可能对人体造成伤害或危及生命



注意：产品在某一特定情况下或实际应用中可能对产品本身或其它产品造成损坏



高压危险



注意:请参考使用手册



信号接地。机壳接地



信号接地。与其它通道和大地绝缘



勿将电子设备作为未分类的市政废弃物处理。请单独收集处理或联系设备供应商

安全指南

通常



注意

- 勿将重物置于仪器上
- 勿将易燃物置于仪器上
- 避免严重撞击或不当放置而损坏仪器
- 避免静电释放至仪器
- 请使用匹配的连接线，切不可用裸线连接
- 若非专业技术人员，请勿自行拆装仪器
- 请勿将超过 42V_{pk} 的电压连接任何输入/输出接地或机壳接地
- 请勿将输出端接入电压
- 请勿将触发或 MOD 输入端接入超过±5V 的电压

(测量等级) EN 61010-1:2010 规定了如下测量等级，AFG-30XX 系列属于等级 II：

- 测量等级 IV：测量低电压设备电源
- 测量等级 III：测量建筑设备
- 测量等级 II：测量直接连接到低电压设备的电路
- 测量等级 I：测量未直接连接电源的电路

电源



警告

- AC 输入电压: 100 - 240V AC, 50- 60Hz.
- 将交流电源插座的保护接地端子接地，避免电击触电

保险丝



警告

- 保险丝类型:
AFG-3032&3022: T1A/250V
AFG-3031&3021: T0.63A/250V
- 请专业技术人员更换保险丝
- 请更换指定类型和额定值的保险丝
- 更换前请断开电源插座和所有测试导线
- 更换前请查明保险丝的熔断原因

接地



- AFG-30XX 为浮地信号发生器；AFG-30XX 的之间电气隔离是机壳与各通道之间隔离 42V_{pk}（直流+交流）电压。超过 42V_{pp} 可能导致内部电路损坏。
- 如果机壳接地与 CH1(MAIN)或 CH2 的共地之间存在潜在的电压差，请勿将它们短路。否则可能损坏仪器或外部连接设备
- 如果 CH1 和 CH2 的共地之间存在潜在的电压差，请勿将它们短路。否则可能损坏仪器或外部连接设备



- 为避免电击，确保输出电压和浮地电压总计不超过 42V_{pk}
- 在仪器工作时，请勿触摸任何外露接口

清洁仪器

- 清洁前先切断电源
- 以中性洗涤剂和清水沾湿软布擦拭仪器。不要直接将任何液体喷洒到仪器上
- 不要使用含苯，甲苯，二甲苯和丙酮等烈性物质的化学药品或清洁剂

操作环境

- 地点: 室内，避免阳光直射，无灰尘，无导电污染(下注)，避免强磁场
- 相对湿度: <80%
- 海拔: <2000m
- 温度: 0°C~40°C

(污染等级) EN 61010-1:2010 规定了如下污染程度。该仪器属于等级 2:

污染指“可能引起绝缘强度或表面电阻率降低的外界物质，固体，液体或气体(电离气体)”。

- 污染等级 1: 无污染或仅干燥，存在非导电污染，污染无影响
- 污染等级 2: 通常只存在非导电污染，偶尔存在由凝结物引起的短暂导电
- 污染等级 3: 存在导电污染或由于凝结原因使干燥的非导电性污染变成导电性污染。此种情况下，设备通常处于避免阳光直射和充分风压条件下，但温度和湿度未受控制

存储环境

- 地点: 室内
- 相对湿度: < 70%
- 温度: -10°C~70°C

处理



勿将电子设备作为未分类的市政废弃物处理。请单独收集处理或联系设备供应商。请务必妥善处理丢弃的电子废弃物，减少对环境的影响

Class A 设备



警告

AFG-30XX 信号发生器属于 Class A 设备。Class A 等级为工业环境使用。由于传导和辐射干扰，Class A 设备在其它环境中可能存在潜在的电磁兼容性问题

英制电源线

在英国使用信号发生器时，确保电源线符合以下安全说明。

注意: 导线/设备连接必须由专业人员操作



警告: 此装置必须接地

重要: 导线颜色应与下述规则保持一致:

绿色/黄色: 接地

蓝色: 零线

棕色: 火线(相线)



导线颜色可能与插头/仪器中所标识的略有差异，请遵循如下操作:

颜色为绿色/黄色的线需与标有字母“E”，或接地标志 , 或颜色为绿色/黄绿色的接地端子相连;

颜色为蓝色的线需与标有字母“N”，或颜色为蓝色或黑色的端子相连;

颜色为棕色的线需与标有字母“L”或“P”，或者颜色为棕色或红色的端子相连;

若有疑问，请参照本仪器提供的用法说明或与经销商联系。

电缆/仪器需有符合额定值和规格的 HBC 保险丝保护：保险丝额定值请参照仪器说明或使用手册。如: 0.75mm^2 的电缆需要 3A 或 5A 的保险丝。保险丝型号与连接方法有关，再大的导体通常应使用 13A 保险丝。

在移动保险丝或保险丝座时连接器定会被损坏，然而将带有裸线的插头插入火线插座是非常危险的。若需重复连接，必须严格按照本手册说明操作。

产 品 介 绍

本章节介绍了信号发生器的主要特点、外观、设置过程和开机。

注：除特殊说明，本手册所涉及的“AFG-30XX”包含 AFG-3021、AFG-3022、AFG-3031 & AFG-3032。

主要特点

型号	频宽	通道
AFG-3021	20MHz	1(signal ground chassis isolation)
AFG-3022	20MHz	2 (signal ground chassis isolation and channel isolation)
AFG-3031	30MHz	1(signal ground chassis isolation)
AFG-3032	30MHz	2 (signal ground chassis isolation and channel isolation)

性能

- DDS 信号发生器系列
- 全频段 1 μ Hz 高频分辨率
- 1ppm 频率稳定度
- 任意波形能力
 - 250 MSa/s 采样率
 - 125 MSa/s 重复率
 - 8 M 点波形长度
 - 16 位幅值分辨率

- 10 组 8M 波形存储器
- 显示真实波形输出
- 用户定义输出部分
- D W R (直接波形重建)能力
- 无需 PC 就可编辑波形
- 可选 N 次循环和无限次输出模式
- -60dBc 低失真正弦波

特点

- 正弦波、方波、三角波、斜波、脉冲波、噪声波、DC 标准波形
- Int/Ext AM, FM, PWM, FSK, PM, SUM 调制
- 调制/扫描信号输出
- 带内部和外部触发的 Burst 功能
- 存储器存储/调取 10 组设置
- 输出过载保护
- 2 通道追踪(仅 AFG-3022/3032)
- 42Vpk 信号与机壳地之间隔离和 42Vpk 通道隔离
- 多台同步控制
- DSO Link 功能将捕获的波形从 DSO 传送到信号发生器
- 谐波功能
- 上升时间&下降时间可设的脉冲波形
- 频率和幅值扫描


界面

- 接口: 标配: LAN, USB 选配: GPIB
- 4.3"彩色 TFT LCD (480 × 272) 图示用户界面
- AWES (任意波编辑软件)PC 软件


面板介绍

前面板



AFG-3021/3031



AFG-3022/3032



LCD display	TFT 彩色 LCD 显示器，480 x 272 分辨率	
Function keys: F1~F6		位于 LCD 屏下方，用于开启功能
Operation keys		选择波形类型
		设置频率或采样率
		设置波形幅值
		设置直流偏移
		进入存储和调取选项、设置远程接口(USB, GPIB, LAN)、使用 DSO 连接(AFG-3021/3031)、更新和查阅固件版本、进入校正选项、输出阻抗设置(仅 AFG-3021/3031)、设置语言和进入帮助菜单
		设置任意波形参数
		MOD、Sweep 和 Burst 键用于设置调制、扫描和 Burst 选项和参数
		
		
		
Preset		调取预设状态

Main Output (AFG-3021/3031)		开启或关闭波形输出
CH1/CH2Output (AFG-3022/3032)		CH1/CH2 输出键。用于开启或关闭通道输出
CH1/CH2 (AFG-3022/3032)	 	AFG-3022 & AFG-3032 的 CH1/CH2 键用于进入 DSO link 功能、输出阻抗设置和相位设置
Output indicators		当输出指示灯变绿，开启输出
USB host connector		存储、恢复数据，以及更新固件
Output terminals (AFG-3021/3031)	  	调制输出端子，用于 AM、FM、PWM、PM、SUM 或扫描功能 SYNC 输出端子输出一个 TTL 逻辑电平信号，与主输出的零相位同相。50Ω 输出阻抗 主输出端子。50Ω 输出阻抗


注：MAIN 接地与 MOD 输出、SYNC 和 MOD 输入端子共地。他们与 10MHz REF IN 地是隔离并隔离电压为 42Vpk.

Output terminals




SYNC 输出端输出一个 TTL 逻辑电平信号，与 CH1 输出的零相位同相。50Ω 输出阻抗

(AFG-3022/3032)



CH2 输出端子。50Ω 输出阻抗




CH1 输出端子。50Ω 输出阻抗

注：CH1、CH2 和 10MHz REF IN 接地互相隔离，彼此相互隔离电压为 42Vpk

CH1 接地与 MOD 输出、SYNC 和 CH1 MOD 输入端子共地

CH2 接地与 CH2 MOD 输入端子共地

Standby key




待机键使信号发生器处于开机(绿色)或待机(红色)模式

Selection keys




当编辑参数时，用于选择数位


Scroll Wheel



编辑数值和参数




Keypad




输入数值和参数，常与方向键和可调旋钮一起使用

后面板


AFG-3021/3031



AFG-3022/3032



10MHz REF
OUT




10 MHz 参考输出

10MHz REF IN


10 MHz 参考输入

Trigger Input



外部触发输入。用于接收外部触发信号。AFG-3022/3032 的 CH1 和 CH2 通道具有单独的触发输入

MOD input




调制输入端子。AFG-3022/3032 的 CH1 和 CH2 通道具有单独的调制输入

注：CH1 / CH2 MOD 输入终端相互隔离和机壳接地的隔离电压 42 vpk。

CH1 MOD 输入与 CH1 共地。


CH2 MOD 输入与 CH2 共地。

Fan



风扇

Power Socket
Input and fuse



电源输入：100-240V AC

50-60Hz

保险丝：


AFG-3022/3032: T1A/250V

AFG-3021/AFG-3031:

T0.63A/250V

保险丝更换见 458 页

Power Switch



主电源开关

USB B port




连接 PC，进行远程控制

LAN port




以太网远程控制(RJ45 接口)

GPIB



24 pin female GPIB 接口，
PC 远程控制

显示



Parameter 编辑 CH1 和 CH2 的参数值

Windows

Waveform 显示每通道波形

Display

Soft Menu Keys 功能键(F1~F6)与下方的软菜单键对应


设置信号发生器

背景


本章节介绍了如何调整把手位置以及如何开机。

调整把手


向两侧拉把手并旋转




水平放置仪器



或倾斜放置




垂直放置方便手提



开机


1. 将电源线接入后面板插座



2. 开启后面板的电源开关



3. 按前面板的 Standby 键开机，Standby 键指示灯由红(待机)变绿(开启)



4. 当 Standby 键变绿时，屏幕显示载入状态



此时信号发生器已准备就绪

快速操作

本章节介绍仪器的操作快捷方式、内置帮助和默认出厂设置，方便用户快速入门。有关参数、设置和限制详情见操作章节(见 70 页)、调制章节(见 90 页)、辅助系统功能设置章节(见 171 页)、双通道&多台操作章节(见 191 页)或规格(见 459 页)。

如何使用数字输入	27
如何使用帮助菜单	28
选择波形	31
方波	31
三角波	31
正弦波	32
脉冲波	32
噪声波	33
谐波	33
调制	35
AM	35
FM	36
FSK 调制	37
PM	38
SUM 调制	38
PWM 调制	39
扫描	40
Burst	41
ARB	43

ARB –增加内置波形.....	43
ARB –增加内置波形-脉冲.....	43
ARB –增加点.....	44
ARB –增加线.....	44
ARB –输出部分.....	45
ARB –输出 N 次循环.....	45
ARB –输出无限次循环.....	46
Utility 菜单.....	47
存储.....	47
调取.....	47
接口 GPIB.....	47
接口 LAN.....	48
接口 USB.....	48
双通道 – 频率耦合.....	48
双通道 – 幅值耦合.....	49
双通道 – 追踪.....	49
菜单树.....	51
波形.....	50
波形-脉冲.....	51
波形-更多.....	52
ARB –显示.....	53
ARB –编辑.....	54
ARB –内置.....	55
ARB –内置-基本.....	56
ARB –存储.....	57
ARB –调取.....	57
ARB –输出.....	58
MOD.....	59
扫描-Type/MOD = 频率.....	60
扫描-更多.....	60
扫描-Type/MOD = 幅值.....	61

Burst – N 次循环.....	62
Burst –门限	62
CH1 / CH2 (仅 AFG-3022/AFG-3032)	63
UTIL (AFG-3021/3031)	63
UTIL (AFG-3022/AFG-3032).....	64
UTIL –接口.....	65
UTIL –接口- LAN.....	65
UTIL –接口- LAN - Config - Manual.....	66
UTIL –系统.....	66
UTIL –双通道.....	67
默认设置.....	68

如何使用数字输入

背景

AFG-30XX 提供三种数字输入：数字键盘、方向键和可调旋钮。下面介绍如何使用数字输入编辑参数。



1. 按(F1~F6)对应的功能键选择菜单项。例如，功能键 F1 对应软键“Sine”



2. 使用方向键将光标移至需要编辑的数位



3. 使用可调旋钮编辑数值。顺时针增大，逆时针减小
4. 或者使用数字键盘设置高光处的参数值



如何使用帮助菜单

背景

帮助菜单详细描述了每个按键的含义和功能。

1. 按 UTIL



2. 按 System (F4)[AFG-3021/3031 按 F5]




3. 按 More (F5)



4. 按 Help (F2)



5. 可调旋钮浏览帮助菜单。按 Select 选择该项



Keypad


介绍任一前面板键

Arbitrary Waveform	介绍如何创建任意波形
Modulation Function	介绍如何创建调制波形
Sweep Function	介绍扫描功能
Burst Function	介绍 Burst 功能
DSO Link	介绍 DSO link
Hardcopy	介绍如何使用 Hardcopy 功能
Dual Channel	介绍如何完成 AFG-3022/3032 的频率或幅值追踪

6. 例如选择项 5 查看扫描功能



7. 可调旋钮浏览帮助页面



8. 按 F6 返回上级菜单




选择波形

方波

例如: 方波, 3Vpp, 75% 占空比, 1 kHz

输出



1. 按 Waveform 键, 选择 Square (F2)



2. 分别按 Duty (F1), 7 + 5 + % (F5)



输入: N/A

3. 分别按 FREQ/Rate, 1 + kHz (F5)



4. 分别按 AMPL, 3 + VPP (F6)




5. 按 Output 键



三角波

例如: 三角波, 5Vpp, 10kHz

输出



1. 按 Waveform 键, 选择 Triangle (F3)



2. 分别按 FREQ/Rate, 1 + 0 + kHz (F5)



输入: N/A

3. 分别按 AMPL, 5 + VPP (F6)




4. 按 Output 键



正弦波

例如: 正弦波, 10V_{pp}, 100kHz

输出




输入: N/A

1. 按 Waveform 键, 选择 Sine (F1)



2. 分别按 FREQ/Rate key, 1 + 0 + 0 + kHz (F5)



3. 分别按 AMPL, 1 + 0 + VPP (F6)




4. 按 Output 键



脉冲波


例如: 脉冲波, 10V_{pp}, 100kHz, 5us 脉宽

输出



输入: N/A

1. 分别按 FREQ/Rate, 1 + 0 + 0 + kHz (F5)



2. 按 Waveform 键, 选择 Pulse (F4)



3. 分别按 Width (F1), 5 + uSEC (F3)



4. 分别按 AMPL, 1 + 0 + VPP (F6)




5. 按 Output 键



噪声波

例如: 白噪声输出

输出



1. 按 Waveform 键, 选择 More (F6), Noise (F1)



2. 按 Output 键




输入: N/A

谐波

例如: 10kHz 谐波正弦波, 奇&偶(all)谐波, 3rd order (2nd(5Vpp), 3rd(2Vpp), 0° 相位)

输出



1. 按 Waveform 键, 选择 More (F6), Harmonic (F2)



2. 分别按 Total (F1), 3 + Enter (F1)



3. 分别按 Type (F2), ALL (F3)



4. 按 Order (F3)




输入: N/A

5. 分别按 Order (F1), 2 +   

分别按 Amp(F2), 5
+ VPP (F2)



分别按 Phase(F3), 0
+ Degree (F1)



6. 分别按 Order (F1), 3 +   


分别按 Amp(F2), 2
+ VPP (F2)



分别按 Phase(F3), 0
+ Degree (F1)



7. 按 Output 键




调制

AM

例如: AM 调制. 100Hz 调制方波. 1kHz 正弦载波. 80%调制深度

输出



1. 按 MOD 键, 选择 AM (F1)



2. 按 Waveform, 选择 Sine (F1)



输入: N/A

3. 分别按 Freq/Rate, 1 + kHz(F5)




4. 按 MOD 键, 选择 AM (F1), Shape (F4), Square (F2)



5. 按 MOD 键, 选择 AM (F1), AM Freq (F3)



6. 按 1 + 0 + 0 + Hz(F2)



7. 按 MOD 键, 选择 AM (F1), Depth (F2)



8. 按 8 + 0 + % (F1)



9. 按 MOD, AM (F1), Source (F1), INT (F1)




10. 按 Output 键



FM

例如: FM 调制, 100Hz 调制方波, 1kHz 正弦载波, 100 Hz 频移, 内部源

输出



1. 按 MOD 键, 选择 FM (F2)



2. 按 Waveform, 选择 Sine (F1)



输入: N/A

3. 分别按 Freq/Rate, 1 + kHz(F5)




4. 按 MOD 键, 选择 FM (F2), Shape (F4), Square(F2)



5. 按 MOD 键, 选择 FM (F2), FM Freq (F3)




6. 按 1 + 0 + 0 + Hz(F2)



7. 按 MOD 键, 选择 FM (F2), Freq Dev (F2)



8. 按 1 + 0 + 0 + Hz(F3)



9. 按 MOD, FM (F2), Source (F1), INT (F1)




10. 按 Output 键



FSK 调制

例如: FSK 调制, 100Hz 跳跃频率, 1kHz 载波, 三角波, 10 Hz 频率, 内部源

输出



1. 按 MOD 键, 选择 FSK (F3)



2. 按 Waveform, 选择 Triangle (F3)



输入: N/A

3. 分别按 Freq/Rate, 1 + kHz(F5)



4. 按 MOD 键, 选择 FSK (F3), FSK Rate (F3)



5. 按 1 + 0 + Hz(F2)



6. 按 MOD 键, 选择 FSK (F3), Hop Freq(F2)



7. 按 1 + 0 + 0 + Hz (F3)



8. 按 MOD, FSK (F3), Source (F1), INT (F1)




9. 按 Output 键



PM

例如: PM 调制. 100Hz 相位频率. 正弦波形. 180°相位偏差. 1kHz 正弦载波

输出



1. 按 MOD 键, 选择 PM (F4)



2. 按 Waveform, 选择 Sine (F1)



输入: N/A

3. 分别按 Freq/Rate, 1 + kHz(F5)




4. 按 MOD 键, 选择 PM (F4), Shape (F4), Sine(F1)



5. 按 MOD 键, 选择 PM (F4), PM Freq (F3)




6. 按 1 + 0 + 0 + Hz(F2)



7. 按 MOD 键, 选择 PM (F4), Phase Dev (F2)




8. 按 1 + 8 + 0 + Degree(F1)



SUM 调制

例如: SUM 调制. 100Hz SUM 频率. 50% SUM 幅值. 1kHz 正弦载波. 三角波形. 内部源

输出



输入: N/A

1. 按 MOD 键, 选择 SUM (F5)



2. 按 Waveform, 选择 Sine (F1)



3. 分别按 Freq/Rate, 1 + kHz(F5)



4. 按 MOD 键, 选择 SUM (F5), SUM Freq (F3)



5. 按 1 + 0 + 0 + Hz(F2)



6. 按 MOD 键, 选择 SUM (F5), SUM Ampl (F2)



7. 按 5 + 0 + % (F1)



8. 按 MOD 键, 选择 SUM (F5), Shape (F4), Triangle (F3)



9. 按 MOD, SUM (F5), Source (F1), INT (F1)




10. 按 Output 键



PWM 调制

例如: PWM 调制, 800Hz 载波, 15 kHz 调制正弦波, 50% 占空比, 内部源

输出



输入: N/A

1. 按 Waveform, 选择 Square (F2)



2. 按 MOD 键, 选择 PWM (F6)



3. 分别按 FREQ/Rate, 8 + 0 + 0 + Hz(F4)



4. 按 MOD 键, 选择 PWM (F6), Shape (F4), Sine(F1)



5. 按 MOD, PWM (F6), PWM Freq (F3)



6. 按 1 + 5 + kHz(F3)



7. 按 MOD, PWM (F6), Duty (F2)



8. 按 5 + 0 + % (F1)



9. 按 MOD, PWM (F6), Source (F1), INT (F1)




10. 按 Output 键



扫描

例如: 频率扫描. 起始频率 10mHz, 截止频率 1MHz. Log 扫描, 1 s 扫描, 手动触发

输出



1. 按 Sweep, Start (F3)



2. 按 1 + 0 + mHz(F2)



3. 按 Sweep, Stop (F4)



输入: N/A

4. 按 1 + MHz(F5)



5. 按 Sweep,
Type/MOD (F2),
Functions (F3), Log
(F2)



6. 按 Sweep, SWP Time
(F5)



7. 按 1 + SEC (F2)



8. 按 Sweep, TRIG Type
(F6), Manual (F3)



9. 按 Output 键




10. 按 Trigger (F1)



Burst

例如: Burst 模式, N 次循环(内部触发), 1kHz burst 频率, burst 个数= 5, 10 ms burst 周期, 0°burst 相位, 内部触发, 10 us 延迟, 上升沿触发

输出



输入: N/A

1. 按 FREQ/Rate 1 kHz (F5)



2. 按 Burst, N Cycle (F1), Cycles (F1)



3. 按 5 + Cyc(F5)



4. 按 Burst, N Cycle (F1), Period (F4)



5. 按 1 + 0 + msec (F2)



6. 按 Burst, N Cycle (F1), Phase (F3)



7. 按 0 + Degree (F5)



8. 按 Burst, N Cycle (F1), TRIG Setup (F5), INT (F1)



9. 按 Burst, N Cycle (F1), TRIG Setup (F5), Delay (F4)



10. 按 1 + 0 + uSEC (F2)



11. 按 Output 键




ARB

ARB –增加内置波形

例如: ARB 模式, 上升指数函数. Start 0, Length 100, Scale 32767

输出



1. 按 ARB, Built in (F3), Basic (F1), More (F5), Exp Rise (F1)



2. 按 Start (F1), 0 + Enter (F5)



3. 按 Length (F2), 100, Enter (F5)




4. 按 Scale (F3), 32767, Enter (F5), Done (F4)



ARB –增加内置波形-脉冲

例如: ARB 模式, 脉冲波. Start 0, 频率 1kHz, 占空比 25%

输出



1. 按 ARB, Built in (F3), Basic (F1), More (F5), Pulse (F4)



2. 按 Frequency (F1), 1, kHz (F5)




- 按 Duty (F2), 25, % (F5)



ARB -增加点

例如: ARB 模式, 增加点, 地址 40, 数据 30,000

输出



- 按 ARB, Edit (F2), Point (F1), Address (F1)



- 按 4 + 0 + Enter (F5)




- 按 Data (F2), 3+0+0+0+0, Enter (F5)



ARB -增加线

例如: ARB 模式, 增加线, 地址:数据(10:30, 50:100)

输出



- 按 ARB, Edit (F2), Line (F2), Start ADD (F1)



- 按 1 + 0 + Enter (F5)



- 按 Start Data (F2), 3 + 0, Enter (F5)



4. 按 Stop ADD (F3), 5 + 0, Enter (F5)




5. 按 Stop Data (F4), 1 + 0 + 0, Enter (F5), Done (F5)



ARB –输出部分

例如: ARB 模式, 输出 ARB 波形, Start 0, Length 1000

输出




1. 按 ARB, Output (F6)



2. 按 Start (F1), 0 + Enter (F5)




3. 按 Length (F2), 1 + 0 + 0 + 0, Enter (F5)



ARB –输出 N 次循环

例如: ARB 模式, 输出 N 次循环, Start 0, Length 1000, N Cycle 10


输出




1. 按 ARB, Output (F6)



2. 按 Start (F1), 0 + Enter (F5)



3. 按 Length (F2), 1 + 0 + 0, Enter (F5)



4. 按 N Cycle (F4)



5. 按 Cycles (F1), 1 + 0, Enter (F5)




6. 按 Trigger (F5), 触发一次输出



ARB - 输出无限次循环

例如: ARB 模式, 输出 N 次循环, Start 0, Length 1000, 循环无限次


输出




1. 按 ARB, Output (F6)



2. 按 Start (F1), 0 + Enter (F5)



3. 按 Length (F2), 1 + 0 + 0, Enter (F5)



4. 按 Infinite (F5)



Utility 菜单

存储

例如: 存储至内存文件#5

1. 按 UTIL, Memory (F1)



2. 使用可调旋钮选择文件,按 Store (F1), 按 Done(F5)



调取

例如: 调取内存文件#5

1. 按 UTIL, Memory (F1)



2. 使用可调旋钮选择文件,按 Recall (F2), 按 Done (F5)




接口 GPIB

例如: GPIB 接口, 地址 10

GPIB


1. 按 UTIL, Interface (F2), GPIB (F1), Address (F1)






接口 LAN

例如: LAN 接口, DHCP IP 设置




接口 USB


例如: USB 接口



双通道- 频率耦合

例如: 1kHz 偏移耦合. 仅 AFG-3022, 3032





- 按 Offset (F2), 1 + 0 + kHz (F4)

Offset


1

kHz

双通道- 幅值耦合

例如: 幅值耦合. 仅 AFG-3022, 3032

输出



- 按 UTIL, Dual Ch (F5), Ampl Cpl (F2)
- 按 ON (F1)

UTIL

Dual Ch


Ampl

ON

双通道 - 追踪

例如: 反向追踪. 仅 AFG-3022, 3032

输出



- 按 UTIL, Dual Ch (F5), Tracking (F3)
- 按 Inverted (F3)

UTIL

Dual Ch

Tracking

Inverted

菜单树

常规


将菜单树作为信号发生器功能和特性的简易参考。
AFG-3021/3022/3031/3032 菜单系统逐层排列，每层都可由操作键或软键浏览。按 Return 软键返回上级菜单。

例如: 设置 USB 接口;


(1)按 UTIL 键

(2)接口软键


(3) USB




波形




波形-脉冲




波形-更多



ARB-显示




ARB-编辑




ARB-内置

注: 如下菜单树仅列出每个内置 ARB 波形的位置




ARB-内置-基本


注: 仅将“Basic”菜单树列于 ARB > Built-in 菜单树系统中。其它内置 ARB 波形的操作菜单键几乎与下列内容一致




ARB-存储




ARB-调取




ARB-输出




MOD




扫描 - Type/MOD = 频率




扫描-更多




扫描 - Type/MOD = 幅值




Burst - N 次循环




Burst - 门限




CH1 / CH2 (仅 AFG-3022/AFG-3032)




UTIL (AFG-3021/3031)




UTIL (AFG-3022/AFG-3032)




UTIL -接口




UTIL -接口 - LAN




UTIL - 接口 - LAN - Config - Manual



UTIL - 系统



UTIL - 双通道



默认设置

按 Preset 键恢复默认面板设置。



输出设置	功能	正弦波
	频率	1kHz
	幅值	3.000 Vpp
	偏移	0.00V dc
	输出单位	Vpp
	输出端子	50Ω
调制		
(AM/FM/FSK)	载波	1kHz 正弦波
	调制波形	100Hz 正弦波
	AM 深度	100%
	FM 偏移	100Hz
	FSK 跳跃频率	100Hz
	FSK 频率	10Hz
	PWM 占空比	50%
	PWM 频率	20kHz
	调制解调器状态	Off
扫描	起始/截止频率	100Hz/1kHz

	扫描时间	1s
	起始/截止幅值	1.000/3.000 Vpp
	扫描功能	线性
	扫描状态	Off
Burst	Burst 频率	1kHz
	N 次循环	1
	Burst 周期	10ms
	Burst 起始相位	0°
	Burst 状态	Off
触发	触发源	内部(立即)
接口设置	GPIB 地址	10
	接口	USB
	LAN	DHCP
校准	校准菜单	加密

操作

本章节介绍如何输出基本波形。调制、扫描、burst 和任意波形详情见 90 页和 188 页调制和任意波章节。双通道和多台操作详情见 192&200 页。

选择通道	71
CH1/CH2	71
选择波形	72
正弦波	72
设置方波	73
三角波	74
设置脉冲宽度	75
设置脉冲上升&下降时间	76
设置脉冲边沿时间	77
设置脉冲占空比	78
设置斜波	79
噪声波	81
谐波	81
谐波阶	82
谐波特性	84
DC 波形	85
设置波形频率	86
设置幅值	88
设置 DC 偏移	89

选择通道

AFG-3022 或 AFG-3032 为双通道机型，操作前需选择输出通道。

CH1/CH2


面板操作

- 1. 按 CH1 或 CH2 键



- 2. 已选通道呈亮色，未选通道呈灰色

屏幕截图如下，已选 CH1




选择波形

AFG-30XX 可以输出 8 种标准波形：正弦波、方波、三角波、脉冲波、斜波、噪声波、谐波和 DC 波形。


正弦波

面板操作


- 1. 按 Waveform 键




- 2. 按 F1 (Sine)



设置方波

面板操作	1. 按 Waveform 键	
	2. 按 F2 (Square)创建一个方波	 
	3. 按 F1 (Duty), 占空比参数指示 灯变亮	 
	4. 使用方向键和可调旋钮或数字 键盘输入占空比范围	  
	5. 按 F5 (%)选择%单位	 


范围	频率	占空比范围
	≤25MHz (20MHz AFG-3021/3022)	20%~80%
	25MHz~≤30MHz	40%~60%




三角波

面板操作

1. 按 Waveform 键



2. 按 F3 (Triangle)




设置脉冲宽度

脉冲宽度设置与上升&下降时间设置或边沿时间设置和周期设置有关，公式如下：

$$\text{脉冲宽度} - 0.625 * [(\text{上升时间} - 0.6\text{nS}) + (\text{下降时间} - 0.6\text{nS})] \geq 0$$

$$\text{周期} \geq \text{脉冲宽度} + 0.625 * [(\text{上升时间} - 0.6\text{nS}) + (\text{下降时间} - 0.6\text{nS})]$$


脉冲宽度定义：在一个完整周期内，从 50% 上升沿阈值到 50% 下降沿阈值间的时间。



上升和下降时间设置见 76 页，边沿时间设置见 77 页。或通过设置脉冲占空比代替脉冲宽度，见 78 页。

面板操作

1. 按 Waveform 键




2. 按 F4 (Pulse) 创建一个脉冲波



3. 按 F1 (Width), 脉宽参数指示灯变亮




4. 使用方向键和可调旋钮或数字键盘输入脉冲宽度



5. 按 F2~F5 选择单位范围



范围	脉冲宽度	20ns~999.83ks
 注意	分辨率:	Freq <25MHz
		(20MHz AFG-3021/3022): 0.01ns
		脉冲宽度(或 3 位分辨率)
		Freq <8.5 kHz: 0.0001%占空比



设置脉冲上升&下降时间

面板操作

1. 按 Waveform 键



2. 按 F4 (Pulse)创建一个脉冲波




3. 按 F3 (Rise)或 F4 (Fall) , 上升或下降参数指示灯变亮



3. 按 F5 (Edge Time), 边沿时间
参数指示灯变亮



4. 使用方向键和可调旋钮或数字
键盘输入边沿时间



5. 按 F2~F5 选择单位范围



范围	边沿时间范围	9.32ns~799.9ks
 注意	占空比注意事项:	宽度 - 1.25 * (边沿时间 - 0.6ns) ≥ 0 周期 ≥ 脉冲宽度 + 1.25*(边沿时间 - 0.6ns) 0.0001%占空比分辨率

设置脉冲占空比时间

也可以通过设置脉冲占空比代替脉冲宽度的设置。可调占空比与上升 & 下降时间设置有关，公式如下：

$$\text{Duty} \geq 0.625 \times 100 \times [\text{上升时间} - 0.6\text{ns} + \text{下降时间} - 0.6\text{ns}] / \text{周期}$$

Or

$$\text{Duty} \leq 100 - \{62.5 \times [(\text{上升时间} - 0.6\text{ns}) + (\text{下降时间} - 0.6\text{ns})] / \text{周期}\}$$

面板操作

1. 按 Waveform 键



2. 按 F4 (Pulse)创建一个脉冲波

Pulse

F4
3. 按 F2 (DUTY), DUTY 参数指示灯变亮

DUTY

F2
4. 使用方向键和可调旋钮或数字键盘输入占空比时间

7894561230•%
5. 按 F1 选择%单位

%

F1

范围	占空比范围	0.0170%~99.983%
		分辨率 0.0001%

设置斜波

- 面板操作

1. 按 Waveform 键

Waveform
2. 按 F5 (Ramp)创建一个斜波

Ramp

F5
3. 按 F1 (SYM), SYM 参数指示灯变亮

SYM

F1
4. 使用方向键和可调旋钮或数字键盘输入对称百分比

7894561230•%

5. 按 F5 选择%单位

%

F 5

范围

对称

0%~100%



噪声波

面板操作



1. 按 Waveform 键



2. 按 F6 (More)



3. 按 F1 (Noise)



谐波

谐波功能创建一个谐波正弦波，并指定谐波数。

面板操作

1. 按 Waveform 键



2. 按 F6 (More)




3. 按 F2 (Harmonic)



4. 按 F1 (Total)谐波总数。包含基波



5. 使用方向键和可调旋钮或数字键盘输入谐波数




范围

谐波数

2 ~ 8

6. 按 F1 (Enter)




谐波阶数

在选择谐波总数之后(上章节)，可以设置使用的谐波阶数：奇次、偶次、全部或自定义设置。

面板操作

1. 按 Waveform 键



2. 按 F6 (More)




3. 按 F2 (Harmonic)



4. 按 F2 (Type)



5. 按 F1 ~ F4 选择谐波阶数，包含合成谐波



注：仪器处理波形需等待片刻


范围	谐波	偶次, 奇次, 全部, 自定义
----	----	-----------------

- 选择自定义阶数
1. 如果选择自定义设置，每阶均可以独立选择或取消
 2. 开启或关闭自定义设置：

在波形显示屏的“Type”参数上，旋转可调旋钮将光标移至期望阶数



- 绿点表示可选阶数
- 灰点表示取消阶数
- 黄点表示光标位置
- 阶数从 1st (左)~8th (右)



3. 使用 F1 或 F2 软键开启或关闭所选阶数






谐波特性

每个谐波阶数的幅值和相位均可独立设置。默认情况下，幅值和基频是一样的，其中相位设置为 0° 。

面板操作

1. 按 Waveform 键



2. 按 F6 (More)



3. 按 F2 (Harmonic)



4. 按 F3 (Order)




5. 按 F1 (Order)



6. Order 参数指示灯呈亮红色

7. 使用方向键和可调旋钮或数字键盘输入阶数




8. 按 F5 (Enter)



9. 按 F2 (Amplitude)



10. 使用方向键和可调旋钮或数字
键盘输入预先所选阶数的幅值




11. 按 F4~F5 选择幅值单位



12. 按 F3 (Phase)



13. 使用方向键和可调旋钮或数字
键盘输入预先所选阶数的相位




14. 按 F5 (Degree)



DC 波

面板操作

1. 按 Waveform 键




2. 按 F6 (More)



3. 按 F3 (DC)





设置波形频率


面板操作

1. 按 FREQ/Rate 键



2. FREQ 参数指示灯变亮

3. 使用方向键和可调旋钮或数字键盘输入频率




4. 按 F2~F6 选择频率单位



范围	正弦波	1μHz~30MHz (20MHz AFG-3021/3022)
	方波	1μHz~30MHz (20MHz AFG-3021/3022)
	三角波	1μHz~1MHz
	脉冲波	1μHz~25MHz (20MHz AFG-3021/3022)

斜波 1μHz~1MHz



设置幅值


面板操作

1. 按 AMPL 键



2. AMPL 参数变亮


3. 使用方向键和可调旋钮或数字键盘输入幅值



4. 按 F2~F6 选择单位类型



范围	50Ω load	High Z
范围	1mVpp~10Vpp	2mVpp~20Vpp
单位	Vpp, Vrms, dBm	



设置 DC 偏移


面板操作

1. 按 DC Offset 键



2. DC Offset 参数变亮

3. 使用方向键和可调旋钮或数字
键盘输入 DC 偏移



4. 按 F5 (mVDC)或 F6 (VDC)选
择电压范围




50Ω load

High Z

范围

±5Vdc

±10Vdc



调制

AFG-3021, AFG-3022, AFG-3031 & AFG-3032 任意波形信号发生器可以产生 AM、FM、FSK 和 PWM 调制波形，以及扫描波形(频率, 幅值)和 burst 波形。波形类型不同，调制参数的设置也有所不同。

AFG-3022 & AFG-3032 可以同时开启两种不同的调制模式。


幅值调制(AM)	93
选择 AM 调制	94
AM 载波波形	94
载波频率	95
调制波形	96
AM 频率	98
调制深度	100
选择 (AM) 调制源	102
频率调制(FM)	104
选择频率调制(FM)	105
FM 载波波形	105
FM 载波频率	106
FM 波形	107
调制频率	109
频率偏移	111
选择 (FM) 调制源	112
频移键控调制(FSK)	114
选择 FSK 调制	115
FSK 载波波形	115
FSK 载波频率	116

FSK 跳跃频率	117
FSK 频率	118
FSK 调制源	119
相位调制 (PM)	121
选择相位调制 (PM)	122
PM 载波波形	122
PM 载波频率	123
PM 波形	124
调制频率	126
相位调制偏移	128
SUM 调制	130
选择 SUM 调制	131
SUM 载波波形	131
SUM 载波频率	133
SUM 调制波形	133
SUM 频率	134
SUM 幅值	136
SUM 调制源	137
脉冲宽度调制	139
选择脉冲宽度调制	140
PWM 载波波形	140
PWM 载波频率	141
PWM 调制波形	141
调制波形频率	142
调制占空比	143
PWM 调制源	145
扫描	147
选择扫描模式	148
扫描类型	148
设置起始和停止频率/幅值	149

中心频率和跨距.....	150
扫描模式.....	152
扫描功能.....	152
扫描波形类型	153
扫描时间.....	154
扫描触发源.....	156
Burst 模式	158
选择 Burst 模式	158
Burst 模式	158
Burst 频率	159
Burst 循环/Burst 计数.....	160
无限次 Burst 计数.....	162
Burst 周期	162
Burst 相位	164
Burst 触发源	166
Burst 延迟	168
门限触发极性	169
门限触发相位	169

幅值调制(AM)

AM 波形由载波和调制波组成。载波幅值与调制波幅值有关。AFG-30XX 信号发生器可以设置载波频率、幅值、偏移电压以及内部或外部调制源。当使用信号发生器时，每个所选通道一次仅能创建一种调制波形。




选择 AM 调制

面板操作

1. 按 MOD 键



2. 按 F1 (AM)




AM 载波波形

背景

AM 载波可用波形：正弦波、方波、三角波、斜波、脉冲波、噪声波或任意波。默认正弦波。不可将谐波和 DC 用作载波波形。在选择载波波形前，先选择 AM 调制模式，见 35 或 96 页。

选择一个标准载波波形

1. 按 Waveform 键



2. 按 F1~F5 选择载波波形



选择一个任意波 3. 见任意波快速指南或任意波章 见 43 页
作为载波波形 节 见 188 页

范围 AM 载波波形 正弦波, 方波, 三角波, 脉冲波, 斜波, 任意波

载波频率

最大载波频率与所选载波波形有关。默认载波频率 1kHz。


面板操作

1. 按 FREQ/Rate 键



2. FREQ 参数指示灯变亮

3. 使用方向键和可调旋钮或数字键盘输入载波频率



4. 按 F2~F6 选择频率范围





范围	载波波形	载波频率
	正弦波	1μHz~30MHz (20MHz AFG-3021/3022)
	方波	1μHz~30MHz (20MHz AFG-3021/3022)
	三角波	1μHz~1MHz
	脉冲波	1μHz~25MHz (20MHz AFG-3021/3022)

斜波	1μHz~1MHz
噪声波	N/A
ARB	125MHz~1μHz

调制波形

信号发生器可以接收内部和外部源。AFG-30XX 的调制波形包括正弦波、方波、三角波、上斜波、下斜波。默认为正弦波。

面板操作

1. 选择 MOD



2. 按 F1 (AM)




3. 按 F4 (Shape)





4. 按 F1~F5 选择波形形状




~




注意	方波	50% 占空比
	上斜波	100% 对称
	三角波	50% 对称
	下斜波	0% 对称



AM 频率

调制波形频率(AM 频率)范围 2mHz~20kHz。

面板操作

1. 按 MOD 键




2. 按 F1 (AM)




3. 按 F3 (AM Freq)



4. AM Freq 参数变亮



5. 使用方向键和可调旋钮或数字键盘输入 AM 频率



6. 按 F1~F3 选择频率范围



范围	调制频率	2mHz~20kHz
	默认频率	100Hz

调制深度

调制深度决定 AM 波形的最大和最小幅值。调制深度(百分比)定义为：
调制波形电压与载波波形电压之比乘以 100：


$$\text{ModulationDepth} = \frac{\text{ModulatingWaveVoltage}}{\text{CarrierWaveVoltage}} \times 100$$

调制波形最大和最小峰峰值电压定义为：

$$V_{\max} = V_{pp} = V_c \times \left(1 + \frac{\text{Depth}}{100}\right)$$

$$V_{\min} = V_c \times \left(1 - \frac{\text{Depth}}{100}\right)$$

下图解释了调制信号、载波信号和合成输出信号之间的关系。注：
 V_{pp} 为 AFG 的幅值设置



面板操作

1. 按 MOD 键




2. 按 F1 (AM)




3. 按 F2 (Depth)



4. AM Depth 参数变亮



5. 使用方向键和可调旋钮或数字
键盘输入 AM 深度



6. 按 F1 (%)选择%单位



范围

深度

0%~120%

默认深度

100%

注意

即使调制深度大于 100%，输出也不超过 $\pm 5V_{Peak}$ (10k Ω 负载)。

如果选择外部调制源，那么调制深度将由后面板 MOD INPUT 上的 $\pm 5V$ 信号电压控制。例如，如果调制深度设置为 100%，那么最大幅值为+5V, 最小幅值为-5V。

选择 (AM)调制源

信号发生器接受用于 AM 调制的内部或外部源。默认为内部源。

面板操作

1. 按 MOD 键



2. 按 F1 (AM)



3. 按 F1 (Source)




4. 按 F1(INT)或 F2(EXT)选择调制源



外部源


后面板 MOD INPUT 端子接收外部调制信号



AFG-3022/3032 使用 CH1 或 CH2 MOD 输入与调制所用的通道有关。


注意

如果选择外部调制源，那么调制深度将由后面板 MOD INPUT 上的±5V 信号电压控制。例如，如果调制深度设置为 100%，那么最大幅值为+5V，最小幅值为-5V。



频率调制(FM)

FM 波形由载波和调制波组成。载波的瞬时频率随调制波形的幅值而变化。当使用信号发生器时，每个所选通道一次仅能创建一种调制波形。



选择频率调制(FM)


选择 FM 后，调制波形与载波频率、输出幅值和偏置电压有关。

面板操作

1. 按 MOD 键



2. 按 F2 (FM)



FM 载波波形

背景

默认载波为正弦波。载波可选波形：正弦波、方波、三角波或斜波。噪声波、脉冲波、ARB、DC 和谐波不能用作载波。

面板操作

1. 按 Waveform 键



2. 按 F1~F5 选择载波波形(bar F4)



范围	载波波形	正弦波,方波,三角波,斜波
----	------	---------------

FM 载波频率

使用 AFG-30XX 时，载波频率必须大于或等于频率偏移。如果频率偏移大于载波频率，函数发生器会自动将偏移调整到当前载波频率所允许的最大值。载波最大频率与所选波形有关。


面板操作

1. 按 **FREQ/Rate** 键选择载波频率



2. **FREQ** 参数指示灯变亮

3. 使用方向键和可调旋钮或数字键盘输入载波频率



4. 按 **F2~F6** 选择频率单位




范围	载波波形	载波频率
	正弦波	1 μ Hz~30MHz (20MHz AFG-3021/3022)
	方波	1 μ Hz~30MHz (20MHz AFG-3021/3022)
	三角波	1 μ Hz~1MHz
	斜波	1 μ Hz~1MHz
	默认频率	1 kHz

FM 波形

信号发生器可以接收内部和外部源。AFG-30XX 的内部调制波形包括正弦波、方波、三角波、正斜波和负斜波(UpRamp, DnRamp)。默认为正弦波。

面板操作	1. 选择 MOD	
	2. 按 F2 (FM)	 
	3. 按 F4 (Shape)	 
	4. 按 F1~F5 选择波形	  ~  

注意	方波	50% 占空比
	正斜波	100% 对称
	三角波	50% 对称
	负斜波	0% 对称



调制频率

信号发生器将接受用于 FM(调频)的内部或外部调制源。

面板操作

1. 按 MOD 键




2. 按 F2 (FM)




3. 按 F3 (FM Freq)



4. FM Freq 参数变亮



5. 使用方向键和可调旋钮或数字键盘输入 FM 频率



6. 按 F1~F3 选择频率单位



范围

调制频率

2mHz~20kHz

默认频率

100Hz

频率偏移

频率偏移是载波与调制波的峰值频率偏差。

面板操作

1. 按 MOD 键




2. 按 F2 (FM)




3. 按 F2 (Freq Dev)



4. Freq Dev 参数变亮



5. 使用方向键和可调旋钮或数字键盘输入频率偏移



6. 按 F1~ F5 选择频率单位



范围	频率偏移	DC~30MHz(20MHz AFG-3021/3022)
		DC~1MHz(三角波)
	默认偏移	100kHz

选择 (FM) 调制源

信号发生器将接受用于 FM 调制的内部或外部源。默认为内部源。

面板操作

1. 按 MOD 键



2. 按 F2 (FM)




3. 按 F1 (Source)




4. 按 F1 (INT)或 F2 (EXT)选择调制源










外部源

后面板 MOD INPUT 端子接收外部调制信号




AFG-3022/3032 使用 CH1 或 CH2 MOD 输入与调制所用的通道有关

注意

如果选择外部调制源，那么频偏将由后面板 MOD INPUT 上的±5V 信号电压控制。频偏与调制信号电压电平成比例。例如，如果调制电压为+5V，那么频偏将等于设置的频偏。外部信号电平越低，偏移就越小；而负信号电平将会使频偏频率降至载波频


率之下



频移键控 (FSK) 调制

频移键控调制在两个预设频率(载波频率,跳跃频率)间交替输出频率。内部频率发生器或后面板 **Trigger INPUT** 上的电压电平决定交替频率。

所选通道每次仅允许使用一种调制模式。当开启 **FSK** 调制时, 其它调制模式将禁用。扫描和 **Burst** 模式不可使用 **FSK** 调制。在启用 **FSK** 时, 关闭扫描或 **Burst** 模式。



选择 FSK 调制


当使用 FSK 模式时，输出波形使用默认载波频率、幅值和偏置电压。

面板操作

1. 按 MOD 键



2. 按 F3 (FSK)




FSK 载波波形

背景

载波波形包含：正弦波、方波、三角波和斜波。默认正弦波。脉冲波、噪声、斜波、DC 和 ARB 无法用作载波。

面板操作

1. 按 Waveform 键



2. 按 F1~F5 选择载波波形



范围	载波波形	正弦波, 方波, 三角波, 斜波
----	------	------------------

FSK 载波频率

最大载波频率与载波波形有关。默认载波频率均为 1kHz。选择 EXT 时，TriggerINPUT 信号的电压电平控制输出频率。当 TriggerINPUT 信号为逻辑低电平时，输出载波频率；当信号为逻辑高电平时，输出跳跃频率。


面板操作

1. 按 **FREQ/Rate** 键选择载波频率



2. **FREQ** 参数指示灯变亮

3. 使用方向键和可调旋钮或数字键盘输入载波频率



4. 按 **F2~F6** 选择 FSK 频率单位



范围	载波波形	载波频率
	正弦波	1μHz~30MHz (20MHz AFG-3021/3022)
	方波	1μHz~30MHz (20MHz AFG-3021/3022)
	三角波	1μHz~1MHz
	斜波	1μHz~1MHz

FSK 跳跃频率

默认跳跃频率均为 100 Hz。50% 占空比方波用作内部调制波。选择 EXT 时，TriggerINPUT 信号的电压电平控制输出频率。当 TriggerINPUT 信号为逻辑低电平时，输出载波频率；当信号为逻辑高电平时，输出跳跃频率。

面板操作

1. 按 MOD 键




2. 按 F3 (FSK)




3. 按 F2 (Hop Freq)



4. Hop Freq 参数变亮



5. 使用方向键和可调旋钮或数字键盘输入跳跃频率



6. 按 F1~F5 选择频率范围



范围	波形	载波频率
	正弦波	1μHz~30MHz (20MHz AFG-3021/3022)
	方波	1μHz~30MHz (20MHz AFG-3021/3022)
	三角波	1μHz~1MHz
	斜波	1μHz~1MHz

FSK 频率

FSK 频率是决定输出载波频率还是跳跃频率的频率值。FSK 频率功能仅适合内部 FSK 源。

面板操作

1. 选择 MOD




2. 按 F3 (FSK)




3. 按 F3 (FSK Rate)



4. FSK Rate 参数变亮



5. 使用方向键和可调旋钮或数字
键盘输入 FSK 频率



6. 按 F1~F5 选择频率单位



范围	FSK 频率	2mHz~100kHz
	默认	10Hz

注意 如果选择外部源，忽略 FSK 频率设置

FSK 源

AFG-30XX 接受内部和外部 FSK 源，默认为内部源。当选择内部 FSK 源时，使用 FSK Rate 功能设置 FSK 频率。当选择外部源时，FSK 频率等于后面板 TriggerINPUT 信号频率。

面板操作 1. 按 MOD 键



2. 按 F3 (FSK)



3. 按 F1 (Source)




4. 按 F1 (INT)或 F2 (EXT)选择
FSK 源




注意

Trigger INPUT 端子不能设置边沿极性



相位调制 (PM)

PM 波形由载波和调制波生成。调制波的量级决定载波相位。当使用信号发生器时，所选通道每次仅可以创建一种调制波形。



选择相位调制 (PM)


当选择 PM 时，调制波形与载波频率、输出幅值和偏移电压有关。

面板操作

1. 按 MOD 键



2. 按 F4 (PM)




PM 载波波形

背景

默认正弦波。载波波形包含：正弦波、方波、三角波或斜波。脉冲波、噪声、ARB、DC 和谐波无法用作载波。

面板操作

1. 按 Waveform 键



2. 按 F1~F5 选择载波波形(bar F4)



范围	载波波形	正弦波, 方波, 三角波, 斜波
----	------	------------------

PM 载波频率

最大载波频率与所选载波波形有关。默认载波频率均为 1kHz。


面板操作

1. 按 **FREQ/Rate** 键选择载波频率



2. **FREQ** 参数指示灯变亮

3. 使用方向键和可调旋钮或数字键盘输入载波频率



4. 按 **F2~F6** 选择频率单位



范围	载波波形	载波频率
	正弦波	1 μ Hz~30MHz (20MHz AFG-3021/3022)
	方波	1 μ Hz~30MHz (20MHz AFG-3021/3022)
	三角波	1 μ Hz~1MHz
	斜波	1 μ Hz~1MHz
	默认频率	1 kHz

PM 波形

信号发生器可以接收内部和外部源。AFG-30XX 的内部调制波形包括正弦波、方波、三角波、正斜波和负斜波(UpRamp, DnRamp)。默认为正弦波。

面板操作

1. 选择 MOD

MOD

2. 按 F4 (PM)

PM

F 4

3. 按 F4 (Shape)

Shape

F 4

4. 按 F1~F5 选择波形形状

Sine


F 1

~

DnRamp

F 5

注意	方波	50%占空比
	正斜波	100%对称
	三角波	50%对称
	负斜波	0%对称



调制频率

使用内部源时，PM Freq 参数设置相位调制功能的调制频率。

面板操作

1. 按 MOD 键




2. 按 F4 (PM)




3. 按 F3 (PM Freq)



4. PM Freq 参数变亮



5. 使用方向键和可调旋钮或数字键盘输入 PM 频率



6. 按 F1~F3 选择频率单位



范围

调制频率

2mHz~20kHz

默认频率

100Hz

相位调制偏移

相位调制偏移是调制波形与载波的峰值相位偏差。

面板操作

1. 按 MOD 键




2. 按 F4 (PM)




3. 按 F2 (Phase Dev)



4. PM Dev 参数变亮



5. 使用方向键和可调旋钮或数字键盘输入相位偏移



6. 按 F1 选择单位



范围

PM 偏移

0~360°


默认

180°

SUM 调制

SUM 调制将调制波形加入载波波形。以载波幅值的百分比形式设置调制波形幅值。

所选通道每次仅能开启一种调制模式。如果开启 SUM，其它调制模式将关闭。同样的，**burst** 和扫描模式也不能与 SUM 调制一起使用，在开启 SUM 后关闭。



选择 SUM 调制


选择 SUM 时需考虑载波频率、幅值和频率。

面板操作

1. 按 MOD 键



2. 按 F5 (SUM)




SUM 载波波形

背景

SUM 载波可设为正弦波、三角波、脉冲波或斜波，默认正弦波。三角波、噪声波、脉冲、ARB、DC 和谐波不可用作载波。

面板操作

1. 按 Waveform 键



2. 按 F1~F5 选择载波波形(bar F3)



范围	载波波形	正弦波、三角波、脉冲波、斜波
----	------	----------------

SUM 载波频率

最大载波频率与所选载波波形有关，默认均为 1kHz。


面板操作

1. 按 **FREQ/Rate** 键选择载波频率



2. **FREQ** 参数变亮

3. 使用方向键和可调旋钮或数字键盘输入载波频率



4. 按 **F2~F6** 选择频率单位



范围	载波波形	载波频率
	正弦波	1μHz~30MHz (20MHz AFG-3021/3022)
	三角波	1μHz~1MHz
	斜波	1μHz~1MHz
	默认频率	1 kHz

SUM 调制波形

内部调制波形包含正弦波、方波、三角波、正斜波和负斜波，默认正弦波。

面板操作


1. 按 MOD 键
2. 按 F5 (SUM)
3. 按 F4 (Shape)
4. 按 F1~F5 选择波形



范围

波形

- 方波50% 占空比
- 正斜波100% 对称
- 三角波50%对称
- 负斜波0%对称



SUM 频率

设置调制波形的频率。

面板操作

1. 按 MOD 键




2. 按 F5 (SUM)




3. 按 F3 (SUM Freq)



4. SUM Freq 参数变亮



5. 使用方向键和可调旋钮或数字键盘输入 SUM 频率



6. 按 F1~F3 选择频率单位



范围

SUM 频率

2mHz~20kHz

默认

20kHz

SUM 幅值

以载波幅值的百分比形式设置调制波形的幅值。

面板操作

1. 按 MOD 键




2. 按 F5 (SUM)




3. 按 F2 (SUM Ampl)



4. SUM Ampl 参数变亮



5. 使用方向键和可调旋钮或数字键盘输入 SUM 幅值



6. 按 F1 (%) 选择百分比单位



范围

SUM 幅值

0% ~ 100%

默认 50%

SUM 调制源

AFG-30XX 接受内部或外部调制源，默认内部调制源。

面板操作

1. 按 MOD 键



2. 按 F5 (SUM)




3. 按 F1 (Source)




4. 按 F1 (INT)或 F2 (EXT)选择调制源










外部调制源


从后面板的 MOD INPUT 端子接收外部调制信号



AFG-3022/3032 使用 CH1 或 CH2 MOD 输入与使用哪一个调制通道有关

注意


如果选择外部调制源，那么 SUM 幅值将由后面板 MOD INPUT 端子上的± 5V 信号电压控制。例如，如果 SUM 调制设为 100%，那么最大幅值限定在 +5V，最小幅值限定在 -5V



脉冲宽度调制

对于脉宽调制，调制波形的瞬时电压决定脉冲宽度。

所选通道每次仅允许启用一种调制模式。如果使用 PWM，其它调制模式关闭。同样的，burst 和扫描模式不可与 PWM 一起使用。启用 PWM 后关闭扫描和 burst 模式。




选择脉冲宽度调制

选择 PWM 时，需要考虑载波频率的当前设置、幅值调制频率、输出和偏移电压。

面板操作

1. 按 Waveform 键




2. 按 F2 (Square)



3. 按 MOD 键



4. 按 F6 (PWM)



PWM 载波波形

PWM 使用方波作为载波波形，否则会提示错误。

PWM 载波频率

载波频率与方波有关。默认 1kHz。


面板操作

1. 按 **FREQ/Rate** 键选择载波频率



2. **FREQ** 参数变亮

3. 使用方向键和可调旋钮或数字键盘输入载波频率



4. 按 **F2~F6** 选择 PWM 频率单位



范围

频率

1μHz~30MHz
(20MHz AFG-3021/3022)

PWM 调制波形

内部调制波形包括正弦波、方波、三角波、正斜波和负斜波。默认正弦波。

面板操作

1. 按 **MOD** 键



2. 按 **F6 (PWM)**



3. 按 F4 (Shape)




4. 按 F1~F5 选择波形



范围

波形

- | | |
|-----|--------|
| 方波 | 50%占空比 |
| 正斜波 | 100%对称 |
| 三角波 | 50%对称 |
| 负斜波 | 0%对称 |



调制波形频率

面板操作

1. 按 MOD 键




2. 按 F6 (PWM)




3. 按 F3 (PWM Frequency)



4. PWM Freq 参数变亮



5. 使用方向键和可调旋钮或数字键盘输入 PWM 频率



6. 按 F1~F3 选择频率单位



范围	PWM 频率	2mHz~20kHz
	默认	20kHz

调制占空比

设置占空百分比。

面板操作

1. 按 MOD 键




2. 按 F6 (PWM)




3. 按 F2 (Duty)



4. Duty 参数变亮



5. 使用方向键和可调旋钮或数字
键盘输入占空比



6. 按 F1 (%)选择百分号




范围	占空比	0% ~ 100%
	默认	50%

注意 可以使用外部调制源调制脉冲波形。此时，MOD INPUT 端的±5V 电压控制脉宽


PWM 调制源

AFG-30XX 接受内部和外部 PWM 调制源。默认内部调制源。

面板操作	1. 按 MOD 键	
	2. 按 F6 (PWM)	 
	3. 按 F1 (Source)	 
	4. 按 F1 (INT)或 F2 (EXT)选择调制源	  ~  

外部调制源	从后面板的 MOD INPUT 端子接收外部调制信号	
	AFG-3022/3032 使用 CH1 或 CH2 MOD 输入与使用哪一个调制通道有关	

注意	如果选择外部调制源，那么脉宽调制由后面板 MOD INPUT 端子上的±5V 电压控制。例如：如果调制深度设为 100%，则在调制信号为+5V 时，输出最大脉宽；在调制信号为-5V 时，输出最小脉宽
----	---




扫描

信号发生器可以对正弦波、方波、斜波和三角波完成频率扫描，或者对正弦波、方波、三角波、脉冲波、斜波、噪声波和 ARB 波完成幅值扫描。开启扫描模式后，该通道的 **Burst** 或其它调制模式关闭。

当扫描类型设为频率时，信号发生器以指定步进从起始频率到停止频率扫描。

当扫描类型设为幅值时，信号发生器以指定扫描时间从起始幅值到停止幅值扫描。

如果使用手动或外部调制源时，信号发生器可以输出一个单相扫描。扫描以线性或对数步进。函数发生器也可以以频率扫描或幅值扫描，频率扫描和幅值扫描不可同时使用。



选择扫描模式

按 **Sweep** 键进入扫描模式。如果不预先设置，使用默认的输出幅值、偏移和频率。




扫描类型

选择频率扫描或幅值扫描。

面板操作

1. 按 **Sweep** 键




2. 按 **F2 (Type/MOD)**



3. 按 **F1 (Type)**




4. 按 **F1 (Frequency)**或 **F2 (Ampltd)**选择频率或幅值扫描



例如

频率

幅值




设置起始和停止频率/幅值

起始和停止频率/幅值定义扫描上下限。信号发生器从起始频率/幅值扫描至停止频率/幅值，然后又复位回起始频率/幅值。在整个扫描频率范围内(100 μ Hz-30MHz)，相位连续。对于幅值扫描模式，幅值从1mVpp-10Vpp。

面板操作

1. 按 Sweep 键



2. 按 F3 (Start)或 F4 (Stop)选择起始或停止频率/幅值



3. Start 或 Stop 参数变亮

Start

(显示频率)




Stop

(显示幅值)



4. 使用方向键和可调旋钮或数字键盘输入 Stop/Start 频率/幅值



5. 按 F1~F5 选择 Start/Stop 频率/幅值单位



范围 (频率)	扫描范围	1μHz~30MHz(正弦波/方波) (20MHz AFG-3021/3022)
		1μHz~1MHz (斜波/三角波)
	起始 – 默认	100Hz
	停止 – 默认	1kHz
范围(幅值)	扫描范围	1mVpp~10Vpp (into 50Ω)
	起始 – 默认	1Vpp
	停止 – 默认	3Vpp
注意	从低至高的频率/幅值扫描，设置起始频率/幅值<停止频率/幅值。	
	从高至低的频率/幅值扫描，设置起始频率/幅值>停止频率/幅值。	

中心频率和跨距

中心频率和跨距决定扫描上限和下限(起始/停止)。仅当扫描类型 = 频率时，才可以进行该设置。

面板操作

1. 按 Sweep 键



2. 按 F6 (More)




3. 按 F1 (Span)或 F2 (Center)选择跨距或中心频率




4. Span 或 Center 参数变亮


跨距



中心频率



5. 使用方向键和可调旋钮或数字
键盘输入 Span/Center 频率



6. 按 F1~F5 选择 Start/Stop 频
率单位



范围

中心频率	1μHz~30MHz(正弦波/方波) (20MHz AFG-3021/3022) 1μHz~1MHz (三角波/斜波)
跨距频率	DC~30MHz(正弦波/方波) (20MHz AFG-3021/3022) DC ~1MHz (三角波/斜波)
中心频率 – 默认	550Hz
跨距频率–默认	900Hz

- 注意
- 设置正频率跨距，从低频到高频扫描
 - 设置负频率跨距，从高频到低频扫描

扫描模式

分持续扫描或门限扫描。当设为持续模式时，内部触发控制扫描功能的持续输出。当设为门限模式时，扫描输出同步于触发输入。

面板操作

1. 按 SWEEP 键




2. 按 F2 (Type/MOD)



3. 按 F2 (Mode)



4. 按 F1 (Cont)或 F2 (Gated)选择持续或门限模式



扫描功能

可选择线性或对数扫描。默认线性扫描。

面板操作

1. 按 SWEEP 键




2. 按 F2 (Type/MOD)



3. 按 F3 (Function)



4. 按 F1 (Linear)或 F2 (Log)选择
线性或对数扫描




扫描波形

设置扫描波形。

锯齿波创建锯齿形状的扫描波形:

三角波创建羽毛球球形的扫描波形:



面板操作

1. 按 SWEEP 键



2. 按 F2 (Type/MOD)

TypeMOD

F 2


3. 按 F4 (Sawtooth)或 F5 (Triangle)选择波形

Sawtooth

Triangle

F 4

F 5



扫描时间

完成一次从起始到截止频率/幅值扫描所花费的时间称为扫描时间。
信号发生器根据扫描的持续时间，自动确定扫描的离散频率或幅值数。

面板操作

1. 按 SWEEP 键


Sweep

2. 按 F5 (SWP Time)


SWP Time

F 5

3. 扫描时间参数变亮



4. 使用方向键和可调旋钮或数字
键盘输入扫描时间



5. 按 F1~F2 选择时间单位



范围	扫描时间	1ms ~ 500s
	默认	1s

扫描触发源

扫描模式下，信号发生器在收到触发信号后扫描一次。扫描输出完成后，信号发生器输出起始频率，并等待下一次触发。触发源可以是内部(可设触发间隔)触发、手动触发或外部触发。默认内部触发。

面板操作

1. 按 SWEEP 键



2. 按 F1 (TRIG Type)



3. 按 F1 (INT), F2 (EXT)或 F3 (Manual)选择触发源



内部触发


1. 如果选择 INT (内部触发)，按 F5 (TRIG Time)设置内部触发的时间间隔



2. TRIG Time 参数变亮



3. 使用方向键和可调旋钮或数字键盘输入触发间隔时间



4. 按 F1~F2 选择时间单位



范围	内部触发间隔	1ms ~ 500s
----	--------	------------


手动触发	5. 如果选择手动触发，按 F1 (Trigger)手动开启每次扫描	Trigger F 1
	6. 按 F6 (Return)返回菜单	Return F 6

注意	根据触发时间的设定，使用内部触发源将产生一个持续的间隔扫描
	如果使用外部触发源，后面板 Trigger INPUT 端每接收到一个触发脉冲(TTL)就输出一扫描
	触发周期必须等于或大于扫描时间+1ms



Burst 模式

信号发生器能创建一个指定循环次数的 **Burst** 波形。**Burst** 模式支持正弦波、方波、三角波、脉冲波、斜波、噪声(仅门限 **Burst** 模式)波形*。



*ARB 功能也有一个 N-Cycle Burst 模式，但不可理解为 **Burst** 功能模式

选择 Burst 模式

选择 **Burst** 模式后，所选通道的任何调制或扫描模式都将自动关闭。如果没有设置，输出幅值、偏移和频率启用默认值。



Burst 模式

触发(N Cycle)或门限模式可以设置 **Burst** 模式。在 N Cycle / 触发模式下，信号发生器每接收到触发时都将输出一个指定循环次数的波形 (**Burst**)。执行完成后，信号发生器停止并等待下一次触发。默认为 N Cycle。触发模式可以使用内部或外部触发。

相比指定循环次数，门限模式使用外部触发开启或关闭输出。当 **Trigger INPUT** 信号为高电平时，波形持续输出。当 **Trigger INPUT** 信号为低电平时，信号发生器在输出最后一个完整波形后停止。输出电压电平仍与 **Burst** 波形的起始相位相同。

Burst 模式	Burst 计数	Burst 周期	相位	触发源
Triggered(Int)	可用	可用	可用	立即
Triggered (Ext)	可用	不可用	可用	EXT
Gated pulse (Ext)	不可用	不可用	可用	不可用

门限模式下，忽略 **Burst** 计数、**Burst** 周期和触发源。如果此时触发，将不会有任何效果，也不会产生任何错误

面板操作

1. 按 **Burst** 键



2. 选择 **N Cycle (F1)**或 **Gate (F2)**



Burst 频率

在 **N Cycle** 和门限模式下，波形频率定义了 **Burst** 波形的重复率。在 **N Cycle** 模式下，以指定循环次数作为波形频率。在门限模式下，当触发信号为高电平时输出波形频率。**Burst** 模式支持正弦波、方波、三角波或斜波。


面板操作

1. 按 **FREQ/Rate** 键



2. **FREQ** 参数变亮

3. 使用方向键和可调旋钮或数字
键盘输入频率



4. 按 F2~F6 选择频率单位



范围	频率	1uHz~30MHz (20MHz AFG-3021/3022)
	频率 – 斜波	1uHz~1MHz
	默认	1kHz

注意 波形频率不同于 Burst 周期。Burst 周期指 N-Cycle 模式下 Burst 之间的时间间隔


Burst 循环/Burst 计数

Burst 循环(Burst 计数)指 Burst 波形的循环次数。仅用于 N Cycle 模式(内部, 外部或手动触发源)。默认 1 次循环。


面板操作

- 1. 按 Burst 键
- 2. 按 F1 (N Cycle)
- 3. 按 F1 (Cycles)
- 4. Cycles 参数变亮





5. 使用方向键和可调旋钮或数字
键盘输入循环次数



6. 按 F5 选择 Cyc 单位



范围	循环次数	1~1,000,000
----	------	-------------

注意 选择内部触发时，持续输出 Burst 循环。Burst 周期
决定 Burst 频率和它们之间的时间间隔

Burst 计数必须小于脉冲串周期和波形频率的乘积。

$$\text{Burst Cycle} < (\text{Burst Period} \times \text{Wave Frequency})$$

如果选择门限 Burst 模式，将忽略 Burst 计数。如果在门限模式同时远程改变 Burst 计数，信号发生器将记录新计数，并在下次使用。

无限 Burst 计数

面板操作

1. 按 Burst 键



2. 按 F1 (N Cycle)




3. 按 F2 (Infinite)



注意

无限 Burst 仅用在手动触发模式

25MHz 以上, 无限 Burst 仅适合方波和正弦波



Burst 周期

两个相邻 Burst 起始时间之间的间隔称为 Burst 周期。仅用于内部触发 Burst 模式。

面板操作

1. 按 Burst 键




2. 按 F1 (N Cycle)




3. 按 F4 (Period)



4. Period 参数变亮



5. 使用方向键和可调旋钮或数字键盘输入周期时间



6. 按 F1~F3 选择周期单位



范围

周期

1us~500s

默认

10ms

注意

Burst 周期仅用于内部触发。当使用门限 Burst 模式或外部和手动触发时，关闭 Burst 周期设置

Burst 周期一定要够长，且满足如下条件：

Burst 周期 > Burst 计数/波形频率 + 200ns

Burst 相位

Burst 波形的起始相位称为 Burst 相位，默认 0°。

面板操作

1. 按 Burst 键




2. 按 F1 (N Cycle)




3. 按 F3 (Phase)



4. Phase 参数变亮



5. 使用方向键和可调旋钮或数字
键盘输入相位



6. 按 F5 (Degree)选择相位单位



范围	相位	-360°~+360°
	默认	0°

注意 当使用正弦波、方波、三角波或斜波时，0°点与波形 0V 点一致

0°是波形的起始点。对于正弦波、方波或三角波、斜波，0°对应 0V 电压(假设没有 DC 偏置)

Burst 相位用于 N cycle 和门限 Burst 模式。在门限 Burst 模式下，当 TriggerINPUT 信号下降到低电平时，信号发生器完成当前波形后停止输出。电压输出电平仍与起始 Burst 相位对应的电压值相同。

在 Burst 模式下使用方波，第一个和最后一个周期的占空比由于频率响应的原因，在指定相位设置下可能有一些误差。

Burst 触发源

触发 Burst (N-Cycle)模式下，信号发生器每收到一个触发输出一个波形 Burst。Burst 循环(Burst 计数)指定每个 Burst 的波形数。输出完成后，信号发生器停止并等待下一次触发。默认启用内部触发的 Burst(N-cycle)模式。

面板操作

1. 按 Burst 键



2. 按 F1 (N Cycle)



3. 按 F5 (TRIG setup)




4. 按 F1(INT)、F2(EXT)或 F3(Manual)选择触发类型



手动触发

5. 如果选择手动触发，每按一次触发软键(F1)输出一个 Burst



注意

选择内部触发源时，Burst 以指定频率持续输出。
Burst 周期决定 Burst 之间的时间间隔

选择外部触发时，信号发生器后面板 Trigger INPUT 端每收到一个触发信号(TTL)，输出一个 Burst(循环数已设)。输出 Burst 期间接收到的触发信号将被忽略

当使用手动或外部触发，仅可用 Burst 相位和 Burst 循环/计数，不可用 Burst 周期

在接收触发之后、脉冲串开始之前可以插入延迟时间。

Burst 延迟

面板操作

1. 按 Burst 键



2. 按 F1 (N Cycle)



3. 按 F5 (TRIG setup)




4. 按 F4 (Delay)



5. Delay 参数变亮



6. 使用方向键和可调旋钮或数字键盘输入延迟时间



7. 按 F1~F4 选择延迟时间单位



范围	延迟时间	0s~100s
	默认	0s

门限触发极性

设置输入触发信号的极性。

面板操作

1. 按 Burst 键



2. 按 F2 (Gate)



3. 按 F1 (Polarity)



4. 选择 Pos (F1)或 Neg (F2)



门限触发相位

设置输出 Burst 波形的起始相位。

面板操作

1. 按 Burst 键




2. 按 F2 (Gate)



3. 按 F2 (Phase)



4. 使用方向键和可调旋钮或数字
键盘输入相位



5. 按 F5 (Degree)选择相位单位



范围	相位	-360° ~ +360°
	默认	0°

辅助系统功能设置

辅助系统功能设置包括存储和调取设置、LAN/USB/GPIB 设置、查看软件版本、更新固件、自我校准、设置接口类型、改变语言、设置输出阻抗、设置 DSO 连接以及其它辅助功能。

存储、调取或删除	172
选择远程接口	176
GPIB 接口	176
LAN 接口	177
LANHost 接口	179
USB 接口	181
系统和设置	182
查看和更新软件&固件版本	182
语言选择	183
设置蜂鸣器声音	184
屏幕休眠	185
屏幕亮度	185
参考时钟	186
设置输出阻抗 - AFG-3021/3031	188
DSO 连接 - AFG-3021/3031	189

存储、调取或删除

AFG-3021、AFG-3022、AFG-3031 & AFG-3032 的非易失性存储器可以存储仪器状态和数据。10 组内存文件 0~9，保存任意波数据(ARB)和设置。内存文件中的数据(ARB 或设置数据)以红色字体显示。若没有数据则呈现蓝色。

存储/调取内容	ARB
	• 速率 • 频率 • 长度 • 显示水平位置 • 显示垂直位置 • 输出开始 • 输出长度
	设置
	• 功能 • 波形 • 频率 • 脉冲宽度 • 脉冲上升时间 • 脉冲下降时间 • 方波占空比 • 斜波对称性 • 幅值 • 幅值单位 • DC 偏移(仅 DC 波形) • 偏移 • 调制类型 • 蜂鸣器设置 • 阻抗 • 主输出 • FM • 调制源 • 波形 • 深度 • FM 频率 • FSK • 调制源 • 波形 • 频率 • 跳跃频率 • PM • 调制源 • 相位偏差 • PM 频率 • SUM • 调制源 • 波形

- 谐波阶数设置
- 谐波显示
- 扫描
 - 调制源
 - 类型
 - 时间
 - 起始频率
 - 停止频率
 - 中心频率
 - 跨距频率
 - 起始幅值
 - 停止幅值
- AM
 - 调制源
 - 波形
 - 深度
 - AM 频率
- SUM 幅值
- SUM 频率
- PWM
 - 调制源
 - 波形
 - 占空比
 - 频率
- Burst 类型
 - 调制源
 - 类型
 - 循环数
 - 相位
 - 周期
 - 延迟
- 其它
 - 接口
 - 显示
 - 相位
 - 双通道设置

面板操作



1. 按 UTIL 键



2. 按 F1 (Memory)



3. 使用可调旋钮选择内存文件
(M0 ~ M9)





4. 选择文件操作:

按 F1 存储文件，按 F2 调取文件，按 F3 删除文件




5. 使用可调旋钮选择存储/调取/删除的数据类型
(ARB, Setting, ARB+Setting)





6. 按 F5 (Done)完成操作




范围	内存文件	M0 ~ M9
	数据类型	ARB, Setting, ARB+Setting

全部删除 7. 按 F4 删除 M0~M9 所有文件



8. 按 F1 (Done)确认删除所有文件



选择远程接口

AFG-3021、AFG-3022、AFG-3031 & AFG-3032 提供 LAN、GPIB 和 USB 接口。每次仅可以使用一种远程接口。

GPIB 接口

背景 使用 GPIB 接口必须指定 GPIB 地址。默认 GPIB 接口为 10。

面板操作

1. 按 UTIL 键



2. 按 F2 (Interface)



3. 按 F1 (GPIB)




4. 按 F1 (Address)




5. GPIBAddress 参数变亮



6. 使用方向键和可调旋钮或数字
键盘输入 GPIB 地址



7. 按 F5 (Done)确认 GPIB 地址



范围	GPIB 地址	1~30
----	---------	------

LAN 接口

背景 使用 LAN 接口必须指定 IP(DHCP、Auto IP 或手
动设置)。

面板操作

1. 按 UTIL 键



2. 按 F2 (Interface)



3. 按 F3 (LAN)



4. 按 F2 (Config)



5. 按 F1(DHCP)、F2(Auto IP)或 F3(Manual)选择如何设置 IP 地址



范围

DHCP	使用 DHCP 自动设置仪器网络的 IP 地址
Auto IP	用以太网线直接连到 Host PC 后，使用 Auto IP 自动设置仪器的 IP 地址
Manual	手动设置 IP 地址

6. 如果选择手动，依次设置 F1 (IP Addr)、F2 (NetMask)和 F3 (Gateway)



7. IP address、net mask 或 gateway 参数设置变亮



8. 使用数字键盘输入 IP address、Net mask 或 gateway。小数点作为字段分隔符

789

456

123

0.+/=
9. 按 F5 (Done)确认设置

Done

F5
- 10.最后，按 F5 (Done)设置所有 IP

Done

F5

LANHost 名称

背景介绍使用 LAN 接口时如何设置 Host 名称。

- 面板操作

1. 按 UTIL 键

UTIL
2. 按 F2 (Interface)

Interface

F2
3. 按 F3 (LAN)

LAN

F3
4. 按 F2 (Config)

Config

F2
5. 按 F4 (HostName)设置仪器的 Host 名称


HostName

F4

6. Host Name 参数变亮



7. 使用可调旋钮切换字母



8. 按 F1 (Enter Char)选择字母并移至下一位置



9. 按 F5 (Done)确认 Host 名称



USB 接口

背景 介绍如何设置仪表远程控制。

面板操作

1. 按 UTIL 键



2. 按 F2 (Interface)



3. 按 F2 (USB)



系统和设置

用户也可以设置语言选项、屏幕选项、时钟、软件和固件设置。

注：单通道和双通道的“System”软键位置不同。AFG-3021/3031 的“System”软键对应 F4，AFG-3022/3032 对应 F5。

查看和更新软件&固件版本

面板操作

1. 按 UTIL 键



2. 按 F3 (Cal.)



3. 按 F2 (Software)



查看版本

4. 按 F1 (Version) 查看软件和固件版本



屏幕显示版本信息：

仪器、版本、FPGA 版次、Bootload 版本、序列号

更新软件&固件


5. 将包含软件/固件文件的 U 盘插入 USB host 驱动中，按 F2 (Upgrade) 更新软件&固件



注意

软件/固件使用.bin

(格式：AFG***.bin)



语言选择

背景 AFG-3021、AFG-3022、AFG-3031 和 AFG-3032 支持英语、繁体中文、简体中文。默认英语。

- 面板操作
1. 按 UTIL 键


2. 按 F4 (System) [AFG-3021/3031 按 F5]



3. 按 F1 (Language)



4. Language 参数变亮



5. 选择 F1(简体中文)、F2(英文)
或 F3(繁体中文)



设置蜂鸣器声音

背景

打开或关闭蜂鸣器。

面板操作


1. 按 UTIL 键



2. 按 F4 (System) [AFG-3021/3031 按 F5]



3. 按 F4 (Beep)开启或关闭蜂鸣器



4. Beep 参数变亮



屏幕休眠

背景 屏幕休眠。按任一前面板键，屏幕恢复。

面板操作

1. 按 UTIL 键


2. 按 F4 (System)[AFG-3021/3031 按 F5]



3. 按 F2 (Display Opt)



4. 按 F1 (Display)



5. 选择 F1(Suspend)或 F2(ON)
开启或关闭屏幕休眠


 ~ 


屏幕亮度

背景 Utility 系统菜单设置屏幕亮度。

面板操作

1. 按 UTIL 键


2. 按 F4 (System)[AFG-3021/3031 按 F5]




3. 按 F2 (Display Opt)



4. 按 F2 (Brightness)




使用可调旋钮设置屏幕亮度



范围	亮度	1(暗) ~ 10 (亮)
----	----	---------------

5. 按 F1 (Enter)完成设置





参考时钟

背景 外部 10MHz 参考信号可替代内部 10MHz 时钟信号。外部参考时钟用于增加时钟信号的精度或稳定性，也可使不同仪器同步工作在一个时钟下。详情见 200 页多台同步操作。

参考输入与机壳接地隔离，隔离电压 42Vpk。避免接地回路和其它相关干扰。

REF OUT 端提供一个内部参考时钟的同步信号，也可以同步其它设备。详情见 200 页多台同步操作。

连接



10MHz 参考输出	内容	规格
规格	输出电压	1Vp-p/50Ω 方波
	输出阻抗	50Ω, AC 耦合
	输出频率	10MHz

10MHz 参考输入	内容	规格
规格	输入电压	0.5Vp-p ~ 5Vp-p
	输入阻抗	1kΩ, 不平衡, AC 耦合
	最大允许输入	± 10Vdc
	输入频率	10MHz ±10Hz
	波形	正弦波或方波(50±5% 占空比)
	接地绝缘	42Vpk max

面板操作

1. 按 UTIL 键



2. 按 F4 (System)[AFG-3021/3031 按 F5]



3. 按 F3 (Clk Source)



4. 选择 F1(INT)或 F2(EXT)时钟



范围

INT

设置内部时钟为参考时钟

EXT

设置外部 10MHz 信号为参考时钟

5. 如果选择 F2(EXT)作为时钟，
按 F3(EXT Sync)将仪器与外部
参考信号同步



设置输出阻抗 - AFG-3021/3031

背景

AFG-3021/3031 的输出阻抗可选：50Ω(默认)或 High-Z。输出阻抗仅供参考。如果与实际负载阻抗不同，那么实际幅值和偏移也将相应改变。

注意

介绍如何设置 AFG-3021 和 AFG-3031 的输出阻抗。如何设置 AFG-3022 或 AFG-3032 的输出阻抗见 193 页。

面板操作

1. 按 CH1 或 CH2 键



2. 按 F4 (Load)



3. 选择 F1 (50 OHM)或 F2 (High Z)




DSO 连接 -AFG-3021/3031

背景 DSO 连接使 AFG-3021/3031 和 GDS-2000 系列数字存储示波器之间进行无损数据传输。

注意 所有型号均支持 DSO 连接功能。但是单双通道机型的菜单树操作不同。此处操作仅适合 AFG-3021/3031。AFG-3022 和 AFG-3032 连接见 194 页。

- 面板操作
1. 将 AFG-3021/3031 的 USB host 接口连接 GDS-2000 的 USB B device 接口


2. 按 CH1 或 CH2 键


3. 按 F6 (DSOLink)



4. 按 F1 (Search)


5. 按 F1 (CH1)、F3(CH2)、F4(CH3)或 F5(CH4)选择 DSO 通道。然后屏幕显示获取的数据



6. 片刻后 AFG-3021/3031 将自动切换至 ARB 功能，并描绘出 DSO 保存的波形

见 ARB 章节编辑或保存合成波形



双通道&多台操作

双通道章节介绍如何在双通道模式下操作仪器(仅 AFG-3022 & AFG-3032)，以及如何设置任一指定通道。多台操作章节介绍如何以主-从设置同步多台仪器。

双通道设置	192
通道相位设置	192
设置输出阻抗	193
DSO 连接	194
频率耦合	195
幅值耦合	197
通道追踪	198
多台同步	200
多台连接	200
多台设置	201

双通道设置

AFG-3022 和 AFG-3032 具有一些特殊的设置，如通道追踪、DSO 连接、输出阻抗设置和通道相位设置。

通道相位设置

背景	可以将一个通道的起始相位设成如下 4 种预设相位：	
	0 Phase	快速设置 0° 相位
	Sync Int	同步两个通道的相位，并将相位设为 0°
	Degree	设置所选通道的相位
	Align Phase	对准两个通道的时基，但并不改变通道的相位偏差。换句话说，它重新校准两通道之间的相位差

面板操作

1. 按 CH1 或 CH2 键



2. 按 F5 (Phase)




3. 按 F1 (0 Phase)、F2(Sync Int)、F4(Degree)或 F5(Align Phase)选择通道相位









4. 如果选择 Degree，使用方向键和可调旋钮或数字键盘输入相位










5. 再按 F5 (Degree)设置相位单位



范围 度数 -180 °~180° (设置所选通道的相位)



设置输出阻抗

背景 AFG-3022/AFG-3032 每个通道可选输出阻抗：50Ω或高阻。默认 50Ω。输出阻抗仅供参考。如果与实际负载阻抗不同，那么实际幅值和偏移也将相应改变。

注意 如下介绍如何设置 AFG-3022 和 3032 的输出阻抗。AFG-3021/3031 的输出阻抗设置见 188 页

面板操作

1. 按 CH1 或 CH2 键



2. 按 F1 (Load)



3. 选择 F1 (50 OHM)或 F2 (High Z)




DSO 连接

背景 DSO 连接使 AFG-3022/3032 和 GDS-2000 系列数字存储示波器之间进行无损数据传输。

注意 所有型号均支持 DSO 连接功能。但是单双通道机型的菜单树操作不同。此处操作仅适合 AFG-3022 和 AFG-3032。AFG-3021/3031 连接见 189 页

面板操作

1. 将 AFG-3022/3032 的 USB host 接口连接 GDS-2000 的 USB B device 接口



2. 按 CH1 或 CH2 键



3. 按 F6 (DSOLink)



4. 按 F1 (Search)




5. 按 F1 (CH1)、F3(CH2)、F4(CH3)或 F5(CH4)选择 DSO 通道。然后屏幕显示获取的数据



6. 片刻后 AFG-30XX 将自动切换至 ARB 功能，并描绘出 DSO 保存的波形

见 ARB 章节编辑或保存合成波形



频率耦合

背景 频率耦合：以所选通道的频偏或频率比值来表示未选通道的频率。


面板操作

1. 按 UTIL 键 
2. 按 F5 (Dual Ch) 

3. 按 F1 (Freq Cpl) 

4. 按 F2 (Offset)，以所选通道的频偏来表示未选通道的频率 


使用方向键和可调旋钮或数字键盘输入频偏




按 F2~F6 选择频偏单位



5. 按 F3 (Ratio), 以所选通道的频率比值来表示未选通道的频率



使用方向键和可调旋钮或数字键盘输入比值



按 F5 (Enter) 确认



6. 或按 F1 (OFF) 关闭频率耦合



范围	频偏范围	-30MHz ~ 30MHz (-20MHz ~ 20MHz)
	频偏分辨率	1uHz. 未选通道频率 = 所选通道频率 + 偏移， 所选通道的频率为固定值
	比值范围	1000.000 ~ 0.001
	比值分辨率	0.001. 比值 =未选通道频 率/所选通道频率，所选 通道的频率为固定值

幅值耦合

背景 两个通道的幅值耦合。当一个通道的幅值设置发生
改变，同样的设置将自动影响另一通道。

- 面板操作

1. 按 UTIL 键


2. 按 F5 (Dual Ch)




3. 按 F2 (Ampl Cpl)




4. 按 F1 开启幅值耦合或 F2 关闭幅值耦合














通道追踪

背景

通道追踪：一个通道的波形输出保持与另一通道设置一致。当该通道的设置发生改变，这些改变将反应到另一通道。该功能也可以完成反向追踪，即该通道的输出与另一通道正好相反。

面板操作

1. 按 UTIL 键



2. 按 F5 (Dual Ch)



3. 按 F3 (Tracking)



4. 按 F1 (OFF)、F2 (ON)或 F3(Inverted)选择追踪功能





多台同步

多台仪器与时钟同步，时钟信号可以是外部参考信号或来自主控 AFG-30XX 的内部参考输出。


多台连接

背景

虽然不同的连接方式均可以完成多台同步操作，但所选方式决定了同步的仪器数量和同步时钟的传播时间。下面详细介绍两种连接方式：

菊花链

菊花链方式最多可以同步 4 台仪器。BNC 线连接主控机的 REF OUT 端和从属机#1 的 REF IN 端。从从属机#1 的 REF OUT 端连接从属机#2 的 REF IN 端。同理直至接到从属机#3




注：菊花链方式的最大相位延迟为：

$$\text{最大相位延迟(ns)} = 39 + (N-2) \times 39 \pm 25\text{nS}$$

其中 N 为总连接台数，最多 4 台

并联连接


并联方式：BNC 线连接主控机的 REF OUT 端和 T-divider。T-divider 然后连接从属机#1 的 REF IN 端和第二个 T-divider。同理直至最后一个从属机。最后一个从属机的 REF IN 端接 50Ω。此方式最多可连接 6 台



注：并联方式的最大相位延迟为:

最大相位延迟(ns) = (N-1)*6 ±25nS

其中 N 为总连接台数，最多 6 台



注意

如果主控机使用外部参考信号，将外部参考信号接至后面板 REF IN 端

10MHz 参考输入规格:

输入电压	0.5Vp-p~5Vp-p
输入阻抗	1kΩ, 不平衡, AC 耦合
最大允许输入	± 10Vdc
输入频率	10MHz ±10Hz
波形	正弦波或方波(50± 5%占空比)
	10MHz, 幅值 0.5Vpp~5Vpp

多台设置

背景

设置相连的主控机和从属机，详情见 186 页。



 注意

使用外部参考功能时，不支持 ARB 和双通道功能。

详情见 186 页参考时钟章节

面板操作

1. 按 UTIL 键



2. 按 F4 (System)



3. 按 F3 (Clk Source)



4. 设置主控机:

内部信号，按 F1 (INT)



外部信号, 按 F2 (EXT)



按 F3 (EXT Sync), 外部信号
开始同步主机



5. 设置从属机:

每台从属机按 F2 (EXT)*。从属机接收来自主控机的参考信号



每台从属机按 F3 (EXT Sync)

EXT Sync

F3

*返回独立操作

6. Clk Source 设为 F1 (INT), 从属机回到独立操作

INT

F1



任意波

AFG-30XX 系列能够创建自定义的任意波形。每个波形最多包含 8M 数据点。每个数据点垂直范围在 65535 (± 32767) 以内，采样率 250MSa/s。

插入内置波形	206
插入内置波形	206
插入 DC 波形	209
插入脉冲波形	211
显示任意波形	214
设置水平显示范围	214
设置垂直显示范围	215
页面浏览(下页)	218
页面浏览(上页)	219
显示整个波形	221
编辑任意波形	222
增加一个点	222
增加一条线	223
复制波形	225
清除波形	227
ARB 保护	229
输出任意波形	232
输出任意波形	232
任意波形的门限输出	233
输出 N 次循环的任意波形	235
输出任意波形 – 无限循环	237

存储/调取任意波形 239

 将波形保存至内存239

 将波形保存至 U 盘240

 从内存调取波形243

 从 U 盘调取波形246

插入内置波形

AFG-30XX 系列信号发生器可以创建一些常见波形，包括正弦波、方波、斜波、 $\sin(x)/x$ 、指数上升、指数下降、脉冲波和 DC 波形。总计 65 种内置波形。波形图示见 469 页。

插入内置波形

可按照如下步骤插入除 DC 和脉冲波以外的任何内置 ARB 波形。插入 DC 或脉冲波见 209 页&211 页。

面板操作

1. 按 ARB 键



2. 按 F3(Built in)



3. 按 F1~F5 选择内置波形



Basic

Sine, Square, Ramp, $\sin(x)/x$,
Exponential Rise, Exponential
Fall, Pulse, DC

Common 1

Absatan, Haversine,
Sinever, Absin, Haversine,
Stair_down, Absinehalf,
N_pulse, Stair_UD, Ampalt,
Negramp, Stair_up

Common 2	Attalt, Rectpuls1, Stepresp, Diric_even, Roundhalf, Trapezia, Diric_odd, Sawtoot, Tripuls1, Gauspuls1, Sinetra
Math	Dlorentz, In, Sqrt, Since, Lorentz, Xsquare, Gauss, Since
Trigonometric	Arccos, Arctan, Sech, Arccot, Arctanh, Sinh, Arccsc, Cosh, Tan, Arcsec, Cot, Tanh, Arcsin, Csc, Arcsinh, Sec
Window	Barthannwin, Chebwin, Kaiser, Bartlett, Flattopwin, Triang, Blackman, Hamming, Tukeywin, Bohmanwin, Hann

4. 所选内置波形以红色显示。其余 ARB 波形显示绿色

5. 按 F1(Start)



6. Start 参数变亮



7. 使用方向键和可调旋钮或数字
键盘输入波形的起始地址

789

456

123

0.%

8. 按 F5 (Enter)确认起始点

Enter

F 5

9. 重复 Step 5~8，设置 Length
(F2)和 Scale (F3)

Length

F 2

~

Scale

F 3

• Length 表示 x 方向拉伸多少个波形点

• Scale 表示以中心线为基准，波形的垂直刻度

范围	项	设置范围
	Start	0 ~ 8388606
	Length	2 ~ 8388608
	Scale	1 ~ 32767

10. 按 F4 (Done)完成操作

Done


F 4

11. 按 F6 (Return)返回上级菜单

Return

F 6

例如创建一个正弦波，start: 0, Length: 40,
Scale: 32767



插入 DC 波形

面板操作

1. 按 ARB 键



2. 按 F3 (Built in)



3. 按 F1(Basic)



4. 按 F5 (More)



5. 按 F3 (DC)




6. 按 F1 (Start)



7. Start 参数变亮



8. 使用方向键和可调旋钮或数字
键盘输入 DC 波形的起始地址



9. 按 F5 (Enter)确认起始点




10. 重复 Step 4~9，设置 Length
(F2)和 Data (F3)



- Length 表示 x 方向拉伸多少个 DC 波形点
- Data 表示以零电平为基准，DC 波形的垂直
准位

范围	项	设置范围
	Start	0 ~ 8388606
	Length	2 ~ 8388608
	Data	-32767 ~ 32767


11. 按 F5 (Done)完成操作



12. 按 F6 (Return)返回上级菜单



例如创建一个 DC 波形，start: 0，Length:
524288，Data: 10000



插入脉冲波形

按照如下步骤插入脉冲波形。

范围	频率	分辨率	占空比分辨率
	1pHz~5Hz	1pHz	0.0001%
	>5Hz~50Hz	1uHz	0.0001%
	>50Hz~500Hz	10uHz	0.001%
	>500Hz~5kHz	100uHz	0.01%
	>5kHz~50kHz	1mHz	0.1%
	>50kHz~500kHz10mHz		1%

面板操作

1. 按 ARB 键



2. 按 F3 (Built in)



3. 按 F1(Basic)



4. 按 F5 (More)



5. 按 F4 (Pulse)




6. 按 F1 (Frequency)



7. Pulse Freq 参数变亮




8. 使用方向键和可调旋钮或数字键盘输入脉冲频率



9. 按 F1~F5 选择频率单位




10. 按 F2 (DUTY), 使用数字键盘或可调旋钮选择占空比



11. 按 F5 (%)选择单位



12. 按 F5 (Done)完成操作



13. 按 F6 (Return)返回上级菜单



例如创建一个脉冲波形，100kHz 频率， 占空比 50%



显示任意波形

设置水平显示范围

两种方式设置水平显示范围：使用起始点和长度或使用中心点和长度。

面板操作

1. 按 ARB 键



2. 按 F1 (Display) 进入显示菜单



3. 按 F1 (Horizon) 进入水平菜单



设置视窗边界

Length 设置决定显示视窗宽度。Horizontal Start 参数设置显示视窗的起始位置。Center 参数设置视窗中心点

4. 按(F2) Length




5. Length 参数变亮



6. 使用方向键和可调旋钮或数字键盘输入 Length 值

- F4 (clear) 取消数值



7. 按 F5 (Enter)保存设置



设置起始点或中心点 8. 重复 Step 4~8，设置 Start (F1)或 Center F3



- Start 软键用于编辑水平参数

Zoom in

9. 按 F4 (Zoom In)放大任意波形。每按一次长度减小一半。最小允许长度 3




Zoom out

10. 按 F5 (Zoom out)沿波形中心点缩小任意波形。每按一次长度增加一倍。最大允许长度 8388608



例如任意正弦波，start0，length40，center20



设置垂直显示范围

与水平窗口类似，两种方式设置垂直显示范围：设置上下限或设置中心点。

面板操作

1. 按 ARB 键



2. 按 F1 (Display)



3. 按 F2(Vertical)



设置下限

4. 按 F1 (Low)




5. Vertical Low 参数变亮



6. 使用方向键和可调旋钮或数字键盘输入垂直下限

- F4 (clear)取消数值



7. 按 F5 (Enter)保存设置



设置上限

8. 重复 Step 4~8, 设置 High (F2)



设置中心点

9. 如果需要, 重复 Step 4~8, 设置 Center (F3)



Zoom

10. 按 F4 (Zoom In)沿波形中心放大任意波。每按一次幅值减小一半。最小允许垂直下限-2，最小垂直上限 2
11. 按 F5 (Zoom out)垂直缩小波形。每按一次幅值增加一倍。最大允许垂直下限-32767，最大垂直上限+32767



例如正弦波，垂直下限-16384，垂直上限 16384，center0。注：由于垂直显示边界限制，正弦波部分剪除



页面浏览(下页)

背景 观察波形时，使用 Next/Back Page 功能前/后移动显示窗口。

面板操作

1. 按 ARB 键



2. 按 F1 (Display)



3. 按 F3 (Next Page)向后移动一个观察长度



$\text{New Horizon From} = \text{Horizon From} + \text{Length}$

$\text{New Center} = \text{Center} + \text{Length}$

$\text{*Horizon From} + \text{Length} \leq 8388608$

按 Next Page 后，屏幕显示如下：

Horizon From: 0 → 45

Length: 45

Center: 22 → 67



页面浏览(上页)

背景 观察波形时，使用 Next/Back Page 功能前/后移动显示窗口。

- 面板操作
1. 按 ARB 键 
 2. 按 F1 (Display) 

 3. 按 F4 (Back Page)向前移动一个观察长度 



$\text{New Horizon From}^* = \text{Horizon From} - \text{Length}$
 $\text{New Center}^* = \text{Center} - \text{Length}$
*Length until 0

按 Back Page 后，屏幕显示如下：

Horizon From: 45 → 0

Length: 45

Center: 67 → 22



显示整个波形

面板操作

1. 按 ARB 键



2. 按 F1 (Display)



3. 按 F5 (Overview)显示整个波形



水平：0~8388607

垂直：32767~ -328767


按 Overview 后，屏幕显示如下：

Horizon From: 0

Length: 8388608

Center: 4194304

Vertical low/high: ± 32767



编辑任意波形

增加一个点

背景 AFG-30XX 提供强大的编辑功能，用户可以在波形的任何位置创建点或线。

面板操作

1. 按 ARB 键



2. 按 F2 (Edit)



3. 按 F1 (Point)




4. 按 F1 (Address)



5. Address 参数变亮



6. 使用方向键和可调旋钮或数字键盘输入地址



7. 按 F5 (Enter)保存设置




8. 按 F2 (Data)



9. Data 参数变亮

10. 使用方向键和可调旋钮或数字
键盘输入数值




11. 按 F5 (Enter)保存参数



12. 按 F6 (Return)返回 ARB 菜单



如下图 Address8，Data0。编辑区域显示红色



增加一条线

背景

AFG-30XX 提供强大的编辑功能，用户可以在波形的任何位置创建点或线。

面板操作

1. 按 ARB 键



2. 按 F2 (Edit)



3. 按 F2 (Line)




4. 按 F1 (Start ADD)



5. Start Address 参数变亮



6. 使用方向键和可调旋钮或数字键盘输入起始地址



7. 按 F5 (Enter)保存设置



8. 重复 Step 4~7, 设置 Start Data (F2)、Stop Address (F3)和 Stop Data (F4)

9. 按 F5 (Done)确认编辑



10. 按 F6 (Return) 返回上级菜单



创建一条红线，参数如下：

Start Address: 8, Start Data: 0

Stop Address: 15, Stop Data: 0




复制波形

面板操作

1. 按 ARB 键



2. 按 F2 (Edit)



3. 按 F3 (Copy)




4. 按 F1 (Start)



5. Copy From 参数变亮



6. 使用方向键和可调旋钮或数字键盘输入复制的波形地址



7. 按 F5 (Enter)保存设置



8. 重复 Step 4~7, 设置 Length (F2)和 Paste To (F3)

9. 按 F5 (Done)确认



10. 按 F6 (Return)返回上级菜单



点 30~45 的波形部分复制到点 0~15:

Copy From: 30

Length: 15

To: 0



清除波形

面板操作

1. 按 ARB 键



2. 按 F2 (Edit)



3. 按 F4 (Clear)




4. 按 F1 (Start)



5. Clear From 参数变亮



6. 使用方向键和可调旋钮或数字
键盘输入需清除的波形地址



7. 按 F5 (Enter)保存设置



8. 重复 Step 4~8, 设置 Length (F2)



9. 按 F3 (Done)清除部分任意波形



10. 按 F6 (Return)返回上级菜单



全部删除

11. 按 F5 (ALL)删除全部波形



12. 再按 F5 (Done)确认删除



13. 按 F6 (Return)返回上级菜单




从 0 清除, 长度 15



删除该部分后:



删除整个波形后：



ARB 保护

保护任意波形的某个区域不被改变。

面板操作

1. 按 ARB 键



2. 按 F2 (Edit)




3. 按 F5 (Protect)




4. 按 F2 (Start)



5. Protect Start 参数变亮



6. 使用方向键和可调旋钮或数字键盘输入保护的起始地址



7. 按 F5 (Enter)保存设置



8. 重复 Step 4~8, 设置 Length (F3)



9. 按 F5 (Done)确认保护区域



10. 保护区域显示橙色

全部保护

11. 按 F1 (ALL)保护整个波形



12. 按 F6 (Done)确认



撤销全部保护

13. 按 F5 (Unprotect)解除整个波形的保护



14. 按 F6 (Done)确认



15. 波形背景变回黑色。“Protect Off”参数呈灰色

波形保护区背景呈橘色，如图：

Protect Start:0, Length: 15.



输出任意波形

信号发生器最多可输出 8Mpts (0~8388607)的任意波形，可以指定循环次数也可以无限次循环。

输出任意长度的波形

面板操作

1. 按 ARB 键



2. 按 F6 (Output)




3. 按 F1 (Start)



4. Start 参数变亮



5. 使用方向键和可调旋钮或数字键盘输入起始地址




6. 按 F5 (Enter)确认起始点



7. 重复 Step 4~7, 设置 Length (F2)



前面板端子输出 0~1024 长度的波形，如图：



任意波形的门限输出

背景 当设为门限触发时，使用后面板触发输入可以输出 ARB 波形。门限触发可在正或负触发准位输出任意波形。

- 面板操作
1. 按 ARB 键


2. 按 F6 (Output)



3. 定义任意波输出的 Start 和 Length

见 232 页

注：改变 length 将改变脉冲波的占空比/频率

4. 按 F3 (Gate)





5. 选择正或负触发极性



- 选择门限模式时，禁用任何之前的触发输出
- 选择不同的输出模式均可关闭门限模式，如 Ncycle 或 Infinite

门限触发

6. 在后面板 TRIG 输入端接收高或低 TTL 准位输入之后，将输出 ARB 波形




注：在输入一个信号到触发输入端之前，请确认按下 Output 键，且 OUTPUT 指示灯变亮

7. 按 F6 (Return)返回上级菜单



触发设为 Gate Pos，如图：



输出 N 次循环的任意波形

背景 以指定循环次数重复输出任意波形。N Cycle 功能使用手动触发或外部触发。

范围 1~8388607 次循环

- 面板操作
1. 按 ARB 键


2. 按 F6 (Output)



3. 定义任意波形输出的 Start 和 Length

见 232 页

注：改变 length 将改变脉冲波的占空比/频率

4. 按 F4 (N Cycle)




5. 按 F1 (Cycles)



6. Cycles 参数变亮



7. 使用方向键和可调旋钮或数字键盘输入循环次数



8. 按 F5 (Enter)确认循环次数



手动触发

9. 按 Manual (F4)设置手动触发



10. 按 Trigger (F5)内部触发一次输出



注：在按 F5 (Trigger)之前，请确认按下 Output 键，且 OUTPUT 指示灯变亮

11. 按 F6 (Return)返回上级菜单




外部触发

12. 按 EXT (F3)，使用后面板 TRIG 输入端接收的外部信号触发



13. 信号发生器接收后面板触发输入端的触发信号(TTL)。每收到一个触发信号，信号发生器就输出一个脉冲串(循环数已设)




注：在输入一个信号到触发输入端之前，请确认按下 Output 键，且 OUTPUT 指示灯变亮

14. 按 F6 (Return) 返回上级菜单



前面板端输出 3 次循环波形，如图：



输出任意波形 – 无限循环

背景 无限次重复输出任意波形。

面板操作

1. 按 ARB 键



2. 按 F6 (Output)



3. 定义任意波输出的 Start 和 Length

见 232 页

注：改变 length 将改变脉冲波的占空比/频率

4. 按 F5 (Infinite) 无限次输出任意波形




注：按 Output 键输出 ARB 波形

5. 按 F6 (Return)返回上级菜单

Return

F 6

前面板端输出无限次循环波形，如图：



存储/调取任意波形

AFG-30XX 系列信号发生器可以创建一些常见波形，包括正弦波、方波、斜波、sinc、指数上升、指数下降和 DC 波形。

将波形保存至内存

面板操作

1. 按 ARB 键



2. 按 F4 (Save)




3. 按 F1 (Start)



4. Start 参数变亮

5. 使用方向键和可调旋钮或数字键盘输入起始地址



6. 按 F5 (Enter)确认起始点



7. 重复 Step 4~6，设置 Length (F2)




8. 按 F3 (Memory)



9. 使用可调旋钮选择内存

ARB0~ARB9




10. 按 F1 (Select)将波形保存至所选文件



11. 按 F6 (Return)返回上级菜单



使用可调旋钮选择文件 ARB1，如图：



将文件保存至 U 盘

面板操作

1. 按 ARB 键



2. 按 F4 (Save)




3. 按 F1 (Start)



4. Start 参数变亮

5. 使用方向键和可调旋钮或数字键盘输入起始地址



6. 按 F5 (Enter)确认起始点




7. 重复 Step 4~6, 设置 Length (F2)



8. 按 F4 (USB)



9. 使用可调旋钮浏览文件系统



10. 按 Select 选择目录或文件名




创建文件夹


11. 按 F2 (New Folder)



12. 文件编辑器显示默认文件夹名 "NEW_FOL"



13. 使用可调旋钮移动光标



14. 使用 F1 (Enter Char)或 F2 (Backspace)创建文件夹名称



15. 按 F5 (Save)保存文件夹名称




创建新文件


16. 按 F3 (New File)



17. 文件编辑器显示默认文件名“NEW_FIL”



18. 使用可调旋钮移动光标




19. 使用 F1 (Enter Char)或 F2 (Backspace)创建文件名



20. 按 F5 (Save)保存文件名



在根目录下创建文件夹“ABC”和文件 AFG.CSV，如图：



从内存调取波形

面板操作

1. 按 ARB 键



2. 按 F5 (Load)



3. 按 F1 (To)选择需调取的波形
起始点


- 默认 0



4. Load To 参数变亮



5. 使用方向键和可调旋钮或数字
键盘输入起始点




6. 按 F5 (Enter)确认起始点



7. 按 F3 (Memory)



8. 使用可调旋钮浏览文件系统




9. 按 Select 选择目录或文件名



立即调取 ARB 波形

使用可调旋钮选择文件 ARB1，调取位置 0，如图：



从 U 盘调取波形

面板操作

1. 按 ARB 键



2. 按 F5 (Load)



3. 按 F1 (To)选择需调取的波形起始点




- 默认 0

4. Load To 参数变亮



5. 使用方向键和可调旋钮或数字键盘输入起始点




6. 按 F5 (Enter)确认起始点



7. 按 F4 (USB)



8. 使用可调旋钮选择文件名




9. 按 F1 (Select)选择需调取的文件



立即调取 ARB 文件

使用可调旋钮选择文件 AFG.CSV，调取位置 0，如图：



远程接口

建立远程连接	249
浏览器控制接口	256
指令语法	259
指令列表	265
488.2 常见指令	273
状态寄存器指令	276
系统指令	283
应用指令	286
输出指令	295
脉冲设置指令	306
谐波指令	310
幅值调制 (AM) 指令	315
AM 介绍	315
频率调制 (FM) 指令	321
FM 介绍	321
频移键控 (FSK) 指令	328
FSK 介绍	328
相位调制 (PM) 指令	332

PM 介绍	332
SUM 指令	337
SUM 介绍	337
脉冲宽度调制(PWM) 指令	343
PWM 介绍	343
频率扫描指令	349
扫描介绍	349
Burst 模式指令	363
Burst 模式介绍	363
任意波形指令	376
任意波形介绍	376
追踪指令	428
参考指令	433
存储和调取指令	435
错误信息	438
SCPI 状态寄存器	452

建立远程连接

AFG-3021、AFG-3022、AFG-3031 和 AFG-3032 支持 USB、LAN 和 GPIB 远程连接。

设置 USB 接口

USB 设置

PC 接口

Type A, host

AFG-30XX 接口 Type B, slave

速度 1.1/2.0 (full speed)

面板操作

1. 从 GW Instek 网站下载和安装 USB 驱动
www.gwinstek.com。进入产品>信号发生器>任意波形信号发生器>AFG-30XX 页面找到 USB 驱动设置文件

双击驱动文件，根据安装说明安装驱动

2. 按 Utility 键、Interface (F2)和 USB (F2)




3. USB 线连接后面板 USB B (slave)接口



设置 GPIB 接口

GPIB 设置	接口	24 pin Female
	GPIB 地址	1-30
GPIB 限制	• 最多连接 15 台设备，电缆总长不超过 20m，每台设备间距 2m	
	• 每台设备具有独立地址	
	• 至少启动 2/3 的设备	
	• 不允许环状或并联连接	


引脚分配



Pin1	Data line 1	Pin13	Data line 5
Pin2	Data line 2	Pin14	Data line 6
Pin3	Data line 3	Pin15	Data line 7
Pin4	Data line 4	Pin16	Data line 8
Pin5	EOI	Pin17	REN
Pin6	DAV	Pin18	Ground
Pin7	NRFD	Pin19	Ground
Pin8	NDAC	Pin20	Ground
Pin9	IFC	Pin21	Ground
Pin10	SRQ	Pin22	Ground
Pin11	ATN	Pin23	Ground
Pin12	Shield (screen)	Pin24	Signal ground

面板操作

1. 将 GPIB 线连接后面板 GPIB 接口



2. 按 Utility 键、Interface (F2)和 GPIB(F1)。按 Address (F1)

UTIL

Interface

GPIB

Address
3. 使用可调旋钮或数字键盘选择一个地址

7

8

9

4

5

6

1

2

3

0

.

%
4. 按 Done (F5)确认

Done

设置 LAN 接口

LAN 设置	MAC 地址	域名
	仪器名称	DNS IP 地址
	用户密码	网关 IP 地址
	仪器 IP 地址	子网掩码
	HTTP Port 80 (固定)	

- 面板操作

1. 将 LAN 线连接后面板 LAN 接口

LAN
2. 按 Utility 键、Interface (F2)和 LAN (F3)

UTIL

Interface

LAN

- DHCP 连接

对于使用 DHCP 服务器的网络，DHCP 自动设置 IP 地址
3. 按 Config (F2)、DHCP (F1)、Done(F5)。再按 Done(F5)

Config

DHCP

Done

Done

自动 IP 连接 当以太网线直接连接 Host PC 时，使用 Auto IP 自动设置 IP 地址

4. 按 Config (F2)、Auto IP (F2)、Done(F5)。再按 Done(F5)
- Config

AutoIP

Done

Done

手动 IP 连接 手动设置 IP 地址

5. 按 Config (F2)、Manual (F3)
- Config

Manual
6. 按 IP Addr (F1)，使用数字键盘设置 IP 地址。按 Done (F1) 完成设置 IP 地址
- IP Addr

Done
7. 按 NetMask (F2)，使用数字键盘设置 Mask 地址。按 Done (F1)完成设置
- Net Mask

Done
8. 按 Gateway (F3)，使用数字键盘设置网关地址。按 Done (F1)完成设置
- Gateway


Done
9. 按 Done (F5)设置手动 IP 地址，并返回 LAN 接口菜单。再按 Done(F5)
- Done

Done

设置 Host 名 10.按 Host Name (F4)

Host Name

11. 使用可调旋钮、方向键和软键输入 Host 名。可调旋钮点亮字符，按 Enter Char (F1)选择字符




12. 按 Done (F5)完成设置。再按 Done(F5)



远程控制端口连接实例

AFG 设置	设置 USB 接口(见 249 页)，将 AFG 与 PC 相连。
终端应用	调用终端应用，如 MTTY (Multi-Threaded TTY)。根据 AFG-30XX 的 COM 分配，设置 COM 口。 检测 COM 端口号，见 PC 的设备管理器。对于 WinXP，进入 Control panel → System → Hardware tab。
功能检测	在终端输入查询指令： *idn? 返回制造商、型号、序列号和固件版本，格式如下： GW INSTEK,AFG-3032,SN:XXXXXXXX,Vm.mm
显示	远程连接确立后，除 F6 之外所有面板键均被锁定。 1. 按 REM/LOCK (F6)，信号发生器返回本地模式






浏览器控制接口

AFG-30XX 提供一个远程控制的浏览器页面。

介绍


欢迎页面

欢迎页面为浏览器控制的主页面。该页列出仪器信息和 LAN 设置。它也可以链接到 **Browser Web Control** 和 **View & Modify Configuration** 页面。




Browser Web
Control

浏览器 Web 控制可以通过 LAN 远程控制和查看仪器。由鼠标控制虚拟面板进而达到控制仪器的作用。SCPI 控制通过 SCPI 命令输入或通过 SCPI 命令文件运行。



View & Modify
Configuration

View & Modify Configuration 页面显示所有 LAN 设置和允许编辑的内容



操作

1. 将 AFG-30XX 接口设为 LAN，并与 LAN 相连或直接与 PC 相连(如果 LAN 接口设为 Auto IP)


详情见 252 页 LAN 设置

2. 下一步开启虚拟界面。按 Utility 键、Interface (F2)、LAN (F3)和 Remote (F1)，开启/关闭虚拟界面



Interface: USB	Virtual Interface: Enable
GPIO Address: 10	LAN Boot Mode: AutoIP
CH1 Load: 50 OHM	IP Address: 169.254.206.154
CH2 Load: 50 OHM	NetMask: 255.255.0.0
Language: English	GateWay: 0.0.0.0
Boot: On	Mac Address:

3. 在浏览器的地址栏输入仪器的 IP 地址



4. 浏览器显示欢迎页面

Support | Products | Gwinstek Inc.

Welcome Page

Browser Web Control

View & Modify Configuration

Welcome to your

Web-Enabled AFG-3032
Arbitrary Function Generator

Information about this Web-Enabled Instrument

Instrument:	AFG-3032
Serial Number:	111111111
Description:	GW INSTEK AFG-3032 SN:111111111 V0.130
Hostname:	51F1087D01
Config Type:	AutoIP
IP Address:	169.254.206.154
VISA TCP/IP Connect String:	TCP/IP:169.254.206.154:1026 SOCKET
MAC Address:	00-45-56-76-9A-CD
Software Version:	GW INSTEK AFG-3032 DATE:0901 SCFT-V0.11ED FPGA:0108 Boot V0.18 SN:111111111
Auto-MUX Capable:	Yes

Use the navigation bar on the left to access your AFG-3032 Arbitrary Function Generator and related information.

© GWINSTEK Technologies, Inc. 2011


指令语法

Compatible standard	• IEEE488.2, 1992 (fully compatible) • SCPI, 1994 (partially compatible)
---------------------	--

Command Tree	The SCPI standard is an ASCII based standard that defines the command syntax and structure for programmable instruments.
--------------	--

Commands are based on a hierarchical tree structure. Each command keyword is a node on the command tree with the first keyword as the root node. Each sub node is separated with a colon.

Shown below is a section of the SOURce[1|2] root node and the :PWM and :PULSe sub nodes.



Command types	Commands can be separated in to three distinct types, simple commands, compound commands and queries.
---------------	---

Simple	A single command with/without a parameter
Example	*OPC
Compound	Two or more commands separated by a colon (:) with/without a parameter
Example	SOURce1:PULSe:WIDTH

	Query A query is a simple or compound command followed by a question mark (?). A parameter (data) is returned. The maximum or minimum value for a parameter can also be queried where applicable.
	Example SOURce1:FREQuency? SOURce1:FREQuency? MIN
Command forms	Commands and queries have two different forms, long and short. The command syntax is written with the short form of the command in capitals and the remainder (long form) in lower case. long SOURce1 short long DCOffset short The commands can be written in capitals or lower-case, just so long as the short or long forms are complete. An incomplete command will not be recognized. Below are examples of correctly written commands: LONG SOURce1:DCOffse t SOURCE1:DCOFFSET source1:dcoffset SHORT SOUR1:DCO sour1:dco

Command	SOURCE1:DCOffset<offset>LF 1234				1: command header
Format					2: single space 3: parameter 4: message terminator
Square Brackets []	Commands that contain squares brackets indicate that the contents are optional. The function of the command is the same with or without the square bracketed items. Brackets are not sent with the command. For example, the frequency query below can use any of the following 3 forms: SOURCE1:FREQUENCY? [MINimum MAXimum] SOURCE1:FREQUENCY? MAXimum SOURCE1:FREQUENCY? MINimum SOURCE1:FREQUENCY?				
Braces {}	Commands that contain braces indicate one item within the braces must be chosen.Braces are not sent with the command.				
Angled Brackets <>	Angle brackets are used to indicate that a value must be specified for the parameter. See the parameter description below for details. Angled brackets are not sent with the command.				
Bars	Bars are used to separate multiple parameter choices in the command format.				
Parameters	Type	Description	Example		
	<Boolean>	Boolean logic	0, 1/ON,OFF		
	<NR1>	integers	0, 1, 2, 3		
	<NR2>	decimal numbers	0.1, 3.14, 8.5		

<NR3>	floating point	4.5e-1, 8.25e+1
<NRf>	any of NR1, 2, 3	1, 1.5, 4.5e-1
<NRf+> <Num eric>	NRf type with a suffix including MINimum, MAXimum or DEFault parameters.	1, 1.5, 4.5e-1 MAX, MIN,
<aard>	Arbitrary ASCII characters.	
<discrete>	Discrete ASCII character parameters	IMM, EXT, MAN
<frequency> <peak deviation in Hz> <rate in Hz>	NRf+ type including frequency unit suffixes.	1 KHZ, 1.0 HZ, MHZ
<amplitude>	NRf+ type including voltage peak to peak.	VPP
<offset>	NRf+ type including volt unit suffixes.	V
<seconds>	NRf+ type including time unit suffixes.	NS, S MS US
<percent> <depth in percent>	NRf type	N/A

Message terminators	LF CR	line feed code (new line) and carriage return.
	LF	line feed code (new line)
	EOI	IEEE-488 <i>EOI</i> (End-Or-Identify)
Note ^j or ^m should be used when using a terminal program.		
Command Separators	Space	A space is used to separate a parameter from a keyword/command header.
	Colon (:)	A colon is used to separate keywords on each node.
	Semicolon (;)	A semi colon is used to separate subcommands that have the same node level. For example: SOURce[1]:DCOffset? SOURce[1]:OUTPut? →SOURce1:DCOffset?:OUTPut?
Colon + Semicolon (,:)		A colon and semicolon can be used to combine commands from different node levels. For example: SOURce1:PWM:SOURce? SOURce:PULSe:WIDTh? →SOURce1:PWM:SOURce?:;SOURce:PULSe:WIDTh?

Comma (,)

When a command uses multiple parameters, a comma is used to separate the parameters.

For example:

SOURce:APPLy:SQUare 10KHZ, 2.0
VPP, -1V

指令列表

488.2 Common Commands.....	273
*IDN?.....	273
*RST.....	273
*TST?.....	273
*OPC.....	274
*OPC?.....	274
*WAI.....	275
Status Register Commands	276
*CLS.....	276
*ESE.....	276
*ESR?.....	277
*STB?.....	278
*SRE.....	278
*PSC.....	279
STATus:QUESTionable:CONDition?	280
STATus:QUESTionable:EVENT?	281
STATus:QUESTionable:ENABle.....	281
STATus:PRESet.....	282
System Commands	283
SYSTem:ERRor?	283
SYSTem:INTerface.....	283
SYSTem:LOCal.....	283
SYSTem:REMOte.....	284
SYSTem:LANGuage.....	284
SYSTem:VERSion?	285
Apply Commands.....	286
SOURce[1 2]:APPLy:SINusoid.....	288
SOURce[1 2]:APPLy:SQUare.....	288

SOURce[1 2]:APPLy:RAMP	289
SOURce[1 2]:APPLy:PULSe	290
SOURce[1 2]:APPLy:NOISe	290
SOURce[1 2]:APPLy:TRIAngle	291
SOURce[1 2]:APPLy:DC	292
SOURce[1 2]:APPLy:HARMonic	292
SOURce[1 2]:APPLy:USER	293
SOURce[1 2]:APPLy?	294
Output Commands	295
SOURce[1 2]:FREQuency	295
SOURce[1 2]:AMPLitude	296
SOURce[1 2]:PHASe	298
SOURce[1 2]:PHASe:ALIGn	299
SOURce[1 2]:DCOffset	299
SOURce[1 2]:SQUare:DCYCLe	300
SOURce[1 2]:RAMP:SYMMetry	301
OUTPut[1 2]	302
OUTPut[1]:LOAD	303
OUTPut[1 2]:SYNC	304
SOURce[1]:VOLTage:UNIT	305
Pulse Configuration Commands	306
SOURce[1 2]:PULSe:WIDTh	306
SOURce[1 2]:PULSe:DCYCLe	307
SOURce[1 2]:PULSe:EDGetime	308
SOURce[1 2]:PULSe:RISE	309
SOURce[1 2]:PULSe:FALL	310
Harmonic Commands	310
SOURce[1 2]:HARMonic:TOTAL	311
SOURce[1 2]:HARMonic:TYPE	311
SOURce[1 2]:HARMonic:ORDER	312

SOURce[1 2]:HARMonic:DISPlay	313
Amplitude Modulation (AM) Commands	315
AM Overview	315
SOURce[1 2]:AM:STATe	316
SOURce[1 2]:AM:MODulation:INPut	317
SOURce[1 2]:AM:INternal:FUNCTion	318
SOURce[1 2]:AM:INternal:FREQuency	318
SOURce[1 2]:AM:DEPTh	319
Frequency Modulation (FM) Commands	321
FM Overview	321
SOURce[1 2]:FM:STATe	322
SOURce[1 2]:FM:MODulation:INPut	323
SOURce[1 2]:FM:INternal:FUNCTion	324
SOURce[1 2]:FM:INternal:FREQuency	325
SOURce[1 2]:FM:DEViation	325
Frequency-Shift Keying (FSK) Commands	328
FSK Overview	328
SOURce[1 2]:FSKey:STATe	328
SOURce[1 2]:FSKey:MODulation:INPut	329
SOURce[1 2]:FSKey:FREQuency	330
SOURce[1 2]:FSKey:INternal:RATE	331
Phase Modulation (PM) Commands	332
PM Overview	332
SOURce[1 2]:PM:STATe	333
SOURce[1 2]:PM:INternal:FUNCTion	333
SOURce[1 2]:PM:INternal:FREQuency	334
SOURce[1 2]:PM:DEViation	335
Additive Modulation (SUM) Commands	337
SUM Overview	337
SOURce[1 2]:SUM:STATe	338

SOURce[1 2]:SUM:MODulation:INPut	339
SOURce[1 2]:SUM:INteRnal:FUNction.....	340
SOURce[1 2]:SUM:INteRnal:FREQuency	341
SOURce[1 2]:SUM:AMPLitude.....	341
Pulse Width Modulation (PWM) Commands	343
PWM Overview.....	343
SOURce[1 2]:PWM:STATe	344
SOURce[1 2]:PWM:MODulation:INPut.....	345
SOURce[1 2]:PWM:INteRnal:FUNction.....	345
SOURce[1 2]:PWM:INteRnal:FREQuency.....	346
SOURce[1 2]:PWM:DUTY.....	347
Frequency Sweep Commands	349
Sweep Overview	349
SOURce[1 2]:SWEep:STATe	350
SOURce[1 2]:SWEep:TYPE	351
SOURce[1 2]:SWEep:MODE.....	352
SOURce[1 2]:SWEep:SHApe.....	353
SOURce[1 2]:SWEep:MANual:TRIGger	353
SOURce[1 2]:SWEep:FREQuency:START.....	354
SOURce[1 2]:SWEep:FREQuency:STOP	355
SOURce[1 2]:SWEep:FREQuency:CENTer.....	356
SOURce[1 2]:SWEep:FREQuency:SPAN.....	357
SOURce[1 2]:SWEep:FUNction.....	358
SOURce[1 2]:SWEep:TIME.....	358
SOURce[1 2]:SWEep:TRIGger	359
SOURce[1 2]:SWEep:AMPLitude:START.....	361
SOURce[1 2]:SWEep:AMPLitude:STOP	362
Burst Mode Commands	363
Burst Mode Overview	363
SOURce[1 2]:BURSt:STATe.....	366

SOURce[1 2]:BURSt:MODE.....	367
SOURce[1 2]:BURSt:NCYCles.....	368
SOURce[1 2]:BURSt:INTernal:PERiod.....	369
SOURce[1 2]:BURSt:PHASe.....	370
SOURce[1 2]:BURSt:TRIGger:MANual.....	371
SOURce[1 2]:BURSt:TRIGger.....	371
SOURce[1 2]:BURSt:TRIGger:DELay.....	373
SOURce[1 2]:BURSt:TRIGger:SLOPe.....	374
SOURce[1 2]:BURSt:GATE:POLarity.....	374
Arbitrary Waveform Commands	376
Arbitrary Waveform Overview.....	376
DATA:DAC	377
SOURce[1 2]:ARB:EDIT:COPY.....	378
SOURce[1 2]:ARB:EDIT:DELete.....	379
SOURce[1 2]:ARB:EDIT:DELete:ALL.....	380
SOURce[1 2]:ARB:EDIT:POINT.....	380
SOURce[1 2]:ARB:EDIT:PROTect.....	380
SOURce[1 2]:ARB:EDIT:PROTect:ALL.....	381
SOURce[1 2]:ARB:EDIT:UNProtect.....	382
SOURce[1 2]:ARB:BUIlt:SINusoid.....	382
SOURce[1 2]:ARB:BUIlt:SQUare.....	383
SOURce[1 2]:ARB:BUIlt:PULSe.....	383
SOURce[1 2]:ARB:BUIlt:RAMP.....	384
SOURce[1 2]:ARB:BUIlt:SINC.....	385
SOURce[1 2]:ARB:BUIlt:EXPRise.....	386
SOURce[1 2]:ARB:BUIlt:EXPFall.....	386
SOURce[1 2]:ARB:BUIlt:DC.....	387
SOURce[1 2]:ARB:BUIlt:stair_ud.....	387
SOURce[1 2]:ARB:BUIlt:stair_down.....	388
SOURce[1 2]:ARB:BUIlt:stair_up.....	389
SOURce[1 2]:ARB:BUIlt:absatan.....	389

SOURce[1 2]:ARB:BUIlt:abssin	390
SOURce[1 2]:ARB:BUIlt:abssinehalf	390
SOURce[1 2]:ARB:BUIlt:ampalt	391
SOURce[1 2]:ARB:BUIlt:attalt	392
SOURce[1 2]:ARB:BUIlt:diric_even	392
SOURce[1 2]:ARB:BUIlt:diric_odd	393
SOURce[1 2]:ARB:BUIlt:gauspuls	393
SOURce[1 2]:ARB:BUIlt:havercosine	394
SOURce[1 2]:ARB:BUIlt:haversine	395
SOURce[1 2]:ARB:BUIlt:n_pulse	395
SOURce[1 2]:ARB:BUIlt:negramp	396
SOURce[1 2]:ARB:BUIlt:rectpuls	396
SOURce[1 2]:ARB:BUIlt:roundhalf	397
SOURce[1 2]:ARB:BUIlt:sawtoot	398
SOURce[1 2]:ARB:BUIlt:sinetra	398
SOURce[1 2]:ARB:BUIlt:stepresp	399
SOURce[1 2]:ARB:BUIlt:sinever	399
SOURce[1 2]:ARB:BUIlt:trapezia	400
SOURce[1 2]:ARB:BUIlt:tripulsl	401
SOURce[1 2]:ARB:BUIlt:dlorentz	401
SOURce[1 2]:ARB:BUIlt:gauss	402
SOURce[1 2]:ARB:BUIlt:ln	402
SOURce[1 2]:ARB:BUIlt:lorentz	403
SOURce[1 2]:ARB:BUIlt:sinc	404
SOURce[1 2]:ARB:BUIlt:sqrt	404
SOURce[1 2]:ARB:BUIlt:xsquare	405
SOURce[1 2]:ARB:BUIlt:arccos	405
SOURce[1 2]:ARB:BUIlt:arccot	406
SOURce[1 2]:ARB:BUIlt:arccsc	407
SOURce[1 2]:ARB:BUIlt:arcsec	407
SOURce[1 2]:ARB:BUIlt:arcsin	408

SOURce[1 2]:ARB:BUIlt:arcsinh	408
SOURce[1 2]:ARB:BUIlt:arctan	409
SOURce[1 2]:ARB:BUIlt:arctanh	410
SOURce[1 2]:ARB:BUIlt:cosh	410
SOURce[1 2]:ARB:BUIlt:cot	411
SOURce[1 2]:ARB:BUIlt:csc	411
SOURce[1 2]:ARB:BUIlt:sec	412
SOURce[1 2]:ARB:BUIlt:sech	413
SOURce[1 2]:ARB:BUIlt:sinh	413
SOURce[1 2]:ARB:BUIlt:tan	414
SOURce[1 2]:ARB:BUIlt:tanh	414
SOURce[1 2]:ARB:BUIlt:barthannwin	415
SOURce[1 2]:ARB:BUIlt:bartlett	416
SOURce[1 2]:ARB:BUIlt:blackman	416
SOURce[1 2]:ARB:BUIlt:bohmanwin	417
SOURce[1 2]:ARB:BUIlt:chebwin	417
SOURce[1 2]:ARB:BUIlt:flattopwin	418
SOURce[1 2]:ARB:BUIlt:hamming	419
SOURce[1 2]:ARB:BUIlt:hann	419
SOURce[1 2]:ARB:BUIlt:kaiser	420
SOURce[1 2]:ARB:BUIlt:traing	420
SOURce[1 2]:ARB:BUIlt:tukeywin	421
SOURce[1 2]:ARB:OUTPut	422
SOURce[1 2]:ARB:RATE	423
SOURce[1 2]:ARB:GATE	423
SOURce[1 2]:ARB:NCYCLE	424
SOURce[1 2]:ARB:NCYCles:CYCLE	425
SOURce[1 2]:ARB:MANual:TRIGger	426
Tracking Commands	428
SOURce[1 2]:COUPle:FREQuency:MODE	428
SOURce[1 2]:COUPle:FREQuency:OFFSet	429

SOURce[1 2]:COUPle:FREQuency:RATio.....	430
SOURce[1 2]:COUPle:AMPLitude.....	431
SOURce[1 2]:TRACking:STATe	432
Reference Commands.....	433
SOURce[1 2]:REFeRence	433
SOURce[1 2]:REFeRence:SYNChronous.....	434
Save and Recall Commands.....	435
*SAV.....	435
*RCL.....	435
MEMory:STATe:DELeTe.....	435
MEMory:STATe:DELeTe ALL	436
MEMory:STATe?	436

488.2 常见指令

*IDN?		System Query
Description	Returns the function generator manufacturer, model number, serial number and firmware version number in the following format: GW INSTEK,AFG-3032,SN:XXXXXXXX,Vm.mm	
Query Syntax	IDN?	
Return parameter	<string>	
Example	*IDN? GW INSTEK,AFG-3032,SN:XXXXXXXX,Vm.mm Returns the identification of the function generator.	
*RST		System Command
Description	Reset the function generator to its factory default state.	
Note	Note the *RST command will not delete instrument save states in memory.	
Syntax	*RST	
*TST?		System Query
Description	Performs a system self-test and returns a pass or fail judgment. An error message will be generated if the self test fails.	

Note	The error message can be read with the SYST:ERR? query.
------	---

Query Syntax	*TST?
--------------	--------------

Return parameter	+0	Pass judgment
	+1	Fail judgment

Example	*TST? +0 The function generator passed the self-test.
---------	--

*OPC

System Command

Description	This command sets the Operation Complete Bit (bit 0) of the Standard Event Status Register after the function generator has completed all pending operations. For the AFG-30XX, the *OPC command is used to indicate when a sweep or burst has completed.
-------------	---

Note	Before the OPC bit is set, other commands may be executed.
------	--

Syntax	*OPC
--------	-------------

*OPC?

System Query

Description	Returns the OPC bit to the output buffer when all pending operations have completed. I.e. when the OPC bit is set.
-------------	--

Note	Commands cannot be executed until the *OPC? query has completed.
------	--

Query Syntax	*OPC?	
Return parameter	1	
Example	*OPC? 1 Returns a “1” when all pending operations are complete.	

*WAI		System Command
Description	This command waits until all pending operations have completed before executing additional commands. I.e. when the OPC bit is set.	
Note	This command is only used for triggered sweep and burst modes.	
Syntax	*WAI	

状态寄存器指令

*CLS System Command

Description	The *CLS command clears all the event registers, the error queue and cancels an *OPC command.
Syntax	*CLS

*ESE System Command

Description	The Standard Event Status Enable command determines which events in the Standard Event Status Event register can set the Event Summary Bit (ESB) of the Status Byte register. Any bit positions set to 1 enable the corresponding event. Any enabled events set bit 5 (ESB) of the Status Byte register.		
Note	The *CLS command clears the event register, but not the enable register.		
Syntax	*ESE <enable value>		
Parameter	<enable value>	0~255	
Example	*ESE 20 Sets a bit weight of 20 (bits 2 and 4).		
Query Syntax	*ESE?		

Return Parameter	Bit	Register	Bit	Register
	0	Operation complete bit	4	Execution Error

1	Not Used	5	Command Error
2	Query Error	6	Not Used
3	Device Error	7	Power On

Example ***ESE?**

4

Bit 2 is set.

***ESR?** System Command

Description	Reads and clears the Standard Event Status Register. The bit weight of the standard event status register is returned.
Note	The *CLS will also clear the standard event status register.

Query Syntax ***ESR?**

Return Parameter	Bit	Register	Bit	Register
	0	Operation Complete	4	Execution Error
	1	Not Used	5	Command Error
	2	Query Error	6	Not Used
	3	Device Error	7	Power On

Query Example ***ESR?**

5

Returns the bit weight of the standard event status register (bit 0 and 2).

*STB?

System Command

Description	Reads the Status byte condition register.
Note	Bit 6, the master summary bit, is not cleared.
Syntax	*STB?

*SRE

System Command

Description	The Service Request Enable Command determines which events in the Status Byte Register are allowed to set the MSS (Master summary bit). Any bit that is set to “1” can cause the MSS bit to be set.		
Note	The *CLS command clears the status byte event register, but not the enable register.		
Syntax	*SRE <enable value>		
Parameter	<enable value>	0~255	
Example	*SRE 12 Sets a bit weight of 12 (bits 2 and 3) for the service request enable register.		
Query Syntax	*SRE?		

Return Parameter	Bit	Register	Bit	Register
	0	Not used	4	Message Available
	1	Not used	5	Standard Event

2	Error Queue	6	Master Summary*
3	Questionable Data	7	Not used

* The Master Summary (MSS) bit cannot be used to set itself.

Query Example ***SRE?**

12

Returns the bit weight of the status byte enable register.

***PSC** System Command

Description	The Power-On Status Clear command is used to clear a number enable registers at power-on. The following enable register groups are cleared when the *PSC command is enabled: Questionable data enable register Standard operation enabled register Status byte condition enable register Standard event enable register
-------------	--

Syntax ***PSC {OFF|ON}**

Parameter	OFF	Disables PSC.
	ON	Enables PSC.

Example ***PSCOFF**

Disables the Power-On Status Clear function.

Query Syntax ***PSC?**

Return	0	PSC disabled
Parameter	1	PSC enabled
Example	*PSC? 0 PSC is disabled.	

STATus:QUEStionable:CONDition? System Command

Description	Reads the Questionable Status Condition register. The bit weight of the register is returned.			
Note	This command will not clear the Status Questionable Condition register.			
Query Syntax	STATus:QUEStionable:CONDition?			
Return	Bit	Register	Bit	Register
Parameter	0	Voltage overload	4	Over temperature
	5	Loop unlock	7	Ext Mod Overload
	8	Cal Error	9	External Reference

Query Example	STAT:QUES:COND? 0 Returns the bit weight of the questionable status condition register (bit 0). Indicates that there are no errors.
---------------	---

STATus:QUEStionable:EVENT?

System Command

Description	Reads and clears the Questionable Status Event register. The bit weight of the register is returned.
-------------	--

Query Syntax	STATus:QUEStionable:EVENT?
--------------	-----------------------------------

Return Parameter	Bit	Register	Bit	Register
	0	Voltage overload	4	Over temperature
	5	Loop unlock	7	Ext Mod Overload
	8	Cal Error	9	External Reference

Query Example	STAT:QUES:EVEN?
---------------	------------------------

16

Returns the bit weight of the questionable status event register (bit 0). Indicates that an over temperature (bit 4) event has occurred.

STATus:QUEStionable:ENABLE

System Command

Description	This command determines which events in the QuestionableStatus Register group are allowed to set the Questionable Data bit in the Status Byte register.
-------------	---

Syntax	STATus:QUEStionable:ENABLE<enable value>
--------	---

Parameter	<enable value>	0~255
-----------	----------------	-------

Example **STAT:QUES:ENAB17**

 Sets a bit weight of 17 (bits 0 and 4). I.e, enables voltage overload and over temperature bits.

Query Syntax **STATus:QUEStionable:ENABle?**

Return Parameter	Bit	Register	Bit	Register
	0	Voltage overload	4	Over temperature
	5	Loop unlock	7	Ext Mod Overload
	8	Cal Error	9	External Reference

Query Example **STAT:QUES:ENAB?**

17

 Returns the bit weight of the questionable status enable register.

STATus:PRESet

System Command

Description Clears the Questionable Status Enable registers.

Syntax **STATus:PRESet**

Example **STAT:PRES**

 Clears the Questionable Status Enable registers.

系统指令

SYSTem:ERRor?		System Query
Description	Reads an error from the error queue. See page 457 for details regarding the error queue.	
Query Syntax	SYSTem:ERRor?	
Return parameter	<string>	Returns an error string, <256 ASCII characters.
Example	SYSTem:ERRor? -138 Suffix not allowed Returns an error string.	

SYSTem:INTerface		System Command
Description	Selects the remote interface. USB is the factory default.	
Note	There is no interface query.	
Syntax	SYSTem:INTerface {GPIB LAN USB}	
Example	SYST:INT USB Sets the interface to USB.	

SYSTem:LOCal		System Command
Description	Sets the function generator to local mode. In local mode, all front panel keys are operational.	

Syntax **SYSTem:LOCal**

Example **SYST:LOC**

SYSTem:REMOte System Command

Description Disables the front panel keys and puts the function generator into remote mode.

Syntax **SYSTem:REMOte**

Example **SYST:REM**

SYSTem:LANGUage System Command

Description Sets or queries the display language. Select the language shown on the function generator front-panel display. Only one language can be enabled at a time. SYSTem:LANGUage? query returns "CHIN", "ENF" or "TRCH".

Note Only one language can be set.

Syntax **SYSTem:LANGUage**
{CHINese|ENGLISH|TRCHinese}

Example **SYST:LANG ENG**

Sets the display language to English.

Query Syntax **SYSTem:LANGUage?**

Return	CHIN	Chinese
Parameter	ENG	English

	TRCH	Traditional Chinese
--	------	---------------------

Query Example **SYST:LANG?**

ENG

The current language is English.

SYSTem:VERSion?	System Query
-----------------	--------------

Description	Performs a system version query. Returns a string with the instrument, firmware version, FPGA revision and bootloader.
-------------	--

Query Syntax	SYSTem:VERSion?
--------------	------------------------

Return parameter	<string>
------------------	----------

Example **SYST:VERS?**

AFG-3032 VX.XXX_XXXX FPGA:XXXX
BootLoad:XXXX

Returns the date and version for that date.

应用指令

The APPLy command has 8 different types of outputs (Sine, Square, Ramp, Pulse, Noise, Triangle, Harmonic, User). The command is the quickest, easiest way to output waveforms remotely. Frequency, amplitude and offset can be specified for each function.

As only basic parameters can be set with the Apply command, other parameters use the instrument default values.

The Apply command will set the trigger source to immediate and disable burst, modulation and sweep modes. Turns on the output command OUTP[1 | 2] ON. The termination setting will not be changed.

As the frequency, amplitude and offset parameters are in nested square brackets, amplitude can only be specified if the frequency has been specified and offset can only be specified if amplitude has been set. For the example:

```
SOURce[1 | 2]:APPLy:SINusoid [<frequency> [<amplitude> [<offset>] ]]
```

Output Frequency	For the output frequency, MINimum, MAXimum and DEFault can be used. The default frequency for all functions is set to 1 kHz. The maximum and minimum frequency depends on the function used. If a frequency output that is out of range is specified, the max/min frequency will be used instead. A "Data out range error will be generated" from the remote terminal.
------------------	--

Output
Amplitude

When setting the amplitude, MINimum, MAXimum and DEFault can be used. The range depends on the function being used and the output termination (50Ω or high impedance). The default amplitude for all functions is 100 mVpp (50Ω).

If the amplitude has been set and the output termination is changed from 50Ω to high impedance, the amplitude will double. Changing the output termination from high impedance to 50Ω will half the amplitude.

Vrms, dBm or Vpp units can be used to specify the output unit to use with the current command. The SOURce[1 | 2]:VOLT:UNIT command can be used to set the units when no unit is specified with the Apply command. If the output termination is set to high impedance, dBm units cannot be used. The units will default to Vpp.

The output amplitude can be affected by the function and unit chosen. Vpp and Vrms or dBm values may have different maximum values due to differences such as crest factor. For example, a 5Vrms square wave must be adjusted to 3.536 Vrms for a sine wave.

DC Offset
voltage

The offset parameter can be set to MINimum, MAXimum or DEFault. The default offset is 0 volts. The offset is limited by the output amplitude as shown below.

$$|V_{offset}| < V_{max} - V_{pp}/2$$

If the output specified is out of range, the maximum offset will be set.

The offset is also determined by the output termination (50Ω or high impedance). If the offset has been set and the output termination has changed from 50Ω to high impedance, the offset will double. Changing the output termination from high impedance to 50Ω will half the offset.

		Source Specific
SOURce[1 2]:APPLy:SINusoid		Command
Description	Outputs a sine wave from the selected channel when the command has executed. Frequency, amplitude and offset can also be set.	
Syntax	SOURce[1 2]:APPLy:SINusoid [<frequency> [<amplitude> [<offset>]]]	
Parameter	<frequency>	1μHz~30MHz (20MHZ AFG-3021/3022)
	<amplitude>	1mV~10V (50Ω) (3.536 Vrms)
	<offset>	0~4.99V (50Ω)
Example	SOUR1:APPL:SIN 2KHZ,MAX,MAX Sets frequency to 2kHz and sets the amplitude and offset to the maximum.	

		Source Specific
SOURce[1 2]:APPLy:SQUare		Command
Description	Outputs a square wave from the selected channel when the command has executed. Frequency, amplitude and offset can also be set. The duty cycle is set to 50%.	

Syntax	SOURce[1 2]:APPLy:SQUare [<frequency> [,<amplitude> [,<offset>]]]	
Parameter	<frequency>	1μHz~30MHz (20MHz AFG-3021/3022)
	<amplitude>	1mV~10V (50Ω)
	<offset>	0~4.99V (50Ω)
Example	SOUR1:APPL:SQU 2KHZ,MAX,MAX Sets frequency to 2kHz and sets the amplitude and offset to the maximum.	
SOURce[1 2]:APPLy:RAMP		Source Specific Command
Description	Outputs a ramp wave from the selected channel when the command has executed. Frequency, amplitude and offset can also be set. The symmetry is set to 100%.	
Syntax	SOURce[1 2]:APPLy:RAMP [<frequency> [,<amplitude> [,<offset>]]]	
Parameter	<frequency>	1μHz~1MHz
	<amplitude>	1mV~10V (50Ω)
	<offset>	0~4.99V (50Ω)
Example	SOUR1:APPL:RAMP 2KHZ,MAX,MAX Sets frequency to 2kHz and sets the amplitude and offset to the maximum.	

SOURce[1 2]:APPLy:PULSe		Source Specific Command
Description	Outputs a ramp wave from the selected channel when the command has executed. Frequency, amplitude and offset can also be set.	
Note	The PW settings from the SOURce[1]:PULS: WIDT command are preserved. Edge and pulse width may be adjusted to supported levels. Repetition rates will be approximated from the frequency. For accurate repetition rates, the period should be adjusted using the SOURce[1]:PULS:PER command	
Syntax	SOUR[1 2]:APPLy:PULSe [<frequency> [, <amplitude> [, <offset>]]]	
Parameter	<frequency>	1μHz~25MHz (20MHz AFG-3021/3022)
	<amplitude>	1mV~10V (50Ω)
	<offset>	0~4.99V (50Ω)
Example	SOUR1:APPL:PULS 1KHZ,MIN,MAX Sets the frequency to 1kHz, sets the amplitude to the minimum and the offset to the maximum.	

SOURce[1 2]:APPLy:NOISe		Source Specific Command
Description	Outputs white noise (no set bandwidth). Amplitude and offset can also be set.	

Note	Frequency cannot be used with the noise function; however a value (or DEFault) must be specified. The frequency is remembered for the next function used.
------	---

Syntax	SOURce[1 2]:APPLy:NOISe [<frequency DEFault> [,<amplitude> [,<offset>]]]
--------	--

Parameter	<frequency DEFault>	Not applicable
	<amplitude>	1mV~10V (50Ω)
	<offset>	0~4.99V (50Ω)

Example	SOUR1:APPL:NOIS DEF,3.0,1.0 Sets the amplitude to 3 volts with an offset of 1 volt.
---------	---

	Source Specific
SOURce[1 2]:APPLy:TRIangle	Command

Description	Outputs a triangle wave from the selected channel when the command has executed. Frequency, amplitude and offset can also be set.
-------------	---

Syntax	SOURce[1 2]:APPLy:TRIangle [<frequency> [,<amplitude> [,<offset>]]]
--------	---

Parameter	<frequency>	1μHz~1MHz
	<amplitude>	1mV~10V (50Ω)
	<offset>	0~4.99V (50Ω)

Example	SOUR1:APPL:TRI2khz,3.0,1.0 Sets the frequency to 1 MHz with an amplitude of 3 volts and with an offset of 1 volt.
---------	---

Source Specific Command	
SOURce[1 2]:APPLy:DC	
Description	Outputs a DC signal from the selected channel when the command has executed. Amplitude and offset can also be set.
Note	Frequency cannot be used with the DC function; however a value (or DEFault) must be specified.
Syntax	SOURce[1 2]:APPLy:DC [<frequency> DEFault[,<amplitude> [,<offset>]]]
Parameter	<frequency> DEFault> 1μHz~1MHz
	<amplitude> 1mV~10V (50Ω)
	<offset> 0~4.99V (50Ω)
Example	SOUR1:APPL:DCDEF,3.0,1.0 Sets the DC voltage to 4 volts (amplitude of 3V with an offset of 1 volt).

Source Specific Command	
SOURce[1 2]:APPLy:HARMonic	
Description	Outputs a sine wave with harmonic components from the selected channel when the command has executed. Frequency, amplitude and offset can also be set. The maximum frequency is limited by the highest order. Highest order n: maximum frequency is 30MHz/n or 20MHz/n for AFG-3021/3022)).
Syntax	SOURce[1 2]:APPLy:HARMonic [<frequency> [,<amplitude> [,<offset>]]]

SOURce[1 2]:APPLy?		Source Specific Command
Description	Outputs a string with the current settings for the selected channel.	
Note	The string can be passed back appended to the Apply Command.	
Syntax	SOURce[1 2]:APPLy?	
Return Parameter	<string>	Function, frequency, amplitude, offset
Example	SOUR1:APPL? SIN +5.000000000000E+03,+3.0000E+00,-2.50E+00 Returns a string with the current function and parameters, Sine, 5kHz, 3Vpp, -2.5V offset.	

输出指令

Unlike the Apply commands, the Output commands are low level commands to program the function generator.

This section describes the low-level commands used to program the function generator. Although the APPLy command provides the most straightforward method to program the function generator, the low-level commands give you more flexibility to change individual parameters.

SOURce[1 2]:FREQuency		Source Specific Command
Description	Sets the output frequency for the selected channel and the query command returns the current frequency setting.	
Note	The maximum and minimum frequency depends on the function mode.	
	Sine, Square	1μHz~30MHz (20MHz AFG-3021/3022)
	Ramp, Triangle	1μHz~1MHz
	Pulse	1μHz~25MHz (20MHz AFG-3021/3022)
	Noise	Not applicable
	User	1pHz~125MHz

If the function mode is changed and the current frequency setting is not supported by the new mode, the frequency setting will be altered to next highest value.

The duty cycle of square waveforms depends on the frequency settings.

20% to 80% (*frequency* < 25 MHz)

40% to 60% (25 MHz <*frequency* ≤ 30 MHz)

If the frequency is changed and the set duty cycle cannot support the new frequency, the highest duty cycle available at that frequency will be used. A “settings conflict” error will result from the above scenario.

Syntax	SOURce[1 2]:FREQuency {<frequency> MINimum MAXimum}	
Example	SOUR1:FREQ MAX Sets the frequency to the maximum for the current mode.	
Query Syntax	SOURce[1 2]:FREQuency?	
Return Parameter	<NR3>	Returns the frequency for the current mode.
Example	SOUR1:FREQ? MAX +1.0000000000000E+03 The maximum frequency that can be set for the current function is 1MHz.	
SOURce[1 2]:AMPLitude		Source Specific Command

Description	Sets the output amplitude or queries the current amplitude settings for the selected channel.
Note	The maximum and minimum amplitude depends on the output termination. The default amplitude for all functions is 3Vpp (50Ω). If the amplitude has been set and the output termination is changed from 50Ω to high impedance, the amplitude will double. Changing the output termination from high impedance to 50Ω will half the amplitude. The offset and amplitude are related by the following equation. $ V_{offset} < V_{max} - V_{pp}/2$ If the output termination is set to high impedance, dBm units cannot be used. The units will default to Vpp. The output amplitude can be affected by the function and unit chosen. Vpp and Vrms or dBm values may have different maximum values due to differences such as crest factor. For example, a 5Vrms square wave must be adjusted to 3.536 Vrms for a sine wave. The amplitude units can be explicitly used each time the SOURce[1]:AMPLitude command is used. Alternatively, theSOURce[1 2]:VOLT:UNITcommand can be used to set the amplitude units for all commands.
Syntax	SOURce[1 2]:AMPLitude {< amplitude> MINimum MAXimum}

Example	SOUR1:AMPLMAX
	Sets the amplitude to the maximum for the current mode.

Query Syntax	SOURce[1 2]:AMPLitude? {MINimum MAXimum}
--------------	---

Return Parameter	<NR3>	Returns the amplitude for the current mode.
------------------	-------	---

Example	SOUR1:AMPL? MAX +5.0000E+00
---------	--

The maximum amplitude that can be set for the current function is 5 volts.

Source Specific
Command

SOURce[1|2]:PHASe

Description	Sets or queries the output phase angle (-360° ~ 360°) of the selected channel. The default phase is 0° .
-------------	---

Syntax	SOURce[1 2]:PHASe{<angle> MINimum MAXimum}
--------	--

Example	SOUR[1]:PHAS:MAX Sets the output phase to the maximum.
---------	--

Query Syntax	SOURce[1 2]:PHASe {MINimum MAXimum}
--------------	--

Return Parameter	<NR3>	Returns the phase in degrees.
------------------	-------	-------------------------------

Example	SOUR1:PHAS? +1.2000E+01
---------	--

The phase is set to 12°.

	Source Specific
SOURce[1 2]:PHASe:ALIGn	Command

Description	Aligns the timebase of both channels but doesn't change the phase deviation of the channels. In other words it re-calibrates the phase difference between both of the channels.
-------------	---

Syntax	SOURce[1 2]:PHASe:ALIGn
--------	--------------------------------

Example	SOUR[1]:PHAS:ALIG Turns on the phase align function.
---------	--

	Source Specific
SOURce[1 2]:DCOffset	Command

Description	Sets or queries the DC offset for the current mode.
-------------	---

Note	The offset parameter can be set to MINimum, MAXimum or DEFault. The default offset is 0 volts. The offset is limited by the output amplitude as shown below.
------	--

$$|V_{offset}| < V_{max} - V_{pp}/2$$

If the output specified is out of range, the maximum offset will be set.

The offset is also determined by the output termination (50Ω or high impedance). If the offset has been set and the output termination has changed from 50Ω to high impedance, the offset will double. Changing the output termination from high impedance to 50Ω will half the offset.

Syntax	SOURce[1 2]:DCOffset {< offset> MINimum MAXimum}	
Example	SOUR1:DCO MAX Sets the offset to the maximum for the current mode.	
Query Syntax	SOURce[1 2]:DCOffset? (MINimum MAXimum)	
Return Parameter	<NR3>	Returns the offset for the current mode.
Example	SOUR1:DCO? +3.0000E+00 The offset for the current mode is set to +3 volts.	

SOURCE SPECIFIC COMMAND

SOURce[1|2]:SQUare:DCYCLE

Description	Sets or queries the duty cycle for square waves only. The setting is remembered if the function mode is changed. The default duty cycle is 50%.
Note	The duty cycle of square waveforms depend on the frequency settings. 20% to 80% (<i>frequency</i> < 25 MHz) 40% to 60% (25 MHz <<i>frequency</i> ≤ 30 MHz) If the frequency is changed and the set duty cycle cannot support the new frequency, the highest duty cycle available at that frequency will be used. A “settings conflict” error will result from the above scenario. For square waveforms, the Apply command and

	AM/FM modulation modes ignore the duty cycle settings.	
Syntax	SOURce[1 2]:SQUare:DCYCl e {< percent> MINimum MAXimum}	
Example	SOUR1:SQU:DCYC MAX Sets the duty cycle to the highest possible for the current frequency.	
Query Syntax	SOURce[1 2]:SQUare:DCYCl e? {MINimum MAXimum}	
Return Parameter	<NR3>	Returns the duty cycle as a percentage.
Example	SOUR1:SQU:DCYC? +5.00E+01 The duty cycle is set 50%.	

		Source Specific Command
SOURce[1 2]:RAMP:SYMMetry		
Description	Sets or queries the symmetry for ramp waves only. The setting is remembered if the function mode is changed. The default symmetry is 50%.	
Note	For ramp waveforms, the Apply command and AM/FM modulation modes ignore the current symmetry settings.	
Syntax	SOURce[1 2]:RAMP:SYMMetry {< percent> MINimum MAXimum}	
Example	SOUR1:RAMP:SYMM MAX Sets the symmetry to the 100%.	

Query Syntax	SOURce[1 2]:RAMP:SYMMetry? {MINimum MAXimum}	
Return Parameter	<NR3>	Returns the symmetry as a percentage.
Example	SOUR1:RAMP:SYMMetry? +1.0000E+02 The symmetry is set as 100%.	

		Source Specific Command
OUTPut[1 2]		
Description	Enables/Disables or queries the front panel output. The default is set to off.	
Note	If the output is overloaded by an external voltage, the output will turn off and an error message will be displayed. The overload must first be removed before the output can be turned on again with the output command. Using the Apply command automatically sets the front panel output to on.	
Syntax	OUTPut[1 2] {OFF ON}	
Example	OUTP1 ON Turns the output on for channel 1.	
Query Syntax	OUTPut[1 2]?	
Return Parameter	1	ON
	0	OFF
Example	OUTP1?	

1

The output is currently on for channel 1.

Source Specific					
OUTPut[1]:LOAD Command					
Description	Sets or queries the output termination. Two impedance settings can be chosen, DEFault (50Ω) and INFinity (high impedance >10 kΩ). The output termination is to be used as a reference only. If the output termination is set 50Ωbut the actual load impedance is not 50Ω, then the amplitude and offset will not be correct.				
Note	If the amplitude has been set and the output termination is changed from 50Ω to high impedance, the amplitude will double. Changing the output termination from high impedance to 50Ω will half the amplitude. If the output termination is set to high impedance, dBm units cannot be used. The units will default to Vpp.				
Syntax	OUTPut[1]:LOAD {DEFault INFinity}				
Example	OUTP1:LOAD DEF Sets the output termination to 50Ω for channel 1.				
Query Syntax	OUTPut[1]:LOAD?				
Return Parameter	<table><tr><td>DEF</td><td>Default</td></tr><tr><td>INF</td><td>INFinity</td></tr></table>	DEF	Default	INF	INFinity
DEF	Default				
INF	INFinity				

Example

OUTP1:LOAD?

DEF

The output is set to the default of 50Ω for channel 1.

Source Specific Command

Description

This command turns waveform gating on or off for the selected channel's output. When gating is turned on, it allows the output signal to be output when the trigger input is asserted. It does not turn the output on, change the phase or other timing characteristics.

For example: When gating is turned on the waveform is output when the trigger signal goes high. When the trigger signal is low the waveform continues to be generated internally. The next time the trigger signal is high, the internally generated waveform is output at that particular point in time, instead of a newly generated waveform.

Syntax

OUTPut[1|2]:SYNC {OFF|ON}

Example

OUTP1:SYNC ON

Turns gating on for channel 1.

Query Syntax

OUTPut[1|2]:SYNC?

Return

1

ON

Parameter

0

OFF

Example

OUTP1:SYNC?


1

The sync output is enabled for channel 1.

Source Specific Command							
SOURce[1]:VOLTage:UNIT							
Description	Sets or queries the output amplitude units. There are three types of units: VPP, VRMS and DBM.						
Note	The units set with the VOLTage:UNIT command will be used as the default unit for all amplitude units unless a different unit is specifically used for a command. If the output termination is set to high impedance, dBm units cannot be used. The Units will automatically default to Vpp.						
Syntax	SOURce[1]:VOLTage:UNIT {VPP VRMS DBM}						
Example	SOUR1:VOLT:UNIT VPP Sets the amplitude units to Vpp for channel 1.						
Query Syntax	SOURce[1]:VOLTage:UNIT?						
Return Parameter	<table><tr><td>VPP</td><td>Vpp</td></tr><tr><td>VRMS</td><td>Vrms</td></tr><tr><td>DBM</td><td>dBm</td></tr></table>	VPP	Vpp	VRMS	Vrms	DBM	dBm
VPP	Vpp						
VRMS	Vrms						
DBM	dBm						
Example	SOUR1:VOLT:UNIT? VPP The amplitude units are set to Vpp.						

脉冲设置指令

The pulse chapter is used to control and output pulse waveforms. Unlike the APPLy command, low level control is possible including setting the rise time, fall time, period and pulse width.



Source Specific Command	
SOURce[1 2]:PULSe:WIDTh	
Description	Sets or queries the pulse width. The default pulse width is 500us. Pulse width is defined as the time from the rising to falling edges (at a threshold of 50%).
Note	The pulse width is restricted to the following limitations: $\text{Pulse Width} - 0.625 * [(\text{Rise Time} - 0.6\text{nS}) + (\text{Fall Time} - 0.6\text{nS})] \geq 0$ $\text{Period} \geq \text{Pulse Width} + 0.625 * [(\text{Rise Time} - 0.6\text{nS}) + (\text{Fall Time} - 0.6\text{nS})]$
Syntax	SOURce[1 2]:PULSe:WIDTh {<seconds> MINimum MAXimum}
Example	SOUR1:PULS:WIDT MAX Sets the pulse width to the maximum allowed.

Query Syntax	SOURce[1 2]:PULSe:WIDTh? [MINimum MAXimum]	
Return	<seconds>	20ns ~ 999.83ks
Parameter		
Example	SOUR1:PULS:WIDT? MIN +2.0000E-08 The pulse width is set to 20 nanoseconds.	
SOURce[1 2]:PULSe:DCYCLE		Source Specific Command
Description	Sets or queries the pulse duty cycle.	
Note	The duty cycle is limited by the rise/fall time as noted below: $Duty \geq 0.625 \times 100 \times [\text{rise time} - 0.6\text{ns} + \text{fall time} - 0.6\text{ns}] / \text{period}$ $Duty \leq 100 - \{62.5 \times [(\text{rise time} - 0.6\text{ns}) + (\text{fall time} - 0.6\text{ns})] / \text{period}\}$	
Syntax	SOURce[1 2]:PULSe:DCYCLE{<percent> MINimum MAXimum}	
Example	SOUR1:PULS:DCYC MAX Sets the duty to the maximum allowed.	
Query Syntax	SOURce[1 2]:PULSe:DCYCLE? [MINimum MAXimum]	
Return	<NR3>	0.0170%~99.983%
Parameter		Resolution 0.0001%
Example	SOUR1:PULS:DCYC?	

+1.0000E+01

The duty cycle is set to 10%

	Source Specific
SOURce[1 2]:PULSe:EDGEtime	Command

Description	Sets or queries the pulse edge time. The default edge time is 10us. This command will set the rise time = the fall time = edge time.	
Note	The edge time is limited by the pulse width as noted below: $\text{Pulse Width} - 0.625 * [(\text{Rise Time} - 0.6\text{nS}) + (\text{Fall Time} - 0.6\text{nS})] \geq 0$ $\text{Period} \geq \text{Pulse Width} + 0.625 * [(\text{Rise Time} - 0.6\text{nS}) + (\text{Fall Time} - 0.6\text{nS})]$	
Syntax	SOURce[1 2]:PULSe:EDGEtime{<seconds> MINimum MAXimum}	
Example	SOUR1:PULS:EDGE MAX Sets the edge time to the maximum allowed.	
Query Syntax	SOURce[1 2]:PULSe:EDGEtime? [MINimum MAXimum]	
Return Parameter	<NR3>	9.32ns ~ 799.9ks
Example	SOUR1:PULS:EDGE? MIN +9.3200E-09 The edge time is 9.32 nanoseconds.	

Source Specific Command	
SOURce[1 2]:PULSe:RISE	
Description	Sets or queries the pulse rise time. The default rise time is 10us. The rise and fall time can be different.Range: 9.32ns~ 799.9ks
Note	The rise time is limited by the pulse width, period and fall time as noted below: Pulse Width - 0.625 * [(Rise Time - 0.6nS) + (Fall Time - 0.6nS)] ≥ 0 Period ≥ Pulse Width+ 0.625 * [(Rise Time - 0.6nS)+(Fall Time - 0.6nS)]
Syntax	SOURce[1 2]:PULSe:RISE{<seconds> MINimum MAXimum}
Example	SOUR1:PULS:RISE MAX Sets the rise time to the maximum allowed.
Query Syntax	SOURce[1 2]:PULSe:RISE? [MINimum MAXimum]
Return Parameter	<NR3> 9.32ns ~ 799.9ks
Example	SOUR1:PULS:FALL? MIN +9.3200E-09 The minimum rise time is 9.32 nanoseconds.

SOURce[1 2]:PULSe:FALL		Source Specific Command
Description	Sets or queries the pulse fall time. The default fall time is 10us. The rise and fall time can be different. Range: 9.32ns ~ 799.9ks	
Note	The fall time is limited by the pulse width, period and rise time as noted below: Pulse Width - 0.625 * [(Rise Time - 0.6nS) + (Fall Time - 0.6nS)] ≥ 0 Period ≥ Pulse Width+ 0.625 * [(Rise Time - 0.6nS)+(Fall Time - 0.6nS)]	
Syntax	SOURce[1 2]:PULSe:FALL{<seconds> MINimum MAXimum}	
Example	SOUR1:PULS:FALL MAX Sets the fall time to the maximum allowed.	
Query Syntax	SOURce[1 2]:PULSe:FALL? [MINimum MAXimum]	
Return Parameter	<NR3>	9.32ns ~ 799.9ks
Example	SOUR1:PULS:FALL? MIN +9.3200E-09 The minimum fall time is 9.32 nanoseconds.	

谐波指令

SOURce[1 2]:HARMonic:TOTAL		Source Specific Command
Description	Sets the highest order harmonic for the harmonic output. By default this is set to 2.	
Syntax	SOURce[1 2]:HARMonic:TOTAL{<id> MINimum MAXimum}	
Example	SOUR1:HARMonic:TOTAL MAX Sets the highest order harmonic to the maximum allowed.	
Query Syntax	SOURce[1 2]:HARMonic:TOTAL?[MINimum MAXimum]	
Return Parameter	<NR1>	2 ~ 8
Example	SOUR1:HARM:? MIN 2 Returns the minimum harmonic.	

SOURce[1 2]:HARMonic:TYPE		Source Specific Command
Description	Specifies which harmonics are output; odd, even, all or user specified.	
Syntax	SOURce[1 2]:HARMonic:TYPE {EVEN ODD ALL USER,10000001}	

Parameter/ Return Parameter	<EVEN>	Output all even orders
	<ODD>	Output all odd orders
	<ALL>	Output all orders, subject to the number specified in "SOURce[1 2]:HARMonic: TOTAL" command.
	<USER, X ¹ X ² X ³ X ⁴ X ⁵ X ⁶ X ⁷ X ⁸ >	Outputs only the specified orders, where X = Boolean (0, 1) X ^X = order number.

Example	SOURce1:HARMonic:TYPE USER,11000001 Outputs only the 2 nd and 8 th harmonic. (1 st harmonic is the fundamental frequency)
---------	--

Query Syntax	SOURce[1 2]:HARMonic:TYPE?
--------------	-----------------------------------

Example	SOUR1:HARM:TYPE? EVEN 11000000 Returns EVEN harmonic (Limited to the 2 nd harmonic).
---------	--

	Source Specific
SOURce[1 2]:HARMonic:ORDER	Command

Description	Sets or queries the amplitude and phase of each order. By default, each order is set to 3V _{pp} , with a phase of 0°.
-------------	--

Syntax	SOURce[1 2]:HARMonic:ORDER {<id>,<amplitude>,<phase>}	
Parameter/ Return Parameter	<id>	<NR1>Order number: 2 ~ 8
	<amplitude>	<NR3>Amplitude of the selected order: 1mV ~ 10V (50ohm impedance)
	<phase>	<NR3>Phase: -360 ~ -360°
Example	SOURce1:HARMonic:ORDER 2,3.0,180 Sets the 2 nd harmonic to 3.0Vpp and a phase of 180°.	
Query Syntax	SOURce[1 2]:HARMonic:ORDER? <id> Returns the <id>,<amplitude>,<phase>.	
Example	SOUR1:HARM:ORDE? 2 2;,3.000E+00,1.800E+02 Returns the 2 nd harmonic settings as 3Vpp with a phase of 180°.	
SOURce[1 2]:HARMonic:DISPlay		Source Specific Command
Description	Sets or queries whether the screen shows the harmonics in the frequency or time domain. The default setting is time domain.	


Syntax	SOURce[1 2]:HARMonic:DISPlay {FREQuency TIME}	
Parameter/ Return	FREQuency	Sets the display to frequency
Parameter	TIME	Sets the display to time
Example	SOURce1:HARMonic:DISPlay TIME Sets the display to TIME.	
Query Syntax	SOURce[1 2]:HARMonic:DISPlay? Returns TIME or FREQ.	
Example	SOUR1:HARM:DISP? TIME Returns the display format as TIME.	

幅值调制 (AM)指令

AM 介绍

To successfully create an AM waveform, the following commands must be executed in order.

- | | |
|--------------------------------|---|
| Enable AM
Modulation | 1. Turn on AM modulation using the
SOURce[1 2]: AM:STAT ON command |
| ↓ | |
| Configure
Carrier | 2. Use the APPLy command to select a carrier
waveform. Alternatively the equivalent FREQ,
AMPL, and DCOffs commands can be used to
create a carrier waveform with a designated
frequency, amplitude and offset. |
| ↓ | |
| Select
Modulation
Source | 3. Select an internal or external modulation source
using the SOURce[1 2]: AM:MOD:INP
command. |
| ↓ | |
| Select Shape | 4. Use the SOURce[1 2]: AM:INT:FUNC
command to select a sine, square, upramp,
dnramp or triangle modulating waveshape. For
internal sources only. |
| | 5. Set the modulating frequency using the
SOURce[1 2]: AM:INT:FREQ command. For
internal sources only. |



6. Set the modulation depth using the SOURce[1 | 2]: AM:DEPT command.

Source Specific Command	
SOURce[1 2]:AM:STATe	
Description	Sets or disables AM modulation for the selected channel. By default AM modulation is disabled. AM modulation must be enabled before setting other parameters.
Note	Burst or sweep mode will be disabled if AM modulation is enabled on the same channel. As only one modulation is allowed on a channel at any one time, other modulation modes will be disabled when AM modulation is enabled.
Syntax	SOURce[1 2]:AM:STATe {OFF ON}
Example	SOUR1:AM:STAT ON Enables AM modulation.
Query Syntax	SOURce[1 2]:AM:STATe?
Return Parameter	0 Disabled (OFF)
	1 Enabled (ON)

Example	SOUR1:AM:STAT?	
	1	
	AM modulation mode is currently enabled.	
		Source Specific
	SOURce[1 2]:AM:MODulation:INPut	Command
Description	Sets or queries the modulation source as internal or external for the selected channel. Internal is the default modulation source.	
Note	If an external modulation source is selected, modulation depth is limited to $\pm 5V$ from the MOD INPUT terminal on the rear panel. For example, if modulation depth is set to 100%, then the maximum amplitude is +5V, and the minimum amplitude is -5V.	
Syntax	SOURce[1 2]:AM:MODulation:INPut {INTernal EXTernal}	
Example	SOUR1:AM:MOD:INP EXT	
	Sets the modulation source to external.	
Query Syntax	SOURce[1 2]:AM:MODulation:INPut?	
Return Parameter	INT	Internal
	EXT	External
Example	SOUR1:AM:MOD:INP?	
	INT	
	The modulation source is set to internal.	

Source Specific Command	
SOURce[1 2]:AM:INTernal:FUNCTion	
Description	Sets the shape of the modulating waveform from sine, square, triangle, upramp and dnramp for the selected channel. The default shape is sine.
Note	Square and triangle waveforms have a 50% duty cycle. Upramp and dnramp have a symmetry of 100% and 0%, respectively.
Syntax	SOURce[1 2]:AM:INTernal:FUNCTion {SINusoid SQUare TRIangle UPRamp DNRamp}
Example	SOUR1:AM:INT:FUNC SIN Sets the AM modulating wave shape to sine.
Query Syntax	SOURce[1 2]:AM:INTernal:FUNCTion?
Return Parameter	SIN Sine UPRAMP Upramp
	SQU Square DNRAMP Dnramp
	TRI Triangle
Example	SOUR1:AM:INT:FUNC? SIN The shape for the modulating waveform is Sine.

Source Specific Command	
SOURce[1 2]:AM:INTernal:FREQuency	
Description	Sets the frequency of the internal modulating waveform only for the selected channel. The default frequency is 100Hz.

Syntax	SOURce[1 2]:AM:INTernal:FREQuency {<frequency> MINimum MAXimum}	
Parameter	<frequency>	2mHz~ 20kHz
Example	SOUR1:AM:INT:FREQ +1.0000E+02 Sets the modulating frequency to 100Hz.	
Query Syntax	SOURce[1 2]:AM:INTernal:FREQuency? [MINimum MAXimum]	
Return Parameter	<NR3>	Returns the frequency in Hz.
Example	SOUR1:AM:INT:FREQ? MIN +1.0000E+02 Returns the minimum frequency allowed.	

SOURce[1 2]:AM:DEPTh	Source Specific Command
----------------------	----------------------------


Description	Sets or queries the modulation depth for internal sources only for the selected channel. The default is 100%.	
Note	The function generator will not output more than $\pm 5V$, regardless of the modulation depth. The modulation depth of an external source is controlled using the $\pm 5V$ MOD INPUT terminal on the rear panel, and not the SOURce[1]:AM:DEPTh command.	
Syntax	SOURce[1 2]:AM:DEPTh {<depth in percent> MINimum MAXimum}	
Parameter	<depth in percent>	0~120%


Example	SOUR1:AM:DEPT50 Sets the modulation depth to 50%.	
Query Syntax	SOURce[1 2]:AM:DEPTH? [MINimum MAXimum]	
Return Parameter	<NR3>	Return the modulation depth as a percentage.
Example	SOUR1:AM:DEPT? +1.0000E+02 The modulation depth is 100%.	

频率调制 (FM)指令

FM 介绍

The following is an overview of the steps required to generate an FM waveform.





6. Use the SOURce[1 | 2]:FM:DEV command to set the frequency deviation.

Source Specific Command	
SOURce[1 2]:FM:STATe	
Description	Sets or disables FM modulation for the selected channel. By default FM modulation is disabled. FM modulation must be enabled before setting other parameters.
Note	Burst or sweep mode will be disabled if FM modulation is enabled on the same channel. As only one modulation is allowed at any one time on the same channel, other modulation modes will be disabled when FM modulation is enabled.
Syntax	SOUR[1 2]:FM:STATe {OFF ON}
Example	SOUR1:FM:STAT ON Enables FM modulation.
Query Syntax	SOURce[1 2]:FM:STATe?
Return Parameter	0 Disabled (OFF)
	1 Enabled (ON)

Example	SOUR1:FM:STAT? 1 FM modulation mode is currently enabled.	
	SOURce[1 2]:FM:MODulation:INPut	Source Specific Command
Description	Sets or queries the modulation source as internal or external for the selected channel. Internal is the default modulation source.	
Note	If an external modulation source is selected, modulation depth is limited to $\pm 5V$ from the MOD INPUT terminal on the rear panel. For example, if modulation depth is set to 100%, then the maximum amplitude is +5V, and the minimum amplitude is -5V.	
Syntax	SOURce[1 2]:FM:MODulation:INPut {INTernal EXTernal}	
Example	SOUR1:FM:MOD:INP EXT Sets the modulation source to external.	
Query Syntax	SOURce[1 2]:FM:MODulation:INPut?	
Return Parameter	INT	Internal
	EXT	External
Example	SOUR1:FM:MOD:INP INT The modulation source is set to internal.	

SOURce[1 2]:FM:INTernal:FUNCtion		Source Specific Command		
Description	Sets the shape of the modulating waveform from sine, square, triangle, upramp and dnramp for the selected channel. The default shape is sine.			
Note	Square and triangle waveforms have a 50% duty cycle. Upramp and dnramp have a symmetry of 100% and 0%, respectively.			
Syntax	SOURce[1 2]:FM:INTernal:FUNCtion {SINusoid SQUare TRIangle UPRamp DNRamp}			
Example	SOUR1:FM:INT:FUNC SIN Sets the FM modulating wave shape to sine.			
Query Syntax	SOURce[1 2]:FM:INTernal:FUNCtion?			
Return Parameter	SIN	Sine	UPRAMP	Upramp
	SQU	Square	DNRAMP	Dnramp
	TRI	Triangle		
Example	SOUR1:FM:INT:FUNC? SIN The shape for the modulating waveform is Sine.			

SOURce[1 2]:FM:INTernal:FREQuency		Source Specific Command
Description	Sets the frequency of the internal modulating waveform only for the selected channel. The default frequency is 10Hz.	
Syntax	SOURce[1 2]:FM:INTernal:FREQuency {<frequency> MINimum MAXimum}	
Parameter	<frequency>	2mHz~ 20kHz
Example	SOUR1:FM:INT:FREQ +1.0000E+02 Sets the modulating frequency to 100Hz.	
Query Syntax	SOURce[1 2]:FM:INTernal:FREQuency? [MINimum MAXimum]	
Return Parameter	<NR3>	Returns the frequency in Hz.
Example	SOUR1:FM:INT:FREQ? MAX +2.0000E+04 Returns the maximum frequency allowed.	
SOURce[1 2]:FM:DEVIation		Source Specific Command


Description	Sets or queries the peak frequency deviation of the modulating waveform from the carrier waveform for the selected channel. The default peak deviation is 100Hz. The frequency deviation of external sources is controlled using the $\pm 5V$ MOD INPUT terminal on the rear panel. A positive signal ($>0 \sim +5V$) will increase the deviation (up to the set frequency deviation), whilst a negative voltage will reduce the deviation.
Note	The relationship of peak deviation to modulating frequency and carrier frequency is shown below. Peak deviation = modulating frequency - carrier frequency. The carrier frequency must be greater than or equal to the peak deviation frequency. The sum of the deviation and carrier frequency must not exceed the maximum frequency for a specific carrier shape. If an out of range deviation is set for any of the above conditions, the deviation will be automatically adjusted to the maximum value allowed and an "out of range" error will be generated. For square wave carrier waveforms, the deviation may cause the duty cycle frequency boundary to be exceeded. In these conditions the duty cycle will be adjusted to the maximum allowed and a "settings conflict" error will be generated.
Syntax	SOURce[1 2]:FM:DEViation {<peak deviation in Hz> MINimum MAXimum}

Parameter	<peak deviation in Hz>	DC~30MHz (20MHz AFG-3021/3022) DC~1MHz (Ramp)
Example	SOUR1:FM:DEV MAX Sets the frequency deviation to the maximum value allowed.	
Query Syntax	SOURce[1 2]:FM:DEViation? [MINimum MAXimum]	
Return Parameter	<NR3>	Returns the frequency deviation in Hz.
Example	SOURce1:FM:DEViation? MAX +2.0000E+04 The maximum frequency deviation for the current function is 20MHz.	

频移键控 (FSK)指令

FSK 介绍

The following is an overview of the steps required to generate an FSK modulated waveform.



	Source Specific
SOURce[1 2]:FSKey:STATe	Command

Description	Turns FSK Modulation on or off for the selected channel. By default FSK modulation is off.	
Note	Burst or sweep mode will be disabled if FSK modulation is enabled on the same channel. As only one modulation is allowed at any one time on the same channel, other modulation modes will be disabled when FSK modulation is enabled.	
Syntax	SOURce[1 2]:FSKey:STATe {OFF ON}	
Example	SOUR1:FSK:STAT ON Enables FSK modulation	
Query Syntax	SOURce[1 2]:FSKey:STATe?	
Return Parameter	0	Disabled (OFF)
	1	Enabled (ON)
Example	SOUR1:FSK:STAT? ON FSK modulation is currently enabled.	

Source Specific

SOURce[1|2]:FSKey:MODulation:INPut

Command

Description	Sets or queries the FSK source as internal or external for the selected channel. Internal is the default source.	
Note	If an external FSK source is selected, FSK rate is controlled by the Trigger INPUT terminal on the rear panel.	
Syntax	SOURce[1 2]:FSKey:MODulation:INPut {INTernal EXTernal}	

Example	SOUR1:FSK:MOD:INP EXT Sets the FSK source to external.	
Query Syntax	SOURce[1 2]:FSKey:MOD:INP?	
Return Parameter	INT	Internal
	EXT	External
Example	SOUR1:FSK:MOD:INP? INT The FSK source is set to internal.	

SOURce[1 2]:FSKey:FREQuency		Source Specific Command
Description	Sets the FSK hop frequency. The default hop frequency is set to 100Hz.	
Note	For FSK, the modulating waveform is a square wave with a duty cycle of 50%.	
Syntax	SOURce[1 2]:FSKey:FREQuency { <frequency> MINimum MAXimum}	
Parameter	<frequency>	1μHz~30MHz (20MHZ AFG-3021/3022)
Example	SOUR1:FSK:FREQ +1.0000E+02 Sets the FSK hop frequency to 100Hz.	
Query Syntax	SOURce[1 2]:FSKey:FREQuency? [MINimum MAXimum]	

Return	<NR3>	Returns the frequency in
Parameter		Hz.

Example **SOUR1:FSK:FREQ? MAX**

+8.00000E+07

Returns the maximum hop frequency allowed.

SOURCE[1 2]:FSKey:INTERNAL:RATE	Source Specific Command
---------------------------------	-------------------------

Description	Sets or queries the FSK rate for internal sources only.
-------------	---

Note External sources will ignore this command.

Syntax **SOURce[1|2]:FSKey:INternal:RATE {<rate in Hz> |MINimum|MAXimum}**

Parameter	<rate in Hz>	2 mHz~100 kHz
-----------	--------------	---------------

Example **SOUR1:FSK:INT:RATE MAX**

Sets the rate to the maximum (100kHz).

Query Syntax **SOURce[1|2]:FSKey:INternal:RATE?**
[MINimum|MAXimum]

Return	<NR3>	Returns the FSK rate in
Parameter		Hz.

Example **SOUR1:FSK:INT:RATE? MAX**


+1.0000E+05

Returns the maximum FSK rate allowed.

相位调制 (PM) 指令

PM 介绍

The following is an overview of the steps required to generate a PM waveform.



SOURce[1 2]:PM:STATe		Source Specific Command
Description	Sets or disables PM modulation for the selected channel. By default PM modulation is disabled. PM modulation must be enabled before setting other parameters.	
Note	Burst or sweep mode will be disabled if PM modulation is enabled on the same channel. As only one modulation is allowed at any one time on the same channel, other modulation modes will be disabled when PM modulation is enabled.	
Syntax	SOUR[1 2]:PM:STATe {OFF ON}	
Example	SOUR1:PM:STAT ON Enables PM modulation.	
Query Syntax	SOURce[1 2]:PM:STATe?	
Return Parameter	0	Disabled (OFF)
	1	Enabled (ON)
Example	SOUR1:PM:STAT? 1 PM modulation mode is currently enabled.	
SOURce[1 2]:PM:INTernal:FUNCTion		Source Specific Command
Description	Sets the shape of the modulating waveform from sine, square, triangle, upramp and dn ramp for the selected channel. The default shape is sine.	

Note Square and triangle waveforms have a 50% duty cycle. Upramp and dn ramp have a symmetry of 100% and 0%, respectively.

Syntax **SOURce[1|2]:PM:INTernal:FUNction**
{SINusoid|SQUare|TRIangle|UPRamp|DNRamp}

Example **SOUR1:PM:INT:FUNC SIN**
Sets the PM modulating wave shape to sine.

Query Syntax **SOURce[1|2]:PM:INTernal:FUNCTION?**

Return Parameter	SIN	Sine	UPRAMP	Upramp
	SQU	Square	DNRAMP	Dn ramp
	TRI	Triangle		

Example **SOUR1:PM:INT:FUNC?**
SIN
The shape for the modulating waveform is Sine.

SOURce[1|2]:PM:INTernal:FREQuency Source Specific Command

Description Sets the phase modulation frequency for the selected channel. The default frequency is 100Hz.

Syntax **SOURce[1|2]:PM:INTernal:FREQuency**
{<frequency>|MINimum|MAXimum}

Parameter <frequency> 2mHz~ 20kHz

Example **SOUR1:PM:INT:FREQ +1.0000E+02**
Sets the phase modulation frequency to 100Hz.

Query Syntax	SOURce[1 2]:PM:INTernal:FREQuency? [MINimum MAXimum]	
Return Parameter	<NR3>	Returns the frequency in Hz.
Example	SOUR1:PM:INT:FREQ? MAX +2.0000E+04 Returns the maximum frequency allowed.	
SOURce[1 2]:PM:DEVIation		Source Specific Command
Description	Sets or queries the peak phase deviation of the modulating waveform from the carrier waveform for the selected channel. The default peak deviation is 180.0°.	
Syntax	SOURce[1 2]:PM:DEVIation {<peak deviation in degrees> MINimum MAXimum}	
Parameter	<peak deviation in degrees>	0° ~ 360°
Example	SOUR1:PM:DEV MAX Sets the phase deviation to 360°.	
Query Syntax	SOURce[1 2]:PM:DEVIation? [MINimum MAXimum]	
Return Parameter	<NR3>	Returns the phase deviation in degrees.

Example

SOURce1:PM:DEViation? MAX


+3.600E+02


The maximum phase deviation is 360°.

SUM 指令

SUM 介绍

The following is an overview of the steps required to generate a SUM waveform.

- 
- ```
graph TD; A[Enable SUM Modulation] --> B[Configure Carrier]; B --> C[Select Modulation Source]; C --> D[Select shape];
```
1. Turn on SUM modulation using the `SOURce[1 | 2]:SUM:STATe ON` command.
  2. Use the `APPLy` command to select a carrier waveform. Alternatively, the `FREQ`, `AMPL`, and `DCOffs` commands can be used to create a carrier waveform with a designated frequency, amplitude and offset.
  3. Select an internal or external modulation source using the `SOURce[1 | 2]:SUM:MOD:INP` command.
  4. Use the `SOURce[1 | 2]:SUM:INT:FUNCTion` command to select a sine, square, upramp, dn ramp or triangle modulating waveshape. For internal sources only.
  5. Set the SUM frequency using the `SOURce[1 | 2]:SUM:INT:FREQuency` command. For internal sources only.



| Source Specific Command |                                                                                                                                                                                                                                       |
|-------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Description             | Sets or disables SUM modulation for the selected channel. By default SUM modulation is disabled. SUM modulation must be enabled before setting other parameters.                                                                      |
| Note                    | Burst or sweep mode will be disabled if SUM modulation is enabled on the same channel. As only one modulation is allowed at any one time on the same channel, other modulation modes will be disabled when SUM modulation is enabled. |
| Syntax                  | <b>SOUR[1 2]:SUM:STATe {OFF ON}</b>                                                                                                                                                                                                   |
| Example                 | <b>SOUR1:SUM:STAT ON</b><br>Enables SUM modulation.                                                                                                                                                                                   |
| Query Syntax            | <b>SOURce[1 2]:SUM:STATe?</b>                                                                                                                                                                                                         |
| Return Parameter        | 0 Disabled (OFF)                                                                                                                                                                                                                      |
|                         | 1 Enabled (ON)                                                                                                                                                                                                                        |



|              |                                                                                                                                                                                                                                                          |                 |
|--------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| Example      | <b>SOUR1:SUM:STAT?</b>                                                                                                                                                                                                                                   |                 |
|              | <b>1</b>                                                                                                                                                                                                                                                 |                 |
|              | SUM modulation mode is currently enabled.                                                                                                                                                                                                                |                 |
|              |                                                                                                                                                                                                                                                          | Source Specific |
|              | <b>SOURce[1 2]:SUM:MODulation:INPut</b>                                                                                                                                                                                                                  | Command         |
| Description  | Sets or queries the modulation source as internal or external for the selected channel. Internal is the default modulation source.                                                                                                                       |                 |
| Note         | If an external modulation source is selected, the SUM amplitude is limited to $\pm 5V$ from the MOD INPUT terminal on the rear panel. For example, if SUM amplitude is set to 100%, then the maximum amplitude is +5V, and the minimum amplitude is -5V. |                 |
| Syntax       | <b>SOURce[1 2]:SUM:MODulation:INPut {INTernal EXTernal}</b>                                                                                                                                                                                              |                 |
| Example      | <b>SOUR1:SUM:MOD:INP EXT</b>                                                                                                                                                                                                                             |                 |
|              | Sets the modulation source to external.                                                                                                                                                                                                                  |                 |
| Query Syntax | <b>SOURce[1 2]:SUM:MODulation:INPut?</b>                                                                                                                                                                                                                 |                 |
| Return       | INT                                                                                                                                                                                                                                                      | Internal        |
| Parameter    | EXT                                                                                                                                                                                                                                                      | External        |
| Example      | <b>SOUR1:SUM:MOD:INP?</b>                                                                                                                                                                                                                                |                 |
|              | <b>INT</b>                                                                                                                                                                                                                                               |                 |
|              | The modulation source is set to internal.                                                                                                                                                                                                                |                 |

| SOURce[1 2]:SUM:INteRnal:FUNCTion |                                                                                                                                               | Source Specific Command |        |        |
|-----------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|-------------------------|--------|--------|
| Description                       | Sets the shape of the modulating waveform from sine, square, triangle, upramp and dnramp for the selected channel. The default shape is sine. |                         |        |        |
| Note                              | Square and triangle waveforms have a 50% duty cycle. Upramp and dnramp have a symmetry of 100% and 0%, respectively.                          |                         |        |        |
| Syntax                            | SOURce[1 2]:SUM:INteRnal:FUNCTion {SINusoid SQUare TRIangle UPRamp DNRamp}                                                                    |                         |        |        |
| Example                           | SOUR1:SUM:INT:FUNC SIN<br>Sets the SUM modulating wave shape to sine.                                                                         |                         |        |        |
| Query Syntax                      | SOURce[1 2]:SUM:INteRnal:FUNCTion?                                                                                                            |                         |        |        |
| Return Parameter                  | SIN                                                                                                                                           | Sine                    | UPRAMP | Upramp |
|                                   | SQU                                                                                                                                           | Square                  | DNRAMP | Dnramp |
|                                   | TRI                                                                                                                                           | Triangle                |        |        |
| Example                           | SOUR1:SUM:INT:FUNC?<br><br>SIN<br><br>The shape for the modulating waveform is Sine.                                                          |                         |        |        |

|                                    |                                                                                                                                 | Source Specific              |
|------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|------------------------------|
| SOURce[1 2]:SUM:INTernal:FREQuency |                                                                                                                                 | Command                      |
| Description                        | Sets the frequency (SUM frequency) of the internal modulating waveform for the selected channel. The default frequency is 10Hz. |                              |
| Syntax                             | <b>SOURce[1 2]:SUM:INTernal:FREQuency {&lt;frequency&gt; MINimum MAXimum}</b>                                                   |                              |
| Parameter                          | <frequency>                                                                                                                     | 2mHz~ 20kHz                  |
| Example                            | <b>SOUR1:SUM:INT:FREQ +1.0000E+02</b><br>Sets the modulating frequency to 100Hz.                                                |                              |
| Query Syntax                       | <b>SOURce[1 2]:SUM:INTernal:FREQuency? [MINimum MAXimum]</b>                                                                    |                              |
| Return Parameter                   | <NR3>                                                                                                                           | Returns the frequency in Hz. |
| Example                            | <b>SOUR1:SUM:INT:FREQ? MAX</b><br><b>+2.0000E+04</b><br>Returns the maximum frequency allowed.                                  |                              |

|                           |                                                                                                                              | Source Specific |
|---------------------------|------------------------------------------------------------------------------------------------------------------------------|-----------------|
| SOURce[1 2]:SUM:AMPLitude |                                                                                                                              | Command         |
| Description               | The SUM amplitude command sets or queries the amplitude of the modulating waveform as a percentage of the carrier amplitude. |                 |
| Syntax                    | <b>SOURce[1 2]:SUM:AMPLitude {&lt;amplitude percent&gt; MINimum MAXimum}</b>                                                 |                 |


|                     |                                                                            |                                |
|---------------------|----------------------------------------------------------------------------|--------------------------------|
| Parameter           | <amplitude percent>                                                        | 0% ~ 100%                      |
| Example             | <b>SOUR1:SUM:AMPL MAX</b><br>Sets the SUM amplitude to 100%.               |                                |
| Query Syntax        | <b>SOURce[1 2]:SUM:AMPLitude?</b>                                          |                                |
| Return<br>Parameter | <NR3>                                                                      | Returns the amplitude<br>in %. |
| Example             | <b>SOUR1:SUM:AMPL?</b><br><b>+1.0000E+02</b><br>The SUM amplitude is 100%. |                                |


## 脉冲宽度调制 (PWM) 指令

### PWM 介绍

---

The following is an overview of the steps required to generate a PWM modulated waveform.

- 
- Enable PWM Modulation
- ↓
- Configure Carrier
- ↓
- Select Modulation Source
- ↓
- Select Shape
1. Turn on PWM modulation using the `SOURce[1 | 2]: PWM:STATe ON` command.
  2. Use the `APPLy` command to select a pulse waveform. Alternatively, the `FREQ`, `AMPL`, and `DCOffs` commands can be used to create a pulse waveform with a designated frequency, amplitude and offset.
  3. Select an internal or external modulation source using the `SOURce[1 | 2]: PWM:MOD:INP` command.
  4. Use the `SOURce[1 | 2]: PWM:INT:FUNC` command to select a sine, square, upramp, dn ramp or triangle modulating waveshape. For internal sources only.
  5. Set the modulating frequency using the `SOURce[1 | 2]: PWM:INT:FREQ` command. For internal sources only.



| SOURce[1 2]:PWM:STATe |                                                                                                                                                                                                                                       | Source Specific Command |
|-----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------|
| Description           | Turns FSK Modulation on or off. By default FSK modulation is off.                                                                                                                                                                     |                         |
| Note                  | Burst or sweep mode will be disabled if PWM modulation is enabled on the same channel. As only one modulation is allowed at any one time, other modulation modes will be disabled when FSK modulation is enabled on the same channel. |                         |
| Syntax                | <b>SOURce[1 2]:PWM:STATe {OFF ON}</b>                                                                                                                                                                                                 |                         |
| Example               | <b>SOUR1:PWM:STAT ON</b><br>Enables PWM modulation                                                                                                                                                                                    |                         |
| Query Syntax          | <b>SOURce[1 2]:PWM:STATe?</b>                                                                                                                                                                                                         |                         |
| Return Parameter      | 0                                                                                                                                                                                                                                     | Disabled (OFF)          |
|                       | 1                                                                                                                                                                                                                                     | Enabled (ON)            |

Example                   **SOUR1:PWM:STAT?**

**ON**

                             FSK modulation is currently enabled.

Source Specific  
SOURce[1|2]:PWM:MODulation:INPut      Command

Description            Sets or queries the PWM source as internal or external. Internal is the default source.

Note                    If an external PWMsource is selected, the duty cycle/pulse width is controlled by the MOD INPUT terminal on the rear panel.

Syntax                 **SOURce[1|2]:PWM:MODulation:INPut**  
                             **{INTernal|EXTernal}**

Example                **SOUR1:PWM:MOD:INP EXT**

                             Sets the PWM source to external.

Query Syntax          **SOURce[1|2]:PWM:MODulation:INPut?**

|           |     |          |
|-----------|-----|----------|
| Return    | INT | Internal |
| Parameter | EXT | External |

Example                **SOUR1:PWM:MOD:INP?**

**INT**

                             The PWM source is set to internal.

Source Specific  
SOURce[1|2]:PWM:INTernal:FUNction      Command

|                  |                                                                                                                                                                      |          |        |        |
|------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|--------|--------|
| Description      | Sets the shape of the modulating waveform from sine, square, triangle, upramp and dnramp. The default shape is sine.                                                 |          |        |        |
| Note             | Square and triangle waveforms have a 50% duty cycle. Upramp and dnramp have a symmetry to 100% and 0%, respectively.<br><br>Carrier must be a pulse or PWM waveform. |          |        |        |
| Syntax           | <b>SOURce[1 2]:PWM:INTernal:FUNction</b><br><b>{SINusoid SQUare TRIangle UPRamp DNRamp}</b>                                                                          |          |        |        |
| Example          | <b>SOUR1:PWM:INT:FUN SIN</b><br><br>Sets the PWM modulating wave shape to sine. .                                                                                    |          |        |        |
| Query Syntax     | <b>SOURce[1 2]:PWM:INTernal:FUNction?</b>                                                                                                                            |          |        |        |
| Return Parameter | SIN                                                                                                                                                                  | Sine     | UPRAMP | Upramp |
|                  | SQU                                                                                                                                                                  | Square   | DNRAMP | Dnramp |
|                  | TRI                                                                                                                                                                  | Triangle |        |        |

Example                   **SOUR1:PWM:INT:FUNC?**  
  
                             **SIN**  
  
                             The shape for the modulating waveform is Sine.

Source Specific

SOURce[1|2]:PWM:INTernal:FREQuency    Command

|             |                                                                                                    |  |  |  |
|-------------|----------------------------------------------------------------------------------------------------|--|--|--|
| Description | Sets the modulating waveform frequency for internal sources. The default frequency is set to 10Hz. |  |  |  |
| Syntax      | <b>SOURce[1 2]:PWM:INTernal:FREQuency</b><br><b>{&lt;frequency&gt; MINimum MAXimum}</b>            |  |  |  |



|                      |                                                                                                                                                                                                                                                                                                                                                               |                              |
|----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|
| Parameter            | <frequency>                                                                                                                                                                                                                                                                                                                                                   | 2 mHz~ 20 kHz                |
| Example              | <b>SOUR1:PWM:INT:FREQ MAX</b><br>Sets the frequency to the maximum value.                                                                                                                                                                                                                                                                                     |                              |
| Query Syntax         | <b>SOURce[1 2]:PWM:INTernal:FREQuency?</b>                                                                                                                                                                                                                                                                                                                    |                              |
| Return Parameter     | <NR3>                                                                                                                                                                                                                                                                                                                                                         | Returns the frequency in Hz. |
| Example              | <b>SOUR1:PWM:INT:FREQ? MAX</b><br><b>+2.0000E+04</b><br>Returns the modulating frequency. (20kHz)                                                                                                                                                                                                                                                             |                              |
| SOURce[1 2]:PWM:DUTY |                                                                                                                                                                                                                                                                                                                                                               | Source Specific Command      |
| Description          | Sets or queries the duty cycle deviation. The default duty cycle is 50%.                                                                                                                                                                                                                                                                                      |                              |
| Note                 | The duty cycle is limited by period, edge time and minimum pulse width.<br><br>The duty cycle deviation of an external source is controlled using the $\pm 5V$ MOD INPUT terminal on the rear panel. A positive signal ( $>0\sim+5V$ ) will increase the deviation (up to the set duty cycle deviation), whilst a negative voltage will reduce the deviation. |                              |
| Syntax               | <b>SOURce[1 2]:PWM:DUTY {&lt; percent&gt; minimum  maximum}</b>                                                                                                                                                                                                                                                                                               |                              |
| Parameter            | <percent>                                                                                                                                                                                                                                                                                                                                                     | 0%~100% (limited, see above) |
| Example              | <b>SOUR1:PWM:DUTY +3.0000E+01</b>                                                                                                                                                                                                                                                                                                                             |                              |

Sets the duty cycle to 30%.


|                  |                              |                       |
|------------------|------------------------------|-----------------------|
| Query Syntax     | <b>SOURce[1 2]:PWM:DUTY?</b> |                       |
| Return Parameter | <NR3>                        | Returns the dutyin %. |

Example           **SOUR1:PWM:DUTY?**  
  
                      **+ 3.0000E+01**  
  
                      The current duty cycle is 30%.

# 频率扫描指令

## 扫描介绍

Below shows the order in which commands must be executed to perform a sweep.



4. Choose Linear or Logarithmic spacing using the SOURce[1 | 2]:SWE:FUNC command.



Select Sweep  
↓  
Mode

Select Sweep  
↓  
Time

↓  
Select the  
sweep trigger  
source

5. Choose the sweep time using the SOURce[1 | 2]:SWE:TIME command.
6. Select an internal or external sweep trigger source using the SOURce[1 | 2]:TRIG command.

|                         |                 |
|-------------------------|-----------------|
|                         | Source Specific |
| SOURce[1 2]:SWEep:STATe | Command         |

|             |                                                            |
|-------------|------------------------------------------------------------|
| Description | Sets or disables Sweep mode. By default Sweep is disabled. |
|-------------|------------------------------------------------------------|

|              |                                                                                                   |                |
|--------------|---------------------------------------------------------------------------------------------------|----------------|
| Note         | Any modulation modes or Burst mode will be disabled if sweep mode is enabled on the same channel. |                |
| Syntax       | <b>SOURce[1 2]:SWEep:STATe {OFF ON}</b>                                                           |                |
| Example      | <b>SOUR1:SWE:STAT ON</b><br>Enables sweep mode.                                                   |                |
| Query Syntax | <b>SOURce[1 2]:SWEep:STATe?</b>                                                                   |                |
| Return       | 0                                                                                                 | Disabled (OFF) |
| Parameter    |                                                                                                   |                |
|              | 1                                                                                                 | Enabled (ON)   |
| Example      | <b>SOUR1:SWE:STAT?</b><br><b>1</b><br>Sweep mode is currently enabled.                            |                |

|                               |                 |
|-------------------------------|-----------------|
|                               | Source Specific |
| <b>SOURce[1 2]:SWEep:TYPE</b> | Command         |

|              |                                                                                                              |  |
|--------------|--------------------------------------------------------------------------------------------------------------|--|
| Description  | Sets or queries the sweep type, frequency or amplitude sweep.By default, the sweep type is set to frequency. |  |
| Syntax       | <b>SOURce[1 2]:SWEep:TYPE {FREQuency AMPLitude}</b>                                                          |  |
| Example      | <b>SOUR1:SWE:TYPE FREQ</b><br>Sets sweep mode to frequency.                                                  |  |
| Query Syntax | <b>SOURce[1 2]:SWEep:TYPE?</b>                                                                               |  |



| SOURce[1 2]:SWEep:SHApe |                                                                                                                                                     | Source Specific Command               |
|-------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------|
| Description             | Sets or queries the sweep waveform shape. The sweep can be set to a sawtooth or a shuttlecock-like shape. By default, the shape is set to sawtooth. |                                       |
| Syntax                  | <b>SOURce[1 2]:SWEep:SHApe{SAWtooth TRIangle}</b>                                                                                                   |                                       |
| Parameter               | SAW                                                                                                                                                 | Sawtooth shaped sweep                 |
|                         | TRI                                                                                                                                                 | Triangle (shuttle cock) shaped sweep. |
| Example                 | <b>SOUR1:SWE:SHApe SAW</b><br>Sets the sweep shape to sawtooth.                                                                                     |                                       |
| Query Syntax            | <b>SOURce[1 2]:SWEep:SHApe?</b>                                                                                                                     |                                       |
| Return Parameter        | sawtooth                                                                                                                                            | Sawtooth shaped sweep                 |
|                         | triangle                                                                                                                                            | Triangle (shuttle cock) shaped sweep. |
| Example                 | <b>SOUR1:SWE:SHApe?</b><br>Sawtooth<br>The sweep shape is set as sawtooth.                                                                          |                                       |

| SOURce[1 2]:SWEep:MANual:TRIGger |                                                                                             | Source Specific Command |
|----------------------------------|---------------------------------------------------------------------------------------------|-------------------------|
| Description                      | Performs a manual trigger when the sweep trigger is set to manual for the selected channel. |                         |

|                  |                                                                                                       |                                                                         |
|------------------|-------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------|
| Syntax           | <b>SOURce[1 2]:SWEep:MANual:TRIGger</b>                                                               |                                                                         |
| Example          | <b>SOUR1:SWE: MAN:TRIG</b><br>Performs a manual trigger.                                              |                                                                         |
|                  | Source Specific                                                                                       | Command                                                                 |
|                  | <b>SOURce[1 2]:SWEep:FREQuency:STARt</b>                                                              |                                                                         |
| Description      | Sets the start frequency of the sweep for the selected channel. 100Hz is the default start frequency. |                                                                         |
| Note             | To sweep up or down, set the stop frequency higher or lower than the start frequency.                 |                                                                         |
| Syntax           | <b>SOURce[1 2]:SWEep:FREQuency:STARt {&lt;frequency&gt; MINimum MAXimum}</b>                          |                                                                         |
| Parameter        | <frequency>                                                                                           | 1μHz~ 30MHz<br>(20MHz AFG-3021/3022)<br><br>1μHz~ 1MHz (Ramp, Triangle) |
| Example          | <b>SOUR1:SWE:FREQ:STAR +2.0000E+03</b><br>Sets the start frequency to 2kHz.                           |                                                                         |
| Query Syntax     | <b>SOURce[1 2]:SWEep:FREQuency:STARt? [MINimum  MAXimum]</b>                                          |                                                                         |
| Return Parameter | <NR3>                                                                                                 | Returns the start frequency in Hz.                                      |
| Example          | <b>SOUR1:SWE:FREQ:STAR? MAX</b><br><b>+3.0000E+07</b>                                                 |                                                                         |



Returns the maximum start frequency allowed.

Source Specific

SOURce[1|2]:SWEep:FREQuency:STOP Command

|                  |                                                                                                      |                                                                         |
|------------------|------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------|
| Description      | Sets the stop frequency of the sweep for the selected channel. 1 kHz is the default start frequency. |                                                                         |
| Note             | To sweep up or down, set the stop frequency higher or lower than the start frequency.                |                                                                         |
| Syntax           | <b>SOURce[1 2]:SWEep:FREQuency:STOP</b><br><b>{&lt;frequency&gt; MINimum MAXimum}</b>                |                                                                         |
| Parameter        | <frequency>                                                                                          | 1μHz~ 30MHz<br>(20MHz AFG-3021/3022)<br><br>1μHz~ 1MHz (Ramp, Triangle) |
| Example          | <b>SOUR1:SWE:FREQ:STOP +2.0000E+03</b><br>Sets the stop frequency to 2kHz.                           |                                                                         |
| Query Syntax     | <b>SOURce[1 2]:SWEep:FREQuency:STOP?</b><br><b>[MINimum  MAXimum]</b>                                |                                                                         |
| Return Parameter | <NR3>                                                                                                | Returns the stop frequency in Hz.                                       |
| Example          | <b>SOUR1:SWE:FREQ:STOP? MAX</b><br><b>+3.0000E+07</b><br>Returns the maximum stop frequency allowed. |                                                                         |

Source Specific

**SOURce[1|2]:SWEep:FREQuency:CENTer** Command

|                  |                                                                                                                                       |                                                               |
|------------------|---------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------|
| Description      | Sets or queries the center frequency of the sweep for the selected channel. 550 Hz is the default center frequency.                   |                                                               |
| Note             | The maximum center frequency depends on the sweep span and maximum frequency:<br>max center freq = max freq – span/2                  |                                                               |
| Syntax           | <b>SOURce[1 2]:SWEep:FREQuency:CENTer {&lt;frequency&gt; MINimum MAXimum}</b>                                                         |                                                               |
| Parameter        | <frequency>                                                                                                                           | 1μHz~ 30MHz<br>(20MHz AFG-3021/3022)<br><br>1μHz~ 1MHz (Ramp) |
| Example          | <b>SOUR1:SWE:FREQ:CENT +2.0000E+03</b><br><br>Sets the center frequency to 2kHz.                                                      |                                                               |
| Query Syntax     | <b>SOURce[1 2]:SWEep:FREQuency:CENTer? [MINimum  MAXimum]</b>                                                                         |                                                               |
| Return Parameter | <NR3>                                                                                                                                 | Returns the center frequency in Hz.                           |
| Example          | <b>SOUR1:SWE:FREQ:CENT? MAX</b><br><br><b>+3.0000E+07</b><br><br>Returns the maximum center frequency allowed, depending on the span. |                                                               |

| Source Specific                  |                                                                                                                                                                                                                                    | Command                                                       |
|----------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------|
| SOURce[1 2]:SWEep:FREQuency:SPAN |                                                                                                                                                                                                                                    |                                                               |
| Description                      | Sets or queries the frequency span of the sweep for the selected channel. 900 Hz is the default frequency span. The span frequency is equal to the stop-start frequencies.                                                         |                                                               |
| Note                             | To sweep up or down, set the span as positive or negative.<br><br>The maximum span frequency has a relationship to the center frequency and maximum frequency:<br>$\text{max freq span} = 2(\text{max freq} - \text{center freq})$ |                                                               |
| Syntax                           | <b>SOURce[1 2]:SWEep:FREQuency:SPAN</b><br><b>{&lt;frequency&gt; MINimum MAXimum}</b>                                                                                                                                              |                                                               |
| Parameter                        | <frequency>                                                                                                                                                                                                                        | 1μHz~ 30MHz<br>(20MHz AFG-3021/3022)<br><br>1μHz~ 1MHz (Ramp) |
| Example                          | <b>SOUR1:SWE:FREQ:SPAN +2.0000E+03</b><br><br>Sets the frequency span to 2kHz.                                                                                                                                                     |                                                               |
| Query Syntax                     | <b>SOURce[1 2]:SWEep:FREQuency:SPAN?</b><br><b>[MINimum  MAXimum]</b>                                                                                                                                                              |                                                               |
| Return Parameter                 | <NR3>                                                                                                                                                                                                                              | Returns the frequency span in Hz.                             |
| Example                          | <b>SOUR1:SWE:FREQ:SPAN?</b><br><br><b>+2.0000E+03</b><br><br>Returns the frequency span for the current sweep.                                                                                                                     |                                                               |

| Source Specific Command           |                                                                                 |
|-----------------------------------|---------------------------------------------------------------------------------|
| <b>SOURce[1 2]:SWEep:FUNCtion</b> |                                                                                 |
| Description                       | Sets linear or logarithmic sweep spacing. The default spacing is linear.        |
| Syntax                            | <b>SOURce[1 2]:SWEep:FUNCtion {LINear LOG}</b>                                  |
| Example                           | <b>SOUR1:SWE:FUNC LIN</b><br>Sets the spacing to linear.                        |
| Query Syntax                      | <b>SOURce[1 2]:SWEep:FUNCtion?</b>                                              |
| Return Parameter                  | LIN Linear spacing                                                              |
|                                   | LOG Logarithmic spacing                                                         |
| Example                           | <b>SOUR1:SWE:FUNC?</b><br><b>LOG</b><br>The spacing is currently set as linear. |

| Source Specific Command       |                                                                                                                                     |
|-------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|
| <b>SOURce[1 2]:SWEep:TIME</b> |                                                                                                                                     |
| Description                   | Sets or queries the sweep time. The default sweep time is 1 second.                                                                 |
| Note                          | The function generator automatically determines the number of frequency points that are used for the sweep based on the sweep time. |
| Syntax                        | <b>SOURce[1 2]:SWEep:TIME</b><br><b>{&lt;seconds&gt; MINimum MAXimum}</b>                                                           |
| Parameter                     | <seconds> 1 ms ~ 500 s                                                                                                              |

|                           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |                                |
|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------|
| Example                   | <b>SOUR1:SWE:TIME +1.0000E+00</b><br>Sets the sweep time to 1 second.                                                                                                                                                                                                                                                                                                                                                                                                             |                                |
| Query Syntax              | <b>SOURce[1 2]:SWEep:TIME?</b><br><b>{[MINimum MAXimum]}</b>                                                                                                                                                                                                                                                                                                                                                                                                                      |                                |
| Return Parameter          | <NR3>                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | Returns sweep time in seconds. |
| Example                   | <b>SOUR1:SWE:TIME?</b><br><b>+2.0000E+01</b><br>Returns the sweep time (20 seconds).                                                                                                                                                                                                                                                                                                                                                                                              |                                |
| SOURce[1 2]:SWEep:TRIGger |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | Source Specific Command        |
| Description               | Sets or queries the trigger source as internal, external, manual or off for the selected channel. Internal is the default trigger source. Internal will constantly output a swept waveform at a defined interval time. External will output a swept waveform after each external trigger pulse. Manual will output a swept waveform after the trigger softkey is pressed or the SOURce[1   2]:SWEep:MANual:TRIGger command is issued. The OFF setting is for continuous sweeping. |                                |
| Note                      | If the APPLy command was used to create the waveform shape, the source is automatically set to Internal.<br><br>The *OPC/*OPC? command/query can be used to signal the end of the sweep.                                                                                                                                                                                                                                                                                          |                                |

|                  |                                                                                                                      |                                                               |
|------------------|----------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------|
| Syntax           | <b>SOURce[1 2]:SWEep:TRIGger</b><br><b>{EXTernal MANual OFF </b><br><b>INTernal,&lt;seconds&gt; MINimum MAXimum}</b> |                                                               |
| Parameter        | INTernal                                                                                                             | Internal trigger                                              |
|                  | EXTernal                                                                                                             | External trigger                                              |
|                  | MANual                                                                                                               | Manual trigger                                                |
|                  | OFF                                                                                                                  | No interval time, sweep continuously                          |
|                  | <seconds>                                                                                                            | 1ms~ 500s. Interval time in seconds for the internal trigger. |
|                  | MINimum                                                                                                              | Sets the interval time to the minimum                         |
|                  | MAXimum                                                                                                              | Sets the interval time to the maximum                         |
| Example          | <b>SOUR1:SWE:TRIG EXT</b><br>Sets the sweep source to external.                                                      |                                                               |
| Query Syntax     | <b>SOURce[1 2]:SWEep:TRIGger?</b>                                                                                    |                                                               |
| Return Parameter | INT,<NR3>                                                                                                            | Internal trigger, interval time in seconds                    |
|                  | EXT                                                                                                                  | External trigger                                              |
|                  | MAN                                                                                                                  | Manual trigger                                                |
|                  | OFF                                                                                                                  | Sweep continuously                                            |

|                  |                                                                                                                                |                                                   |
|------------------|--------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------|
| Example          | <b>SOUR1:SWE:TRIG?</b><br><br><b>INT +1.00000E+00</b><br><br>The sweep source is set to an interval time of 1 second.          |                                                   |
|                  | SOURce[1 2]:SWEep:AMPLitude:STARt                                                                                              | Source Specific Command                           |
| Description      | Sets the start amplitude for when the sweep is set to the amplitude sweep type. By default the start amplitude is set to 1Vpp. |                                                   |
| Syntax           | <b>SOURce[1 2]:SWEep:AMPLitude:STARt</b><br><b>{&lt;ampiltude&gt; MINimum MAXimum}</b>                                         |                                                   |
| Parameter        | <NR3>                                                                                                                          | Sweep amplitude in volts.<br>(range:1mV~10V @50Ω) |
| Example          | <b>SOUR1:SWE:AMPL:STAR MIN</b><br><br>Sets the start sweep to the minimum level (1mVpp).                                       |                                                   |
| Query Syntax     | <b>SOURce[1 2]:SWEep:AMPLitude:STARt?</b><br><b>{[MINimum MAXimum]}</b>                                                        |                                                   |
| Return Parameter | <NR3>                                                                                                                          | Sweep amplitude in volts.                         |
| Example          | <b>SOUR1:SWE:AMPL:STAR?</b><br><br><b>1.000E+00</b><br><br>The start amplitude is set to 1Vpp.                                 |                                                   |

---

|                                  |                 |
|----------------------------------|-----------------|
|                                  | Source Specific |
| SOURce[1 2]:SWEep:AMPLitude:STOP | Command         |

---

|             |                                                                                                                              |
|-------------|------------------------------------------------------------------------------------------------------------------------------|
| Description | Sets the stop amplitude for when the sweep is set to the amplitude sweep type. By default the stop amplitude is set to 3Vpp. |
|-------------|------------------------------------------------------------------------------------------------------------------------------|

---

|        |                                                                                 |
|--------|---------------------------------------------------------------------------------|
| Syntax | <b>SOURce[1 2]:SWEep:AMPLitude:STOP<br/>{&lt;amplitude&gt; MINimum MAXimum}</b> |
|--------|---------------------------------------------------------------------------------|

---

|           |       |                                                   |
|-----------|-------|---------------------------------------------------|
| Parameter | <NR3> | Sweep amplitude in volts.<br>(range:1mV~10V @50Ω) |
|-----------|-------|---------------------------------------------------|

---

|         |                                                               |
|---------|---------------------------------------------------------------|
| Example | <b>SOUR1:SWE:AMPL:STOP 3</b><br>Sets the stop sweep to 3Vpp). |
|---------|---------------------------------------------------------------|

|              |                                                                  |
|--------------|------------------------------------------------------------------|
| Query Syntax | <b>SOURce[1 2]:SWEep:AMPLitude:STOP?<br/>{[MINimum MAXimum]}</b> |
|--------------|------------------------------------------------------------------|

---

|                     |       |                           |
|---------------------|-------|---------------------------|
| Return<br>Parameter | <NR3> | Sweep amplitude in volts. |
|---------------------|-------|---------------------------|

---

|         |                                                                                       |
|---------|---------------------------------------------------------------------------------------|
| Example | <b>SOUR1:SWE:AMPL:STOP?</b><br><b>3.000E+00</b><br>The stop amplitude is set to 3Vpp. |
|---------|---------------------------------------------------------------------------------------|



# Burst 模式指令

## Burst 模式介绍

Burst mode can be configured to use an internal trigger (N Cycle mode) or an external trigger (Gate mode) using the Trigger INPUT terminal on the rear panel. Using N Cycle mode, each time the function generator receives a trigger, the function generator will output a specified number of waveform cycles (burst). After the burst, the function generator will wait for the next trigger before outputting another burst. N Cycle is the default Burst mode.

The alternative to using a specified number of cycles, Gate mode uses the external trigger to turn on or off the output. When the Trigger INPUT signal is high\*, waveforms are continuously output (creating a burst). When the Trigger INPUT signal goes low\*, the waveforms will stop being output after the last waveform completes its period. The voltage level of the output will remain equal to the starting phase of the burst waveforms, ready for the signal to go high\* again.


\*assuming the Trigger polarity is not inverted.


Only one burst mode can be used at any one time. The burst mode depends on the source of the trigger (internal, external, manual) and the source of the burst.

| Burst Mode &Source              | Function  |           |           |
|---------------------------------|-----------|-----------|-----------|
|                                 | N Cycle*  | Cycle     | Phase     |
| Triggered –IMMediate            | Available | Available | Available |
| Triggered - EXTernal,<br>MANual | Available | Unused    | Available |

|                         |              |        |           |
|-------------------------|--------------|--------|-----------|
| Gated pulse - IMMEDIATE | Unused       | Unused | Available |
|                         | *burst count |        |           |

The following is an overview of the steps required to generate a burst waveform.





7. Use the SOURce[1 | 2]:BURSt:TRIG command to select the trigger source for triggered burst mode only. For manual triggering, execute the SOUR[1]:BURSt:TRIGger:MANual for each trigger.

| SOURCE[1 2]:BURSt:STATe |                                                                                                | Source Specific Command |
|-------------------------|------------------------------------------------------------------------------------------------|-------------------------|
| Description             | Turns burst mode on or off for the selected channel. By default burst mode is turned off.      |                         |
| Note                    | When burst mode is turned on, sweep and any modulation modes are disabled on the same channel. |                         |
| Syntax                  | <b>SOURce[1 2]:BURSt:STATe {OFF ON}</b>                                                        |                         |
| Parameter               | OFF                                                                                            | Disabled                |
|                         | ON                                                                                             | Enabled                 |
| Example                 | <b>SOUR1:BURSt:STAT OFF</b><br>Turns burst mode on.                                            |                         |
| Query Syntax            | <b>SOURce[1 2]:BURSt:STATe?</b>                                                                |                         |
| Return Parameter        | 0                                                                                              | Disabled                |
|                         | 1                                                                                              | Enabled                 |

|                     |                                                                                                          |                            |
|---------------------|----------------------------------------------------------------------------------------------------------|----------------------------|
| Example             | <b>SOUR1:BURS:STAT?</b><br><br><b>OFF</b><br><br>Burst mode is off.                                      |                            |
|                     | SOURce[1 2]:BURSt:MODE                                                                                   | Source Specific<br>Command |
| Description         | Sets or queries the burst mode as gated or triggered. The default burst mode is triggered.               |                            |
| Note                | The burst count, period, trigger source and any manual trigger commands are ignored in gated burst mode. |                            |
| Syntax              | <b>SOURce[1 2]:BURSt:MODE {TRIGgered GATE}</b>                                                           |                            |
| Parameter           | TRIGgered                                                                                                | Triggered mode             |
|                     | GATE                                                                                                     | Gated mode                 |
| Example             | <b>SOUR1:BURS:MODE TRIG</b><br><br>Sets the burst mode to triggered.                                     |                            |
| Query Syntax        | <b>SOURce[1 2]:BURSt:MODE?</b>                                                                           |                            |
| Return<br>Parameter | TRIG                                                                                                     | Triggered mode             |
|                     | GATE                                                                                                     | Gated mode                 |
| Example             | <b>SOUR1:BURS:MODE?</b><br><br><b>TRIG</b><br><br>The current burst mode is triggered.                   |                            |

| SOURce[1 2]:BURSt:NCYCles |                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Source Specific Command             |
|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------|
| Description               | Sets or queries the number of cycles (burst count) in triggered burst mode for the selected channel. The default number of cycles is 1. The burst count is ignored in gated mode.                                                                                                                                                                                                                                                                               |                                     |
| Note                      | <p>If the trigger source is set to immediate, the product of the burst period and waveform frequency must be greater than the burst count:<br/> Burst Period X Waveform frequency &gt; burst count</p> <p>If the burst count is too large, the burst period will automatically be increased and a "Settings conflict" error will be generated.</p> <p>Only sine and square waves are allowed infinite burst above 25 MHz(not applicable for AFG-3021/3022).</p> |                                     |
| Syntax                    | <b>SOURce[1 2]:BURSt:NCYCles{&lt; #cycles&gt;  INFinity MINimum  MAXimum}</b>                                                                                                                                                                                                                                                                                                                                                                                   |                                     |
| Parameter                 | <# cycles>                                                                                                                                                                                                                                                                                                                                                                                                                                                      | 1~1,000,000 cycles.                 |
|                           | INFinity                                                                                                                                                                                                                                                                                                                                                                                                                                                        | Sets the number to continuous.      |
|                           | MINimum                                                                                                                                                                                                                                                                                                                                                                                                                                                         | Sets the number to minimum allowed. |
|                           | MAXimum                                                                                                                                                                                                                                                                                                                                                                                                                                                         | Sets the number to maximum allowed. |
| Example                   | <b>SOUR1:BURS:NCYCI INF</b><br><br>Sets the number of burst cycles to continuous (infinite).                                                                                                                                                                                                                                                                                                                                                                    |                                     |

|                                   |                                                                                                                                                                                                                                                                                                                                           |                                                        |
|-----------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------|
| Query Syntax                      | <b>SOURce[1 2]:BURSt:NCYCles?</b><br><b>[MINimum MAXimum]</b>                                                                                                                                                                                                                                                                             |                                                        |
| Return Parameter                  | <NR3>                                                                                                                                                                                                                                                                                                                                     | Returns the number of cycles.                          |
|                                   | INF                                                                                                                                                                                                                                                                                                                                       | INF is returned if the number of cycles is continuous. |
| Example                           | <b>SOUR1:BURS:NCYC?</b><br><b>+1.0000E+02</b><br>The burst cycles are set to 100.                                                                                                                                                                                                                                                         |                                                        |
| SOURce[1 2]:BURSt:INTernal:PERiod |                                                                                                                                                                                                                                                                                                                                           | Source Specific Command                                |
| Description                       | Sets or queries the burst period for the selected channel. Burst period settings are only applicable when the trigger is set to immediate. The default burst period is 10ms.<br><br>During manual triggering, external triggering or Gate burst mode, the burst period settings are ignored.                                              |                                                        |
| Note                              | The burst period must be long enough to output the designated number of cycles for a selected frequency.<br><br>Burst period > burst count/(waveform frequency + 200 ns)<br><br>If the period is too short, it is automatically increased so that a burst can be continuously output. A “data out of range” error will also be generated. |                                                        |

|                  |                                                                                      |                                      |
|------------------|--------------------------------------------------------------------------------------|--------------------------------------|
| Syntax           | <b>SOURce[1 2]:BURSt:INteRnal:PERiod</b><br><b>{&lt;seconds&gt; MINimum MAXimum}</b> |                                      |
| Parameter        | <seconds >                                                                           | 1 us ~ 500 seconds                   |
| Example          | <b>SOUR1:BURS:INT:PER +1.0000E+01</b><br>Sets the period to 10 seconds.              |                                      |
| Query Syntax     | <b>SOURce[1 2]:BURSt:INteRnal:PERiod?</b><br><b>[MINimum MAXimum]</b>                |                                      |
| Return Parameter | <NR3>                                                                                | Returns the burst period in seconds. |
| Example          | <b>SOUR1:BURS:INT:PER?</b><br><b>+1.0000E+01</b><br>The burst period is 10seconds.   |                                      |

|                         |                                                                                                                                                                                                                                                                                                                                                                                              | Source Specific |
|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| SOURce[1 2]:BURSt:PHASe |                                                                                                                                                                                                                                                                                                                                                                                              | Command         |
| Description             | Sets or queries the starting phase for the burst for the selected channel. The default phase is 0 degrees. At 0 degrees, sine, square and ramp waveforms are at 0 volts.<br><br>In gated burst mode, waveforms are continuously output (burst) when the Trig signal is true. The voltage level at the starting phase is used to determine the voltage level of the signal in-between bursts. |                 |
| Note                    | The phase command is not used with pulse waveforms.                                                                                                                                                                                                                                                                                                                                          |                 |



|                  |                                                                                            |                                     |
|------------------|--------------------------------------------------------------------------------------------|-------------------------------------|
| Syntax           | <b>SOURce[1 2]:BURSt:PHASe</b><br><b>{&lt;angle&gt; MINimum MAXimum}</b>                   |                                     |
| Parameter        | <angle>                                                                                    | -360 ~ 360 degrees                  |
| Example          | <b>SOUR1:BURSt:PHAS MAX</b><br>Sets the phase to 360 degrees.                              |                                     |
| Query Syntax     | <b>SOURce[1 2]:BURSt:PHASe?</b><br><b>[MINimum MAXimum]</b>                                |                                     |
| Return Parameter | <NR3>                                                                                      | Returns the phase angle in degrees. |
| Example          | <b>SOUR1:BURSt:PHAS?</b><br><b>+1.2000E+01</b><br>The burst starting phase is 120 degrees. |                                     |

|                                         |                 |
|-----------------------------------------|-----------------|
|                                         | Source Specific |
| <b>SOURce[1 2]:BURSt:TRIGger:MANual</b> | Command         |

|             |                                                                                                                                                                                                                                        |
|-------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Description | This command is used to manually trigger a burst waveform when the source trigger is set to manual for the selected channel. This command is the equivalent of pressing the trigger soft-key on the front panel for manual triggering. |
|-------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|         |                                                                      |  |
|---------|----------------------------------------------------------------------|--|
| Syntax  | <b>SOURce[1 2]:BURSt:TRIGger:MANual</b>                              |  |
| Example | <b>SOUR1:BURSt:TRIG:MAN</b><br>Manually triggers the burst waveform. |  |

|                                  |                 |
|----------------------------------|-----------------|
|                                  | Source Specific |
| <b>SOURce[1 2]:BURSt:TRIGger</b> | Command         |

|                  |                                                                                                                                                                                                                                                                                                                     |                                                                                                                                                        |
|------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
| Description      | <p>Sets or queries the trigger source for triggered burst mode for the selected channel. In triggered burst mode, a waveform burst is output each time a trigger signal is received and the number of cycles is determined by the burst count.</p> <p>There are three trigger sources for triggered burst mode:</p> |                                                                                                                                                        |
|                  | Immediate                                                                                                                                                                                                                                                                                                           | A burst is output at a set frequency determined by the burst period.                                                                                   |
|                  | External                                                                                                                                                                                                                                                                                                            | EXternal will output a burst waveform after each external trigger pulse. Any additional trigger pulse signals before the end of the burst are ignored. |
|                  | Manual                                                                                                                                                                                                                                                                                                              | Manual triggering will output a burst waveform after the SOUR[1]:BURSt:TRIGger:MANual command is executed or the trigger soft-key is pressed.          |
| Note             | <p>If the APPLy command was used, the source is automatically set to IMMEDIATE.</p> <p>The *OPC/*OPC? command/query can be used to signal the end of the burst.</p>                                                                                                                                                 |                                                                                                                                                        |
| Syntax           | <b>SOURce[1 2]:BURSt:TRIGger {IMMEDIATE EXternal MANual}</b>                                                                                                                                                                                                                                                        |                                                                                                                                                        |
| Example          | <b>SOUR1:BURSt:TRIG:SOUR EXT</b><br><br>Sets the burst trigger source to external.                                                                                                                                                                                                                                  |                                                                                                                                                        |
| Query Syntax     | <b>SOURce[1 2]:BURSt:TRIGger?</b>                                                                                                                                                                                                                                                                                   |                                                                                                                                                        |
| Return Parameter | IMM                                                                                                                                                                                                                                                                                                                 | Immediate                                                                                                                                              |

|  |        |          |
|--|--------|----------|
|  | EXT    | External |
|  | MANual | Manual   |

Example      **SOUR1:BURS:TRIG?**  
**IMM**  
The burst trigger source is set to immediate.

|                                        |                 |
|----------------------------------------|-----------------|
|                                        | Source Specific |
| <b>SOURce[1 2]:BURSt:TRIGger:DElay</b> | Command         |

|             |                                                                                                                                                                                           |
|-------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Description | The DELay command is used to insert a delay (in seconds) before a burst is output for the selected channel. The delay starts after a trigger is received. The default delay is 0 seconds. |
|-------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|        |                                                                                     |
|--------|-------------------------------------------------------------------------------------|
| Syntax | <b>SOURce[1 2]: BURSt:TRIGger:DElay</b><br><b>{&lt;seconds&gt; MINimum MAXimum}</b> |
|--------|-------------------------------------------------------------------------------------|

|           |           |              |
|-----------|-----------|--------------|
| Parameter | <seconds> | 0~100seconds |
|-----------|-----------|--------------|

Example      **SOUR1:BURS:TRIG:DEL +1.0000E+01**  
Sets the trigger delay to 10 seconds.

|              |                                                                     |
|--------------|---------------------------------------------------------------------|
| Query Syntax | <b>SOURce[1 2]:BURSt:TRIGger:DElay?</b><br><b>[MINimum MAXimum]</b> |
|--------------|---------------------------------------------------------------------|

|                     |       |                  |
|---------------------|-------|------------------|
| Return<br>Parameter | <NRf> | Delay in seconds |
|---------------------|-------|------------------|

Example      **SOUR1:BURS:TRIG:DEL**  
**+1.0000E+01**  
The trigger delay is 10 seconds.

|                                 |                                                                                                                                                                                                |                         |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------|
| SOURce[1 2]:BURSt:TRIGger:SLOPe |                                                                                                                                                                                                | Source Specific Command |
| Description                     | Sets or queries the trigger edge for externally triggered bursts from the Trigger INPUT terminal on the rear panel for the selected channel. By default the trigger is rising edge (Positive). |                         |
| Syntax                          | <b>SOURce[1 2]:BURSt:TRIGger:SLOPe {POSitive NEGative}</b>                                                                                                                                     |                         |
| Parameter                       | POSitive                                                                                                                                                                                       | rising edge             |
|                                 | NEGative                                                                                                                                                                                       | falling edge            |
| Example                         | <b>SOUR1:BURS:TRIG:SLOP NEG</b><br>Sets the trigger slope to negative.                                                                                                                         |                         |
| Query Syntax                    | <b>SOURce[1 2]:BURSt:TRIGger:SLOPe?</b>                                                                                                                                                        |                         |
| Return Parameter                | POS                                                                                                                                                                                            | rising edge             |
|                                 | NEG                                                                                                                                                                                            | falling edge            |
| Example                         | <b>SOUR1:BURS:TRIG:SLOP NEG</b><br>The trigger slope is negative.                                                                                                                              |                         |
| SOURce[1 2]:BURSt:GATE:POLarity |                                                                                                                                                                                                | Source Specific Command |

|             |                                                                                                                                                                                                                                                                                                                                |
|-------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Description | In gated mode, for the selected channel, the function generator will output a waveform continuously while the external trigger receives logically true signal from the Trigger INPUT terminal. Normally a signal is logically true when it is high. The logical level can be inverted so that a low signal is considered true. |
|-------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|        |                                                         |
|--------|---------------------------------------------------------|
| Syntax | <b>SOURce[1 2]:BURSt:GATE:POLarity{NORMal INVertes}</b> |
|--------|---------------------------------------------------------|

|           |          |                |
|-----------|----------|----------------|
| Parameter | NORMal   | Logically high |
|           | INVertes | Logically low  |

|         |                                                                               |
|---------|-------------------------------------------------------------------------------|
| Example | <b>SOUR1:BURS:GATE:POL INV</b><br>Sets the state to logically low (inverted). |
|---------|-------------------------------------------------------------------------------|

|              |                                         |
|--------------|-----------------------------------------|
| Query Syntax | <b>SOURce[1 2]:BURSt:GATE:POLarity?</b> |
|--------------|-----------------------------------------|

|                     |      |                              |
|---------------------|------|------------------------------|
| Return<br>Parameter | NORM | Normal(High) logical level   |
|                     | INV  | Inverted (low) logical level |

|         |                                                                                         |
|---------|-----------------------------------------------------------------------------------------|
| Example | <b>SOUR1:BURS:GATE:POL?</b><br><b>INV</b><br>The true state is inverted(logically low). |
|---------|-----------------------------------------------------------------------------------------|

# 任意波形指令

## 任意波形介绍

Use the steps below to output an arbitrary waveform over the remote interface.

Output  
Arbitrary  
Waveform

↓

Select  
Waveform  
Frequency,  
amplitude and  
offset

↓

Load Waveform  
Data

↓

Set Waveform  
Rate

1. Use the  
SOURce[1 | 2]:ARB:BUILt:ARB\_waveform  
command (Example:  
SOURce[1 | 2]:ARB:BUILt:SQUare) to output  
the arbitrary waveform currently selected in  
memory.

2. Use the APPLy command to select frequency,  
amplitude and DC offset. Alternatively,  
FREQ, FUNC, AMPL, and DCOffs commands  
can be used.

3. Waveform data (1 to 8388608 points per  
waveform) can be downloaded into volatile  
memory using the SOURce[1 | 2]:DATA:DAC  
command. Binary integer or decimal integer  
values in the range of ± 32767 can be used.

4. The waveform rate is the product of the  
number of points in the waveform and the  
waveform frequency.

Rate = Hz × # points

Frequency: 1μHz ~ 125MHz μ

# points: 2~8,388,608

| Source Specific      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Command              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| SOURce[1 2]:DATA:DAC |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| Description          | The SOURce[1   2]:DATA:DAC command is used to download binary or decimal integer values into memory using the IEEE-488.2 binary block format or as an ordered list of values.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| Note 1               | <p>The integer values (<math>\pm 32767</math>) correspond to the maximum and minimum peak amplitudes of the waveform. For instance, for a waveform with an amplitude of 5Vpp (0 offset), the value 32767 is the equivalent of 2.5 Volts. If the integer values do not span the full output range, the peak amplitude will be limited. The IEEE-488.2 binary block format is comprised of three parts:</p> <div><div><div># 7 2097152</div><div>1 2 3</div></div><div><div>1. Initialization character (#)</div><div>2. Digit length (in ASCII) of the number of bytes</div><div>3. Number of bytes</div></div></div> <p>IEEE 488.2 uses two bytes to represent waveform data (16 bit integer). Therefore the number of bytes is always twice the number of data points.</p> |
| Note 2               | The data sent by the command is limited to 1MB. To overcome the 1MB limitation, use the <start> parameter to send data segments of 1MB or less. Do not send the command before the last transmission has finished. An example will be shown below.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Syntax               | <b>SOURce[1 2]:DATA:DAC VOLATILE, &lt;start&gt;, {&lt;binary block&gt; &lt;value&gt;, &lt;value&gt;, . . . }</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Parameter            | <div>&lt;start&gt;</div> <div>Start address of the arbitrary waveform</div>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

|                                  |                                                                                                                                                                                                                                                                                                                                              |                                  |
|----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------|
|                                  | <div>&lt;binary block&gt;</div> <div>&lt;value&gt;</div>                                                                                                                                                                                                                                                                                     | Decimal or integer values ±32767 |
| Example1                         | <div><b>SOUR1:DATA:DAC VOLATILE, 0, #216 Binary Data</b></div> <div>The command above downloads 8 data values (stored in 16 bytes) using the binary block format.</div> <div><b>SOUR1:DATA:DAC VOLATILE, 1000, 32767, 2048, 0, -2048, -32767</b></div> <div>Downloads the data values (32767, 2048, 0, -2048, -32767) to address 1000.</div> |                                  |
| Example2a<br>(0~1M data points)  | <div><b>SOUR1:DATA:DAC VOLATILE,0,#72097152 Binary Data</b></div> <div>This command will send that first 0~1M data points to address 0. To send data to the next 1M data points, see below:</div>                                                                                                                                            |                                  |
| Example2b<br>(1M~2M data points) | <div><b>SOUR1:DATA:DAC VOLATILE,1048576,#72097152 Binary Data</b></div> <div>This command will send the next 1M data points (1M~2M)</div>                                                                                                                                                                                                    |                                  |
| SOURce[1 2]:ARB:EDIT:COPY        |                                                                                                                                                                                                                                                                                                                                              | Source Specific Command          |
| Description                      | Copies a segment of a waveform to a specific starting address.                                                                                                                                                                                                                                                                               |                                  |
| Syntax                           | <b>SOURce[1 2]:ARB:EDIT:COPY</b><br><b>[&lt;start&gt;[,&lt;length&gt;[,&lt;paste&gt;]]]</b>                                                                                                                                                                                                                                                  |                                  |



|           |          |                             |
|-----------|----------|-----------------------------|
| Parameter | <start>  | Start address:<br>0~8388606 |
|           | <length> | Length: 2~8388608           |
|           | <paste>  | Paste address:<br>0~8388607 |

Example                   **SOUR1:ARB:EDIT:COPY 1000, 256, 1257**

Copies 256 data values starting at address 1000 and copies them to address 1257.

Source Specific  
SOURce[1|2]:ARB:EDIT:DELeTe                    Command

|             |                                                                                                                                |                             |
|-------------|--------------------------------------------------------------------------------------------------------------------------------|-----------------------------|
| Description | Deletes a segment of a waveform from memory for the selected channel. The segment is defined by a starting address and length. |                             |
| Note        | A waveform/ waveform segmentcannot be deleted when being output.                                                               |                             |
| Syntax      | <b>SOURce[1 2]:ARB:EDIT:DELeTe</b><br><b>[&lt;START&gt;[,&lt;LENGth&gt;]]</b>                                                  |                             |
| Parameter   | <START>                                                                                                                        | Start address:<br>0~8388606 |
|             | <LENGth>                                                                                                                       | Length: 2~8388608           |

Example                   **SOURce1:ARB:EDIT:DEL 1000, 256**

Deletes a section of 256 data points from the waveform starting at address 1000.

SOURCE[1|2]:ARB:EDIT:DELEte:ALL

Source Specific  
Command

|             |                                                                                                                                   |
|-------------|-----------------------------------------------------------------------------------------------------------------------------------|
| Description | Deletes all user-defined waveforms from non-volatile memory and the current waveform in volatile memory for the selected channel. |
| Note        | A waveform cannot be deleted when output.                                                                                         |
| Syntax      | <b>SOURCE[1 2]:ARB:EDIT:DELEte:ALL</b>                                                                                            |
| Example     | <b>SOUR1:ARB:EDIT:DEL:ALL</b><br>Deletes all user waveforms from memory.                                                          |

SOURCE[1|2]:ARB:EDIT:POINt

Source Specific  
Command

|             |                                                                                                                                                         |           |                                     |        |                     |
|-------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|-------------------------------------|--------|---------------------|
| Description | Edit a point on the arbitrary waveform.                                                                                                                 |           |                                     |        |                     |
| Note        | A waveform/ waveform segment cannot be deleted when being output.                                                                                       |           |                                     |        |                     |
| Syntax      | <b>SOURCE[1 2]:ARB:EDIT:POINt [&lt;address&gt; [, &lt;data&gt;]]</b>                                                                                    |           |                                     |        |                     |
| Parameter   | <table><tr><td>&lt;address&gt;</td><td>Address of data point:<br/>0~8388607</td></tr><tr><td>&lt;data&gt;</td><td>Value data: ±32,767</td></tr></table> | <address> | Address of data point:<br>0~8388607 | <data> | Value data: ±32,767 |
| <address>   | Address of data point:<br>0~8388607                                                                                                                     |           |                                     |        |                     |
| <data>      | Value data: ±32,767                                                                                                                                     |           |                                     |        |                     |

|         |                                                                                                                                 |
|---------|---------------------------------------------------------------------------------------------------------------------------------|
| Example | <b>SOUR1:ARB:EDIT:POIN 1000, 32767</b><br>Creates a point on the arbitrary waveform at address 1000 with the highest amplitude. |
|---------|---------------------------------------------------------------------------------------------------------------------------------|

SOURCE[1|2]:ARB:EDIT:PROTeCt

Source Specific  
Command

|                                  |                                                                                                                                       |                                                                |
|----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------|
| Description                      | Protects a segment of the arbitrary waveform from deletion/editing or returns the protection state and co-ordinates (if any).         |                                                                |
| Syntax                           | <b>SOURce[1 2]:ARB:EDIT:PROTect</b><br><b>[&lt;START&gt;[,&lt;LENGth&gt;]]</b>                                                        |                                                                |
| Parameter                        | <START>                                                                                                                               | Start address:<br>0~8388606                                    |
|                                  | <LENGth>                                                                                                                              | Length: 2~8388608                                              |
| Example                          | <b>SOUR1:ARB:EDIT:PROT 40, 50</b><br><br>Protects a segment of the waveform from address 40 for 50 data points.                       |                                                                |
| Query Syntax                     | <b>SOURce[1 2]:ARB:EDIT:PROTect?</b>                                                                                                  |                                                                |
| Return                           | "UnProtect"                                                                                                                           | Returns the string                                             |
| Parameter                        |                                                                                                                                       | "Unprotect" when protection is disabled.                       |
|                                  | "Protect Start:"<START>"                                                                                                              | Returns a string                                               |
|                                  | Protect Length:"<LENGth>                                                                                                              | showing the start of the protection and the protection length. |
| Example                          | <b>SOUR1:ARB:EDIT:PROT?</b><br><br><b>Protect Start:0 Protect Length:10</b><br><br>Returns the protected segment of the ARB waveform. |                                                                |
| SOURce[1 2]:ARB:EDIT:PROTect:ALL |                                                                                                                                       | Source Specific<br>Command                                     |

|             |                                                                                           |
|-------------|-------------------------------------------------------------------------------------------|
| Description | Protects the arbitrary waveform currently in non-volatile memory/ currently being output. |
|-------------|-------------------------------------------------------------------------------------------|

|        |                                         |
|--------|-----------------------------------------|
| Syntax | <b>SOURce[1 2]:ARB:EDIT:PROTect:ALL</b> |
|--------|-----------------------------------------|

|         |                                |
|---------|--------------------------------|
| Example | <b>SOUR1:ARB:EDIT:PROT:ALL</b> |
|---------|--------------------------------|

|                                |                 |
|--------------------------------|-----------------|
|                                | Source Specific |
| SOURce[1 2]:ARB:EDIT:UNProtect | Command         |

|             |                                                                                             |
|-------------|---------------------------------------------------------------------------------------------|
| Description | Unprotects the arbitrary waveform currently in non-volatile memory/ currently being output. |
|-------------|---------------------------------------------------------------------------------------------|

|        |                                       |
|--------|---------------------------------------|
| Syntax | <b>SOURce[1 2]:ARB:EDIT:UNProtect</b> |
|--------|---------------------------------------|

|         |                           |
|---------|---------------------------|
| Example | <b>SOUR1:ARB:EDIT:UNP</b> |
|---------|---------------------------|

|                                |                 |
|--------------------------------|-----------------|
|                                | Source Specific |
| SOURce[1 2]:ARB:BUILt:SINusoid | Command         |

|             |                                                                                               |
|-------------|-----------------------------------------------------------------------------------------------|
| Description | Creates a sinusoid with a specified start address, length and scale for the selected channel. |
|-------------|-----------------------------------------------------------------------------------------------|

|        |                                                                                              |
|--------|----------------------------------------------------------------------------------------------|
| Syntax | <b>SOURce[1 2]:ARB:BUILt:SINusoid<br/>[&lt;START&gt;[, &lt;LENGth&gt;[, &lt;SCALE&gt;]]]</b> |
|--------|----------------------------------------------------------------------------------------------|

|           |          |                              |
|-----------|----------|------------------------------|
| Parameter | <START>  | Start address*:<br>0~8388606 |
|           | <LENGth> | Length*: 2~8388608           |
|           | <SCALE>  | Scale: $\pm 32767$           |

\* Start + Length  $\leq 8388608$

|         |                                           |
|---------|-------------------------------------------|
| Example | <b>SOUR1:ARB:BUIL:SIN 1000, 1000, 100</b> |
|---------|-------------------------------------------|

Creates a sin wave 1000 points in length with a scale of 100 and a start address of 1000.

SOURCE[1|2]:ARB:BUILT:SQUare

Source Specific  
Command

|                           |                                                                                                                                               |                              |
|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|
| Description               | Creates a square wave with a specified start address, length and scale.                                                                       |                              |
| Syntax                    | <b>SOURCE[1 2]:ARB:BUILT:SQUare</b><br><b>[&lt;START&gt;[,&lt;LENGTH&gt;[,&lt;SCALE&gt;]]]</b>                                                |                              |
| Parameter                 | <START>                                                                                                                                       | Start address*:<br>0~8388606 |
|                           | <LENGTH>                                                                                                                                      | Length*: 2~8388608           |
|                           | <SCALE>                                                                                                                                       | Scale: ±32767                |
| * Start + Length ≤8388608 |                                                                                                                                               |                              |
| Example                   | <b>SOUR1:ARB:BUIL:SQU 1000, 1000, 100</b><br><br>Creates a square wave 1000 points in length with a scale of 100 and a start address of 1000. |                              |

SOURCE[1|2]:ARB:BUILT:PULSe

Source Specific  
Command

|             |                                                                                                                      |  |
|-------------|----------------------------------------------------------------------------------------------------------------------|--|
| Description | Creates a pulse wave with a specified frequency and duty.                                                            |  |
| Syntax      | <b>SOURCE[1 2]:ARB:BUILT:PULSe</b><br><b>{[&lt;frequency&gt; MINimum MAXimum[,&lt;percent&gt; MINimum MAXimum]]}</b> |  |

|           |                |                                            |                 |
|-----------|----------------|--------------------------------------------|-----------------|
| Parameter | <frequency>    | Sets the pulse frequency                   |                 |
|           | <percent>      | Sets the duty of the pulse as a percentage |                 |
|           | *Frequency     | Resolution                                 | Duty Resolution |
|           | 1pHz~5Hz       | 1pHz                                       | 0.0001%         |
|           | > 5Hz~50Hz     | 1uHz                                       | 0.0001%         |
|           | > 50Hz~500Hz   | 10uHz                                      | 0.001%          |
|           | > 500Hz~5kHz   | 100uHz                                     | 0.01%           |
|           | > 5kHz~50kHz   | 1mHz                                       | 0.1%            |
|           | > 50kHz~500kHz | 10mHz                                      | 1%              |

Example **SOUR1:ARB:BUIL:PULSe +1.00000002E+03, +1.002E+01**

Creates a 1000.0002Hz pulse wave with a 10.02% duty cycle.

SOURCE[1|2]:ARB:BUILt:RAMP Source Specific Command

Description Creates a ramp wave with a specified start address, length and scale for the selected channel.

Syntax **SOURce[1]:ARB:BUILt:RAMP[<START>[,<LENGt h>[ ,<SCALE>]]]**

|           |          |                              |
|-----------|----------|------------------------------|
| Parameter | <START>  | Start address*:<br>0~8388606 |
|           | <LENGth> | Length*: 2~8388608           |

|             |                                                                                                                                          |                              |
|-------------|------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|
|             | <SCALE>                                                                                                                                  | Scale: $\pm 32767$           |
|             | * Start + Length $\leq 8388608$                                                                                                          |                              |
| Example     | <b>SOUR1:ARB:BUIL:RAMP 1000, 1000, 100</b><br>Creates a ramp wave 1000 points in length with a scale of 100 and a start address of 1000. |                              |
|             | SOURCE[1 2]:ARB:BUILt:SINC                                                                                                               | Source Specific Command      |
| Description | Creates a sinc wave with a specified start address, length and scale.                                                                    |                              |
| Syntax      | <b>SOURCE[1 2]:ARB:BUILt:SINC</b><br><b>[&lt;START&gt;[, &lt;LENGth&gt;[, &lt;SCALE&gt;]]]</b>                                           |                              |
| Parameter   | <START>                                                                                                                                  | Start address*:<br>0~8388606 |
|             | <LENGth>                                                                                                                                 | Length*: 2~8388608           |
|             | <SCALE>                                                                                                                                  | Scale: $\pm 32767$           |
|             | * Start + Length $\leq 8388608$                                                                                                          |                              |
| Example     | <b>SOUR1:ARB:BUIL:SINC 1000, 1000, 100</b><br>Creates a sinc wave 1000 points in length with a scale of 100 and a start address of 1000. |                              |

|                                      |                 |
|--------------------------------------|-----------------|
|                                      | Source Specific |
| <b>SOURce[1 2]:ARB:BUILt:EXPRise</b> | <b>Command</b>  |

|             |                                                                                                             |
|-------------|-------------------------------------------------------------------------------------------------------------|
| Description | Creates an exponential rise wave with a specified start address, length and scale for the selected channel. |
|-------------|-------------------------------------------------------------------------------------------------------------|

|        |                                                                                           |
|--------|-------------------------------------------------------------------------------------------|
| Syntax | <b>SOURce[1 2]:ARB:BUILt:EXPRise<br/>[&lt;START&gt;[,&lt;LENGth&gt;[,&lt;SCALE&gt;]]]</b> |
|--------|-------------------------------------------------------------------------------------------|

|                                 |          |                              |
|---------------------------------|----------|------------------------------|
| Parameter                       | <START>  | Start address*:<br>0~8388606 |
|                                 | <LENGth> | Length*: 2~8388608           |
|                                 | <SCALE>  | Scale: $\pm 32767$           |
| * Start + Length $\leq 8388608$ |          |                              |

|         |                                            |
|---------|--------------------------------------------|
| Example | <b>SOUR1:ARB:BUIL:EXPR 1000, 1000, 100</b> |
|---------|--------------------------------------------|

Creates an exponential rise wave 1000 points in length with a scale of 100 and a start address of 1000.

|                                      |                 |
|--------------------------------------|-----------------|
|                                      | Source Specific |
| <b>SOURce[1 2]:ARB:BUILt:EXPFall</b> | <b>Command</b>  |

|             |                                                                                    |
|-------------|------------------------------------------------------------------------------------|
| Description | Creates an exponential fall wave with a specified start address, length and scale. |
|-------------|------------------------------------------------------------------------------------|

|        |                                                                                           |
|--------|-------------------------------------------------------------------------------------------|
| Syntax | <b>SOURce[1 2]:ARB:BUILt:EXPFall<br/>[&lt;START&gt;[,&lt;LENGth&gt;[,&lt;SCALE&gt;]]]</b> |
|--------|-------------------------------------------------------------------------------------------|

|           |          |                              |
|-----------|----------|------------------------------|
| Parameter | <START>  | Start address*:<br>0~8388606 |
|           | <LENGth> | Length*: 2~8388608           |



|             |                                                                                                                                                           |                              |
|-------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|
|             | <SCALE>                                                                                                                                                   | Scale: $\pm 32767$           |
|             | * Start + Length $\leq 8388608$                                                                                                                           |                              |
| Example     | <b>SOUR1:ARB:BUIL:EXPF 1000, 1000, 100</b><br><br>Creates an exponential fall wave 1000 points in length with a scale of 100 and a start address of 1000. |                              |
|             | SOURCE[1 2]:ARB:BUILt:DC                                                                                                                                  | Source Specific<br>Command   |
| Description | Creates a DC waveform with a specified start address, length and scale.                                                                                   |                              |
| Syntax      | <b>SOURCE[1 2]:ARB:BUILt:DC</b><br><b>[&lt;START&gt;[,&lt;LENGTH&gt;[,&lt;Data&gt;]]]</b>                                                                 |                              |
| Parameter   | <START>                                                                                                                                                   | Start address*:<br>0~8388606 |
|             | <LENGTH>                                                                                                                                                  | Length*: 2~8388608           |
|             | <Data>                                                                                                                                                    | Data: $\pm 32767$            |
|             | * Start + Length $\leq 8388608$                                                                                                                           |                              |
| Example     | <b>SOUR1:ARB:BUIL:DC 1000, 1000, 100</b><br><br>Creates a DC waveform of 1000 points in length with a data of 100 and a start address of 1000.            |                              |
|             | SOURCE[1 2]:ARB:BUILt:stair_ud                                                                                                                            | Source Specific<br>Command   |
| Description | Creates an up& down staircase waveform(8 steps up, 8 steps down).                                                                                         |                              |

|                                 |                                                                                                                                                                  |                              |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|
| Syntax                          | <b>SOURce[1 2]:ARB:BUILt:stair_ud</b><br><b>[&lt;START&gt;[, &lt;LENGth&gt;[, &lt;SCALE&gt;]]]</b>                                                               |                              |
| Parameter                       | <START>                                                                                                                                                          | Start address*:<br>0~8388606 |
|                                 | <LENGth>                                                                                                                                                         | Length*: 2~8388608           |
|                                 | <SCALE>                                                                                                                                                          | Scale: $\pm 32767$           |
| * Start + Length $\leq$ 8388608 |                                                                                                                                                                  |                              |
| Example                         | <b>SOUR1:ARB:BUIL:stair_ud 1000, 1000, 100</b><br>Creates an up & down staircase waveform 1000 points in length with a scale of 100 and a start address of 1000. |                              |

Source Specific

---

SOURce[1|2]:ARB:BUILt:stair\_down
Command

---

|                                 |                                                                                                                                                         |                              |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|
| Description                     | Creates an 8-step down-staircase waveform.                                                                                                              |                              |
| Syntax                          | <b>SOURce[1 2]:ARB:BUILt:stair_down</b><br><b>[&lt;START&gt;[, &lt;LENGth&gt;[, &lt;SCALE&gt;]]]</b>                                                    |                              |
| Parameter                       | <START>                                                                                                                                                 | Start address*:<br>0~8388606 |
|                                 | <LENGth>                                                                                                                                                | Length*: 2~8388608           |
|                                 | <SCALE>                                                                                                                                                 | Scale: $\pm 32767$           |
| * Start + Length $\leq$ 8388608 |                                                                                                                                                         |                              |
| Example                         | <b>SOUR1:ARB:BUIL:stair_down 1000, 1000, 100</b><br>Creates a staircase waveform 1000 points in length with a scale of 100 and a start address of 1000. |                              |

SOURCE[1|2]:ARB:BUILT:stair\_up

Source Specific  
Command

|                            |                                                                                            |                              |
|----------------------------|--------------------------------------------------------------------------------------------|------------------------------|
| Description                | Creates an 8-step up-staircase waveform.                                                   |                              |
| Syntax                     | <b>SOURCE[1 2]:ARB:BUILT:stair_up<br/>[&lt;START&gt;[,&lt;LENGTH&gt;[,&lt;SCALE&gt;]]]</b> |                              |
| Parameter                  | <START>                                                                                    | Start address*:<br>0~8388606 |
|                            | <LENGTH>                                                                                   | Length*: 2~8388608           |
|                            | <SCALE>                                                                                    | Scale: ±32767                |
| * Start + Length ≤ 8388608 |                                                                                            |                              |

Example

**SOURCE1:ARB:BUILT:stair\_up 1000, 1000, 100**  
Creates a staircase waveform 1000 points in length with a scale of 100 and a start address of 1000.

SOURCE[1|2]:ARB:BUILT:absatan

Source Specific  
Command

|                            |                                                                                           |                              |
|----------------------------|-------------------------------------------------------------------------------------------|------------------------------|
| Description                | Creates an absolute atan waveform.                                                        |                              |
| Syntax                     | <b>SOURCE[1 2]:ARB:BUILT:absatan<br/>[&lt;START&gt;[,&lt;LENGTH&gt;[,&lt;SCALE&gt;]]]</b> |                              |
| Parameter                  | <START>                                                                                   | Start address*:<br>0~8388606 |
|                            | <LENGTH>                                                                                  | Length*: 2~8388608           |
|                            | <SCALE>                                                                                   | Scale: ±32767                |
| * Start + Length ≤ 8388608 |                                                                                           |                              |

**Example**                      **SOUR1:ARB:BUIL:absatan 1000, 1000, 100**

Creates an absolute atan waveform 1000 points in length with a scale of 100 and a start address of 1000.

Source Specific

**SOURce[1|2]:ARB:BUILt:abssin**                      Command

**Description**                      Creates an absolute sine waveform.

**Syntax**                      **SOURce[1|2]:ARB:BUILt:abssin**  
**[<START>[,<LENGth>[,<SCALE>]]]**

|                            |          |                              |
|----------------------------|----------|------------------------------|
| <b>Parameter</b>           | <START>  | Start address*:<br>0~8388606 |
|                            | <LENGth> | Length*: 2~8388608           |
|                            | <SCALE>  | Scale: ±32767                |
| * Start + Length ≤ 8388608 |          |                              |

**Example**                      **SOUR1:ARB:BUIL:abssin 1000, 1000, 100**

Creates an absolute sine waveform 1000 points in length with a scale of 100 and a start address of 1000.

Source Specific

**SOURce[1|2]:ARB:BUILt:abssinehalf**                      Command

**Description**                      Creates an absolute half sine waveform.

**Syntax**                      **SOURce[1|2]:ARB:BUILt:abssinehalf**  
**[<START>[,<LENGth>[,<SCALE>]]]**

|                            |                                                                             |                                                                             |
|----------------------------|-----------------------------------------------------------------------------|-----------------------------------------------------------------------------|
| Parameter                  | <div>&lt;START&gt;</div> <div>&lt;LENGth&gt;</div> <div>&lt;SCALe&gt;</div> | Start address*:<br>0~8388606<br><br>Length*: 2~8388608<br><br>Scale: ±32767 |
| * Start + Length ≤ 8388608 |                                                                             |                                                                             |

Example      **SOUR1:ARB:BUIL:abssinehalf 1000, 1000, 100**

Creates an absolute sine half waveform 1000 points in length with a scale of 100 and a start address of 1000.

SOURce[1|2]:ARB:BUILt:ampalt

Source Specific  
Command

Description      Creates an amplifying oscillation waveform.

Syntax      **SOURce[1|2]:ARB:BUILt:ampalt**  
**[<START>[,<LENGth>[,<SCALe>]]]**

|                            |                                                                             |                                                                             |
|----------------------------|-----------------------------------------------------------------------------|-----------------------------------------------------------------------------|
| Parameter                  | <div>&lt;START&gt;</div> <div>&lt;LENGth&gt;</div> <div>&lt;SCALe&gt;</div> | Start address*:<br>0~8388606<br><br>Length*: 2~8388608<br><br>Scale: ±32767 |
| * Start + Length ≤ 8388608 |                                                                             |                                                                             |

Example      **SOUR1:ARB:BUIL:ampalt 1000, 1000, 100**

Creates anamplifying oscillating waveform 1000 points in length with a scale of 100 and a start address of 1000.

Source Specific  
Command

**SOURce[1|2]:ARB:BUILt:attalt**

Description      Creates an attenuated oscillation waveform.

Syntax      **SOURce[1|2]:ARB:BUILt:attalt  
[<START>[,<LENGth>[,<SCALE>]]]**

|           |          |                              |
|-----------|----------|------------------------------|
| Parameter | <START>  | Start address*:<br>0~8388606 |
|           | <LENGth> | Length*: 2~8388608           |
|           | <SCALE>  | Scale: ±32767                |

\* Start + Length ≤ 8388608

Example      **SOUR1:ARB:BUIL:attalt 1000, 1000, 100**

Creates an attenuated oscillating waveform 1000 points in length with a scale of 100 and a start address of 1000.

Source Specific  
Command

**SOURce[1|2]:ARB:BUILt:diric\_even**

Description      Creates an even Dirichlet kernel waveform.

Syntax      **SOURce[1|2]:ARB:BUILt:diric\_even  
[<START>[,<LENGth>[,<SCALE>]]]**

|           |          |                              |
|-----------|----------|------------------------------|
| Parameter | <START>  | Start address*:<br>0~8388606 |
|           | <LENGth> | Length*: 2~8388608           |
|           | <SCALE>  | Scale: ±32767                |

\* Start + Length ≤ 8388608

Example                   **SOUR1:ARB:BUIL:diric\_even 1000, 1000, 100**

Creates an even diric waveform 1000 points in length with a scale of 100 and a start address of 1000.

SOURce[1|2]:ARB:BUILt:diric\_odd                   Source Specific Command

Description           Creates an odd diric waveform.

Syntax                   **SOURce[1|2]:ARB:BUILt:diric\_odd**  
**[<START>[,<LENGth>[,<SCALE>]]]**

|           |          |                              |
|-----------|----------|------------------------------|
| Parameter | <START>  | Start address*:<br>0~8388606 |
|           | <LENGth> | Length*: 2~8388608           |
|           | <SCALE>  | Scale: ±32767                |

\* Start + Length ≤ 8388608

Example                   **SOUR1:ARB:BUIL:diric\_odd 1000, 1000, 100**

Creates an oddDiric waveform 1000 points in length with a scale of 100 and a start address of 1000.

SOURce[1|2]:ARB:BUILt:gauspuls                   Source Specific Command

Description           Creates a Gaussian-modulated sinusoidal pulse waveform.

Syntax                   **SOURce[1|2]:ARB:BUILt:gauspuls**  
**[<START>[,<LENGth>[,<SCALE>]]]**

|                            |          |                              |
|----------------------------|----------|------------------------------|
| Parameter                  | <START>  | Start address*:<br>0~8388606 |
|                            | <LENGth> | Length*: 2~8388608           |
|                            | <SCALe>  | Scale: ±32767                |
| * Start + Length ≤ 8388608 |          |                              |

**Example**      **SOUR1:ARB:BUIL:gauspuls 1000, 1000, 100**

Creates a Gaussian-pulse waveform 1000 points in length with a scale of 100 and a start address of 1000.

SOURce[1|2]:ARB:BUILt:havercosine      Source Specific Command

**Description**      Creates a havercosine waveform.

**Syntax**      **SOURce[1|2]:ARB:BUILt:havercosine[<START>[, <LENGth>[,<SCALe>]]]**

|                            |          |                              |
|----------------------------|----------|------------------------------|
| Parameter                  | <START>  | Start address*:<br>0~8388606 |
|                            | <LENGth> | Length*: 2~8388608           |
|                            | <SCALe>  | Scale: ±32767                |
| * Start + Length ≤ 8388608 |          |                              |

**Example**      **SOUR1:ARB:BUIL:havercosine 1000, 1000, 100**

Creates a havercosine waveform 1000 points in length with a scale of 100 and a start address of 1000.



SOURCE[1|2]:ARB:BUILT:haversine

Source Specific Command

|                            |                                                                                        |                              |
|----------------------------|----------------------------------------------------------------------------------------|------------------------------|
| Description                | Creates a haversine waveform.                                                          |                              |
| Syntax                     | <b>SOURCE[1 2]:ARB:BUILT:haversine[&lt;START&gt;[,&lt;LENGTH&gt;[,&lt;SCALE&gt;]]]</b> |                              |
| Parameter                  | <START>                                                                                | Start address*:<br>0~8388606 |
|                            | <LENGTH>                                                                               | Length*: 2~8388608           |
|                            | <SCALE>                                                                                | Scale: ±32767                |
| * Start + Length ≤ 8388608 |                                                                                        |                              |

Example

**SOURCE1:ARB:BUILT:haversin 1000, 1000, 100**  
Creates a haversine waveform 1000 points in length with a scale of 100 and a start address of 1000.

SOURCE[1|2]:ARB:BUILT:n\_pulse

Source Specific Command

|             |                                                                                      |                              |
|-------------|--------------------------------------------------------------------------------------|------------------------------|
| Description | Creates a negative pulse waveform.                                                   |                              |
| Syntax      | <b>SOURCE[1 2]:ARB:BUILT:n_pulse[&lt;START&gt;[,&lt;LENGTH&gt;[,&lt;SCALE&gt;]]]</b> |                              |
| Parameter   | <START>                                                                              | Start address*:<br>0~8388606 |
|             | <LENGTH>                                                                             | Length*: 2~8388608           |
|             | <SCALE>                                                                              | Scale: ±32767                |

\* Start + Length ≤ 8388608

Example

**SOUR1:ARB:BUIL:n\_pulse 1000, 1000, 100**

Creates a negative pulse waveform 1000 points in length with a scale of 100 and a start address of 1000.

Source Specific

SOURce[1|2]:ARB:BUILt:negramp

Command

Description

Creates a negative ramp pulse waveform.

Syntax

**SOURce[1|2]:ARB:BUILt:negramp**

**[<START>[, <LENGTH>[, <SCALE>]]]**

Parameter

<START>

Start address\*:

0~8388606

<LENGTH>

Length\*: 2~8388608

<SCALE>

Scale: ±32767

\* Start + Length ≤ 8388608

Example

**SOUR1:ARB:BUIL:negramp 1000, 1000, 100**

Creates a negative ramp waveform 1000 points in length with a scale of 100 and a start address of 1000.

Source Specific

SOURce[1|2]:ARB:BUILt:rectpuls

Command

Description

Creates a rectangular pulse.

Syntax

**SOURce[1|2]:ARB:BUILt:rectpuls**

**[<START>[, <LENGTH>[, <SCALE>]]]**

|                            |          |                              |
|----------------------------|----------|------------------------------|
| Parameter                  | <START>  | Start address*:<br>0~8388606 |
|                            | <LENGTh> | Length*: 2~8388608           |
|                            | <SCALe>  | Scale: ±32767                |
| * Start + Length ≤ 8388608 |          |                              |

**Example**                    **SOUR1:ARB:BUIL:rectpuls 1000, 1000, 100**

Creates a rectangular pulse waveform 1000 points in length with a scale of 100 and a start address of 1000.

SOURce[1|2]:ARB:BUILt:roundhalf                    Source Specific Command

**Description**                    Creates a positive half circle ( $y=\sqrt{1-x^2}$ ).

**Syntax**                    **SOURce[1|2]:ARB:BUILt:roundhalf**  
**[<START>[,<LENGTh>[,<SCALe>]]]**

|                            |          |                              |
|----------------------------|----------|------------------------------|
| Parameter                  | <START>  | Start address*:<br>0~8388606 |
|                            | <LENGTh> | Length*: 2~8388608           |
|                            | <SCALe>  | Scale: ±32767                |
| * Start + Length ≤ 8388608 |          |                              |

**Example**                    **SOUR1:ARB:BUIL:roundhalf 1000, 1000, 100**

Creates a positive half circlewaveform 1000 points in length with a scale of 100 and a start address of 1000.

|                               |                                                                                                                                                         | Source Specific Command      |
|-------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|
| SOURce[1 2]:ARB:BUILt:sawtoot |                                                                                                                                                         |                              |
| Description                   | Creates a sawtooth waveform.                                                                                                                            |                              |
| Syntax                        | <b>SOURce[1 2]:ARB:BUILt:sawtoot</b><br><b>[&lt;START&gt;[,&lt;LENGth&gt;[,&lt;SCALE&gt;]]]</b>                                                         |                              |
| Parameter                     | <START>                                                                                                                                                 | Start address*:<br>0~8388606 |
|                               | <LENGth>                                                                                                                                                | Length*: 2~8388608           |
|                               | <SCALE>                                                                                                                                                 | Scale: ±32767                |
| * Start + Length ≤ 8388608    |                                                                                                                                                         |                              |
| Example                       | <b>SOUR1:ARB:BUIL:sawtoot 1000, 1000, 100</b><br><br>Creates a sawtooth waveform 1000 points in length with a scale of 100 and a start address of 1000. |                              |

|                               |                                                                                                 | Source Specific Command      |
|-------------------------------|-------------------------------------------------------------------------------------------------|------------------------------|
| SOURce[1 2]:ARB:BUILt:sinetra |                                                                                                 |                              |
| Description                   | Creates a piecewise sine wave.                                                                  |                              |
| Syntax                        | <b>SOURce[1 2]:ARB:BUILt:sinetra</b><br><b>[&lt;START&gt;[,&lt;LENGth&gt;[,&lt;SCALE&gt;]]]</b> |                              |
| Parameter                     | <START>                                                                                         | Start address*:<br>0~8388606 |
|                               | <LENGth>                                                                                        | Length*: 2~8388608           |
|                               | <SCALE>                                                                                         | Scale: ±32767                |
| * Start + Length ≤ 8388608    |                                                                                                 |                              |

|             |                                                                                                                                                               |                              |
|-------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|
| Example     | <b>SOUR1:ARB:BUIL:sinetra 1000, 1000, 100</b><br><br>Creates a piecewise sine waveform 1000 points in length with a scale of 100 and a start address of 1000. |                              |
|             |                                                                                                                                                               | Source Specific              |
|             | <b>SOURce[1 2]:ARB:BUILt:stepresp</b>                                                                                                                         | Command                      |
| Description | Creates a Heaviside step function(step response).                                                                                                             |                              |
| Syntax      | <b>SOURce[1 2]:ARB:BUILt:stepresp</b><br><b>[&lt;START&gt;[,&lt;LENGth&gt;[,&lt;SCALE&gt;]]]</b>                                                              |                              |
| Parameter   | <START>                                                                                                                                                       | Start address*:<br>0~8388606 |
|             | <LENGth>                                                                                                                                                      | Length*: 2~8388608           |
|             | <SCALE>                                                                                                                                                       | Scale: ±32767                |
|             | * Start + Length ≤ 8388608                                                                                                                                    |                              |
| Example     | <b>SOUR1:ARB:BUIL:stepresp 1000, 1000, 100</b><br><br>Creates aHeaviside sine waveform 1000 points in length with a scale of 100 and a start address of 1000. |                              |
|             |                                                                                                                                                               | Source Specific              |
|             | <b>SOURce[1 2]:ARB:BUILt:sinever</b>                                                                                                                          | Command                      |
| Description | Creates piecewise sine wave (clipped to 0 at 0° to 90° and 180° to 270°).                                                                                     |                              |
| Syntax      | <b>SOURce[1 2]:ARB:BUILt:sinever</b><br><b>[&lt;START&gt;[,&lt;LENGth&gt;[,&lt;SCALE&gt;]]]</b>                                                               |                              |

|                            |          |                              |
|----------------------------|----------|------------------------------|
| Parameter                  | <START>  | Start address*:<br>0~8388606 |
|                            | <LENGth> | Length*: 2~8388608           |
|                            | <SCALE>  | Scale: ±32767                |
| * Start + Length ≤ 8388608 |          |                              |

Example      **SOUR1:ARB:BUIL:sinever 1000, 1000, 100**

Creates apiecewise sine wave waveform 1000 points in length with a scale of 100 and a start address of 1000.

|                                |                            |
|--------------------------------|----------------------------|
| SOURce[1 2]:ARB:BUILt:trapezia | Source Specific<br>Command |
|--------------------------------|----------------------------|

|             |                              |
|-------------|------------------------------|
| Description | Creates atrapezoid waveform. |
|-------------|------------------------------|

|        |                                                                                            |
|--------|--------------------------------------------------------------------------------------------|
| Syntax | <b>SOURce[1 2]:ARB:BUILt:trapezia<br/>[&lt;START&gt;[,&lt;LENGth&gt;[,&lt;SCALE&gt;]]]</b> |
|--------|--------------------------------------------------------------------------------------------|

|                            |          |                              |
|----------------------------|----------|------------------------------|
| Parameter                  | <START>  | Start address*:<br>0~8388606 |
|                            | <LENGth> | Length*: 2~8388608           |
|                            | <SCALE>  | Scale: ±32767                |
| * Start + Length ≤ 8388608 |          |                              |

Example      **SOUR1:ARB:BUIL:trapezia 1000, 1000, 100**

Creates trapezoid waveform 1000 points in length with a scale of 100 and a start address of 1000.

SOURCE[1|2]:ARB:BUILT:tripulsl

Source Specific Command

|                            |                                                                                                  |                              |
|----------------------------|--------------------------------------------------------------------------------------------------|------------------------------|
| Description                | Creates a triangular pulse waveform.                                                             |                              |
| Syntax                     | <b>SOURCE[1 2]:ARB:BUILT:tripulsl</b><br><b>[&lt;START&gt;[,&lt;LENGTH&gt;[,&lt;SCALE&gt;]]]</b> |                              |
| Parameter                  | <START>                                                                                          | Start address*:<br>0~8388606 |
|                            | <LENGTH>                                                                                         | Length*: 2~8388608           |
|                            | <SCALE>                                                                                          | Scale: ±32767                |
| * Start + Length ≤ 8388608 |                                                                                                  |                              |

**Example**                    **SOURCE1:ARB:BUILT:tripulsl 1000, 1000, 100**

Creates triangular pulse waveform 1000 points in length with a scale of 100 and a start address of 1000.

SOURCE[1|2]:ARB:BUILT:dlorentz

Source Specific Command

|             |                                                                                                  |                              |
|-------------|--------------------------------------------------------------------------------------------------|------------------------------|
| Description | Creates a derivative of the Lorentz function waveform.                                           |                              |
| Syntax      | <b>SOURCE[1 2]:ARB:BUILT:dlorentz</b><br><b>[&lt;START&gt;[,&lt;LENGTH&gt;[,&lt;SCALE&gt;]]]</b> |                              |
| Parameter   | <START>                                                                                          | Start address*:<br>0~8388606 |
|             | <LENGTH>                                                                                         | Length*: 2~8388608           |
|             | <SCALE>                                                                                          | Scale: ±32767                |

\* Start + Length ≤ 8388608

Example

**SOUR1:ARB:BUIL:dlorentz 1000, 1000, 100**

Creates a derivative of Lorentz function waveform 1000 points in length with a scale of 100 and a start address of 1000.

Source Specific

SOURce[1|2]:ARB:BUILt:gauss

Command

Description

Creates a gauss bell curve waveform.

Syntax

**SOURce[1|2]:ARB:BUILt:gauss**  
**[<START>[, <LENGth>[, <SCALe>]]]**

Parameter

|          |                              |
|----------|------------------------------|
| <START>  | Start address*:<br>0~8388606 |
| <LENGth> | Length*: 2~8388608           |
| <SCALe>  | Scale: ±32767                |

\* Start + Length ≤ 8388608

Example

**SOUR1:ARB:BUIL:gauss 1000, 1000, 100**

Creates a gauss bell curve waveform 1000 points in length with a scale of 100 and a start address of 1000.

Source Specific

SOURce[1|2]:ARB:BUILt:ln

Command

Description

Creates natural logarithm waveform.

Syntax

**SOURce[1|2]:ARB:BUILt:ln**  
**[<START>[, <LENGth>[, <SCALe>]]]**



|                            |          |                              |
|----------------------------|----------|------------------------------|
| Parameter                  | <START>  | Start address*:<br>0~8388606 |
|                            | <LENGTh> | Length*: 2~8388608           |
|                            | <SCALe>  | Scale: ±32767                |
| * Start + Length ≤ 8388608 |          |                              |

|         |                                                                                                                                                             |
|---------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Example | <b>SOUR1:ARB:BUIL:ln 1000, 1000, 100</b><br><br>Creates a natural logarithm waveform 1000 points in length with a scale of 100 and a start address of 1000. |
|---------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|

|                               |                 |
|-------------------------------|-----------------|
|                               | Source Specific |
| SOURce[1 2]:ARB:BUILT:lorentz | Command         |

|             |                                      |
|-------------|--------------------------------------|
| Description | Creates a Lorentz function waveform. |
|-------------|--------------------------------------|

|        |                                                                                                 |
|--------|-------------------------------------------------------------------------------------------------|
| Syntax | <b>SOURce[1 2]:ARB:BUILT:lorentz</b><br><b>[&lt;START&gt;[,&lt;LENGTh&gt;[,&lt;SCALe&gt;]]]</b> |
|--------|-------------------------------------------------------------------------------------------------|

|                            |          |                              |
|----------------------------|----------|------------------------------|
| Parameter                  | <START>  | Start address*:<br>0~8388606 |
|                            | <LENGTh> | Length*: 2~8388608           |
|                            | <SCALe>  | Scale: ±32767                |
| * Start + Length ≤ 8388608 |          |                              |

|         |                                                                                                                                                                 |
|---------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Example | <b>SOUR1:ARB:BUIL:lorentz 1000, 1000, 100</b><br><br>Creates a Lorentz function waveform 1000 points in length with a scale of 100 and a start address of 1000. |
|---------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|

SOURce[1|2]:ARB:BUILt:sinc Source Specific  
Command

Description Creates a cardinal sine function waveform.

Syntax **SOURce[1|2]:ARB:BUILt:sinc  
[<START>[,<LENGth>[,<SCALE>]]]**

|                            |          |                              |
|----------------------------|----------|------------------------------|
| Parameter                  | <START>  | Start address*:<br>0~8388606 |
|                            | <LENGth> | Length*: 2~8388608           |
|                            | <SCALE>  | Scale: ±32767                |
| * Start + Length ≤ 8388608 |          |                              |

Example **SOUR1:ARB:BUIL:sinc 1000, 1000, 100**  
Creates a cardinal sine function waveform 1000 points in length with a scale of 100 and a start address of 1000.

SOURce[1|2]:ARB:BUILt:sqrt Source Specific  
Command

Description Creates a square root function waveform.

Syntax **SOURce[1|2]:ARB:BUILt:sqrt  
[<START>[,<LENGth>[,<SCALE>]]]**

|           |          |                              |
|-----------|----------|------------------------------|
| Parameter | <START>  | Start address*:<br>0~8388606 |
|           | <LENGth> | Length*: 2~8388608           |
|           | <SCALE>  | Scale: ±32767                |

\* Start + Length ≤ 8388608

|         |                                                                                                                                                                  |
|---------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Example | <b>SOUR1:ARB:BUIL:sqrt 1000, 1000, 100</b><br><br>Creates a square root function waveform 1000 points in length with a scale of 100 and a start address of 1000. |
|---------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|                               |                 |
|-------------------------------|-----------------|
|                               | Source Specific |
| SOURce[1 2]:ARB:BUILt:xsquare | Command         |

|             |                                                          |
|-------------|----------------------------------------------------------|
| Description | Creates a quadratic (x <sup>2</sup> ) function waveform. |
|-------------|----------------------------------------------------------|

|        |                                                                                                 |
|--------|-------------------------------------------------------------------------------------------------|
| Syntax | <b>SOURce[1 2]:ARB:BUILt:xsquare</b><br><b>[&lt;START&gt;[,&lt;LENGth&gt;[,&lt;SCALE&gt;]]]</b> |
|--------|-------------------------------------------------------------------------------------------------|

|                            |                                                                                                                                                                                  |
|----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Parameter                  | <div><div>&lt;START&gt;</div><div>&lt;LENGth&gt;</div><div>&lt;SCALE&gt;</div></div> <div>Start address*:<br/>0~8388606<br/><br/>Length*: 2~8388608<br/><br/>Scale: ±32767</div> |
| * Start + Length ≤ 8388608 |                                                                                                                                                                                  |

|         |                                                                                                                                                                   |
|---------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Example | <b>SOUR1:ARB:BUIL:xsquare 1000, 1000, 100</b><br><br>Creates a quadratic function waveform 1000 points in length with a scale of 100 and a start address of 1000. |
|---------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|                              |                 |
|------------------------------|-----------------|
|                              | Source Specific |
| SOURce[1 2]:ARB:BUILt:arccos | Command         |

|             |                                             |
|-------------|---------------------------------------------|
| Description | Creates aninverse cosine function waveform. |
|-------------|---------------------------------------------|

|        |                                                                                                |
|--------|------------------------------------------------------------------------------------------------|
| Syntax | <b>SOURce[1 2]:ARB:BUILt:arccos</b><br><b>[&lt;START&gt;[,&lt;LENGth&gt;[,&lt;SCALE&gt;]]]</b> |
|--------|------------------------------------------------------------------------------------------------|

|                            |          |                              |
|----------------------------|----------|------------------------------|
| Parameter                  | <START>  | Start address*:<br>0~8388606 |
|                            | <LENGth> | Length*: 2~8388608           |
|                            | <SCALe>  | Scale: ±32767                |
| * Start + Length ≤ 8388608 |          |                              |

Example      **SOUR1:ARB:BUIL:arccos 1000, 1000, 100**

Creates an inverse cosine function waveform 1000 points in length with a scale of 100 and a start address of 1000.

|                              |                            |
|------------------------------|----------------------------|
| SOURce[1 2]:ARB:BUILt:arccot | Source Specific<br>Command |
|------------------------------|----------------------------|

|             |                                                |
|-------------|------------------------------------------------|
| Description | Creates an inversecotangent function waveform. |
|-------------|------------------------------------------------|

|        |                                                                                          |
|--------|------------------------------------------------------------------------------------------|
| Syntax | <b>SOURce[1 2]:ARB:BUILt:arccot<br/>[&lt;START&gt;[,&lt;LENGth&gt;[,&lt;SCALe&gt;]]]</b> |
|--------|------------------------------------------------------------------------------------------|

|                            |          |                              |
|----------------------------|----------|------------------------------|
| Parameter                  | <START>  | Start address*:<br>0~8388606 |
|                            | <LENGth> | Length*: 2~8388608           |
|                            | <SCALe>  | Scale: ±32767                |
| * Start + Length ≤ 8388608 |          |                              |

Example      **SOUR1:ARB:BUIL:arccot 1000, 1000, 100**

Creates an inversecotangent function waveform 1000 points in length with a scale of 100 and a start address of 1000.

SOURCE[1|2]:ARB:BUILT:arccsc

Source Specific  
Command

Description

Creates an inverse cosecant function waveform.

Syntax

**SOURCE[1|2]:ARB:BUILT:arccsc**  
**[<START>[,<LENGTH>[,<SCALE>]]]**

Parameter

<START>

Start address\*:  
0~8388606

<LENGTH>

Length\*: 2~8388608

<SCALE>

Scale: ±32767

\* Start + Length ≤ 8388608

Example

**SOURCE1:ARB:BUILT:arccsc 1000, 1000, 100**  
Creates an inverse cosecant function waveform  
1000 points in length with a scale of 100 and a start  
address of 1000.

SOURCE[1|2]:ARB:BUILT:arcsec

Source Specific  
Command

Description

Creates an inverse secant function waveform.

Syntax

**SOURCE[1|2]:ARB:BUILT:arcsec**  
**[<START>[,<LENGTH>[,<SCALE>]]]**

Parameter

<START>

Start address\*:  
0~8388606

<LENGTH>

Length\*: 2~8388608

<SCALE>

Scale: ±32767

|                               |                                                                                                                                                                                                                       |
|-------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| * Start + Length ≤ 8388608    |                                                                                                                                                                                                                       |
| Example                       | <div><b>SOUR1:ARB:BUIL:arccsc 1000, 1000, 100</b><br/>Creates an inverse secant function waveform 1000 points in length with a scale of 100 and a start address of 1000.</div> <div>Source Specific<br/>Command</div> |
| SOURce[1 2]:ARB:BUILt:arcsin  |                                                                                                                                                                                                                       |
| Description                   | Creates an inverse sine waveform.                                                                                                                                                                                     |
| Syntax                        | <b>SOURce[1 2]:ARB:BUILt:arcsin</b><br><b>[&lt;START&gt;[, &lt;LENGth&gt;[, &lt;SCALe&gt;]]]</b>                                                                                                                      |
| Parameter                     | <div><div>&lt;START&gt;</div><div>&lt;LENGth&gt;</div><div>&lt;SCALe&gt;</div><div>Start address*:<br/>0~8388606<br/>Length*: 2~8388608<br/>Scale: ±32767</div></div> <div>* Start + Length ≤ 8388608</div>           |
| Example                       | <div><b>SOUR1:ARB:BUIL:arcsin 1000, 1000, 100</b><br/>Creates an inverse sine waveform 1000 points in length with a scale of 100 and a start address of 1000.</div> <div>Source Specific<br/>Command</div>            |
| SOURce[1 2]:ARB:BUILt:arcsinh |                                                                                                                                                                                                                       |

|             |                                                                                                   |
|-------------|---------------------------------------------------------------------------------------------------|
| Description | Creates an inverse hyperbolic sine waveform.                                                      |
| Syntax      | <b>SOURce[1 2]:ARB:BUILt:arcsinh</b><br><b>[&lt;START&gt;[, &lt;LENGth&gt;[, &lt;SCALe&gt;]]]</b> |

|                            |          |                              |
|----------------------------|----------|------------------------------|
| Parameter                  | <START>  | Start address*:<br>0~8388606 |
|                            | <LENGth> | Length*: 2~8388608           |
|                            | <SCALe>  | Scale: ±32767                |
| * Start + Length ≤ 8388608 |          |                              |

|         |                                                                                                                                                                         |
|---------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Example | <b>SOUR1:ARB:BUIL:arcsinh 1000, 1000, 100</b><br><br>Creates an inverse hyperbolic sine waveform 1000 points in length with a scale of 100 and a start address of 1000. |
|---------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|                              |                 |
|------------------------------|-----------------|
|                              | Source Specific |
| SOURce[1 2]:ARB:BUILt:arctan | Command         |

|             |                                      |
|-------------|--------------------------------------|
| Description | Creates an inverse tangent waveform. |
|-------------|--------------------------------------|

|        |                                                                                          |
|--------|------------------------------------------------------------------------------------------|
| Syntax | <b>SOURce[1 2]:ARB:BUILt:arctan<br/>[&lt;START&gt;[,&lt;LENGth&gt;[,&lt;SCALe&gt;]]]</b> |
|--------|------------------------------------------------------------------------------------------|

|                            |          |                              |
|----------------------------|----------|------------------------------|
| Parameter                  | <START>  | Start address*:<br>0~8388606 |
|                            | <LENGth> | Length*: 2~8388608           |
|                            | <SCALe>  | Scale: ±32767                |
| * Start + Length ≤ 8388608 |          |                              |

|         |                                                                                                                                                                |
|---------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Example | <b>SOUR1:ARB:BUIL:arctan 1000, 1000, 100</b><br><br>Creates an inverse tangent waveform 1000 points in length with a scale of 100 and a start address of 1000. |
|---------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|

Source Specific  
Command

**SOURce[1|2]:ARB:BUILt:arctanh**

Description      Creates an inverse hyperbolic tangent waveform.

Syntax            **SOURce[1|2]:ARB:BUILt:arctanh[<START>[,<LENGth>[,<SCALE>]]]**

|           |          |                              |
|-----------|----------|------------------------------|
| Parameter | <START>  | Start address*:<br>0~8388606 |
|           | <LENGth> | Length*: 2~8388608           |
|           | <SCALE>  | Scale: ±32767                |

\* Start + Length ≤ 8388608

Example            **SOUR1:ARB:BUIL:arctanh 1000, 1000, 100**

Creates an inverse hyperbolic tangent waveform  
1000 points in length with a scale of 100 and a start  
address of 1000.

Source Specific  
Command

**SOURce[1|2]:ARB:BUILt:cosh**

Description      Creates a hyperbolic cosine waveform.

Syntax            **SOURce[1|2]:ARB:BUILt:cosh  
[<START>[,<LENGth>[,<SCALE>]]]**

|           |          |                              |
|-----------|----------|------------------------------|
| Parameter | <START>  | Start address*:<br>0~8388606 |
|           | <LENGth> | Length*: 2~8388608           |
|           | <SCALE>  | Scale: ±32767                |



\* Start + Length ≤ 8388608

Example                   **SOUR1:ARB:BUIL:cosh 1000, 1000, 100**

Creates a hyperbolic cosine waveform 1000 points in length with a scale of 100 and a start address of 1000.

SOURce[1|2]:ARB:BUILt:cot

Source Specific Command

Description           Creates a cotangent waveform.

Syntax                   **SOURce[1|2]:ARB:BUILt:cot[<START>[,<LENGTH>[,<SCALE>]]]**

|           |          |                              |
|-----------|----------|------------------------------|
| Parameter | <START>  | Start address*:<br>0~8388606 |
|           | <LENGTH> | Length*: 2~8388608           |
|           | <SCALE>  | Scale: ±32767                |

\* Start + Length ≤ 8388608

Example                   **SOUR1:ARB:BUIL:cot 1000, 1000, 100**

Creates a cotangent waveform 1000 points in length with a scale of 100 and a start address of 1000.

SOURce[1|2]:ARB:BUILt:csc

Source Specific Command

Description           Creates a cosecant waveform.

Syntax                   **SOURce[1|2]:ARB:BUILt:csc**  
**[<START>[,<LENGTH>[,<SCALE>]]]**

|                            |          |                              |
|----------------------------|----------|------------------------------|
| Parameter                  | <START>  | Start address*:<br>0~8388606 |
|                            | <LENGth> | Length*: 2~8388608           |
|                            | <SCALe>  | Scale: ±32767                |
| * Start + Length ≤ 8388608 |          |                              |

Example      **SOUR1:ARB:BUIL:csc 1000, 1000, 100**

Creates a cosecant waveform 1000 points in length with a scale of 100 and a start address of 1000.

|                           |                 |
|---------------------------|-----------------|
|                           | Source Specific |
| SOURce[1 2]:ARB:BUILt:sec | Command         |

Description      Creates a secant waveform.

Syntax      **SOURce[1|2]:ARB:BUILt:sec**  
**[<START>[,<LENGth>[,<SCALe>]]]**

|                            |          |                              |
|----------------------------|----------|------------------------------|
| Parameter                  | <START>  | Start address*:<br>0~8388606 |
|                            | <LENGth> | Length*: 2~8388608           |
|                            | <SCALe>  | Scale: ±32767                |
| * Start + Length ≤ 8388608 |          |                              |

Example      **SOUR1:ARB:BUIL:sec 1000, 1000, 100**

Creates a secant waveform 1000 points in length with a scale of 100 and a start address of 1000.

SOURCE[1|2]:ARB:BUILT:sech

Source Specific Command

|                            |                                                                                              |                              |
|----------------------------|----------------------------------------------------------------------------------------------|------------------------------|
| Description                | Creates a hyperbolic secant waveform.                                                        |                              |
| Syntax                     | <b>SOURCE[1 2]:ARB:BUILT:sech</b><br><b>[&lt;START&gt;[,&lt;LENGTH&gt;[,&lt;SCALE&gt;]]]</b> |                              |
| Parameter                  | <START>                                                                                      | Start address*:<br>0~8388606 |
|                            | <LENGTH>                                                                                     | Length*: 2~8388608           |
|                            | <SCALE>                                                                                      | Scale: ±32767                |
| * Start + Length ≤ 8388608 |                                                                                              |                              |

**Example**                    **SOURCE1:ARB:BUILT:sech 1000, 1000, 100**

Creates a hyperbolic secant waveform 1000 points in length with a scale of 100 and a start address of 1000.

SOURCE[1|2]:ARB:BUILT:sinh

Source Specific Command

|             |                                                                                              |                              |
|-------------|----------------------------------------------------------------------------------------------|------------------------------|
| Description | Creates a hyperbolic sine waveform.                                                          |                              |
| Syntax      | <b>SOURCE[1 2]:ARB:BUILT:sinh</b><br><b>[&lt;START&gt;[,&lt;LENGTH&gt;[,&lt;SCALE&gt;]]]</b> |                              |
| Parameter   | <START>                                                                                      | Start address*:<br>0~8388606 |
|             | <LENGTH>                                                                                     | Length*: 2~8388608           |
|             | <SCALE>                                                                                      | Scale: ±32767                |

|         |                                                                                                                                                             |
|---------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|
|         | * Start + Length ≤ 8388608                                                                                                                                  |
| Example | <b>SOUR1:ARB:BUIL:sinh 1000, 1000, 100</b><br><br>Creates a hyperbolic sine waveform 1000 points in length with a scale of 100 and a start address of 1000. |

|                           |                 |
|---------------------------|-----------------|
|                           | Source Specific |
| SOURce[1 2]:ARB:BUILt:tan | Command         |

|             |                             |
|-------------|-----------------------------|
| Description | Creates a tangent waveform. |
|-------------|-----------------------------|

|        |                                                                                      |
|--------|--------------------------------------------------------------------------------------|
| Syntax | <b>SOURce[1 2]:ARB:BUILt:tan[&lt;START&gt; [, &lt;LENGth&gt; [, &lt;SCALe&gt;]]]</b> |
|--------|--------------------------------------------------------------------------------------|

|           |                            |                              |
|-----------|----------------------------|------------------------------|
| Parameter | <START>                    | Start address*:<br>0~8388606 |
|           | <LENGth>                   | Length*: 2~8388608           |
|           | <SCALe>                    | Scale: ±32767                |
|           | * Start + Length ≤ 8388608 |                              |

|         |                                                                                                                                                    |
|---------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| Example | <b>SOUR1:ARB:BUIL:tan 1000, 1000, 100</b><br><br>Creates a tangent waveform 1000 points in length with a scale of 100 and a start address of 1000. |
|---------|----------------------------------------------------------------------------------------------------------------------------------------------------|

|                            |                 |
|----------------------------|-----------------|
|                            | Source Specific |
| SOURce[1 2]:ARB:BUILt:tanh | Command         |

|             |                                        |
|-------------|----------------------------------------|
| Description | Creates a hyperbolic tangent waveform. |
|-------------|----------------------------------------|

|        |                                                                                            |
|--------|--------------------------------------------------------------------------------------------|
| Syntax | <b>SOURce[1 2]:ARB:BUILt:tanh<br/>[&lt;START&gt; [, &lt;LENGth&gt; [, &lt;SCALe&gt;]]]</b> |
|--------|--------------------------------------------------------------------------------------------|

|                            |          |                              |
|----------------------------|----------|------------------------------|
| Parameter                  | <STARt>  | Start address*:<br>0~8388606 |
|                            | <LENGth> | Length*: 2~8388608           |
|                            | <SCALe>  | Scale: ±32767                |
| * Start + Length ≤ 8388608 |          |                              |

|         |                                                                                                                                                                |
|---------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Example | <b>SOUR1:ARB:BUIL:tanh 1000, 1000, 100</b><br><br>Creates a hyperbolic tangent waveform 1000 points in length with a scale of 100 and a start address of 1000. |
|---------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|

|                                   |                 |
|-----------------------------------|-----------------|
|                                   | Source Specific |
| SOURce[1 2]:ARB:BUILt:barthannwin | Command         |

|             |                                                   |
|-------------|---------------------------------------------------|
| Description | Creates a Bartlett-Hann window function waveform. |
|-------------|---------------------------------------------------|

|        |                                                                                                    |
|--------|----------------------------------------------------------------------------------------------------|
| Syntax | <b>SOURce[1 2]:ARB:BUILT:barthannwin</b><br><b>[&lt;STARt&gt;[,&lt;LENGth&gt;,&lt;SCALe&gt;]]]</b> |
|--------|----------------------------------------------------------------------------------------------------|

|                            |          |                              |
|----------------------------|----------|------------------------------|
| Parameter                  | <STARt>  | Start address*:<br>0~8388606 |
|                            | <LENGth> | Length*: 2~8388608           |
|                            | <SCALe>  | Scale: ±32767                |
| * Start + Length ≤ 8388608 |          |                              |

|         |                                                                                                                                                                                  |
|---------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Example | <b>SOUR1:ARB:BUIL:barthannwin 1000, 1000, 100</b><br><br>Creates a Bartlett-Hann window function waveform 1000 points in length with a scale of 100 and a start address of 1000. |
|---------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

SOURce[1|2]:ARB:BUILt:bartlett Source Specific  
Command

Description Creates a Bartlett window function waveform.

Syntax **SOURce[1|2]:ARB:BUILt:bartlett  
[<START>[,<LENGth>[,<SCALE>]]]**

|           |          |                              |
|-----------|----------|------------------------------|
| Parameter | <START>  | Start address*:<br>0~8388606 |
|           | <LENGth> | Length*: 2~8388608           |
|           | <SCALE>  | Scale: ±32767                |

\* Start + Length ≤ 8388608

Example **SOUR1:ARB:BUIL:bartlett 1000, 1000, 100**  
Creates a Bartlett window function waveform 1000 points in length with a scale of 100 and a start address of 1000.

SOURce[1|2]:ARB:BUILt:blackman Source Specific  
Command

Description Creates a Blackman window function waveform.

Syntax **SOURce[1|2]:ARB:BUILt:blackman  
[<START>[,<LENGth>[,<SCALE>]]]**

|           |          |                              |
|-----------|----------|------------------------------|
| Parameter | <START>  | Start address*:<br>0~8388606 |
|           | <LENGth> | Length*: 2~8388608           |
|           | <SCALE>  | Scale: ±32767                |

\* Start + Length ≤ 8388608

Example                   **SOUR1:ARB:BUIL:blackman 1000, 1000, 100**

Creates a Blackman window function waveform  
1000 points in length with a scale of 100 and a start  
address of 1000.

SOURce[1|2]:ARB:BUILt:bohmanwin                   Source Specific  
Command

Description           Creates a Bohmanwin window function waveform.

Syntax                   **SOURce[1|2]:ARB:BUILt:bohmanwin**  
**[<START>[,<LENGth>[,<SCALE>]]]**

|           |          |                              |
|-----------|----------|------------------------------|
| Parameter | <START>  | Start address*:<br>0~8388606 |
|           | <LENGth> | Length*: 2~8388608           |
|           | <SCALE>  | Scale: ±32767                |

\* Start + Length ≤ 8388608

Example                   **SOUR1:ARB:BUIL:bohmanwin 1000, 1000, 100**

Creates a Bohmanwin window function waveform  
1000 points in length with a scale of 100 and a start  
address of 1000.

SOURce[1|2]:ARB:BUILt:chebwin                   Source Specific  
Command

Description           Creates a Chebyshev window function waveform.

Syntax                   **SOURce[1|2]:ARB:BUILt:chebwin**  
**[<START>[,<LENGth>[,<SCALE>]]]**

|                            |          |                              |
|----------------------------|----------|------------------------------|
| Parameter                  | <START>  | Start address*:<br>0~8388606 |
|                            | <LENGth> | Length*: 2~8388608           |
|                            | <SCALe>  | Scale: ±32767                |
| * Start + Length ≤ 8388608 |          |                              |

Example      **SOUR1:ARB:BUIL:chebwin 1000, 1000, 100**

Creates a Chebyshev window function waveform 1000 points in length with a scale of 100 and a start address of 1000.

|                                  |                            |
|----------------------------------|----------------------------|
| SOURce[1 2]:ARB:BUILt:flattopwin | Source Specific<br>Command |
|----------------------------------|----------------------------|

|             |                                                       |
|-------------|-------------------------------------------------------|
| Description | Creates a flat top weighted window function waveform. |
|-------------|-------------------------------------------------------|

|        |                                                                                           |
|--------|-------------------------------------------------------------------------------------------|
| Syntax | <b>SOURce[1 2]:ARB:BUILt:chebwin<br/>[&lt;START&gt;[,&lt;LENGth&gt;[,&lt;SCALe&gt;]]]</b> |
|--------|-------------------------------------------------------------------------------------------|

|                            |          |                              |
|----------------------------|----------|------------------------------|
| Parameter                  | <START>  | Start address*:<br>0~8388606 |
|                            | <LENGth> | Length*: 2~8388608           |
|                            | <SCALe>  | Scale: ±32767                |
| * Start + Length ≤ 8388608 |          |                              |

Example      **SOUR1:ARB:BUIL:chebwin 1000, 1000, 100**

Creates a flat top weighted window function waveform 1000 points in length with a scale of 100 and a start address of 1000.



SOURCE[1|2]:ARB:BUILT:hamming

Source Specific Command

Description      Creates a Hamming window function waveform.

Syntax            **SOURCE[1|2]:ARB:BUILT:hamming**  
**[<START>[,<LENGTH>[,<SCALE>]]]**

|           |          |                              |
|-----------|----------|------------------------------|
| Parameter | <START>  | Start address*:<br>0~8388606 |
|           | <LENGTH> | Length*: 2~8388608           |
|           | <SCALE>  | Scale: ±32767                |

\* Start + Length ≤ 8388608

Example            **SOURCE1:ARB:BUILT:hamming 1000, 1000, 100**

Creates a Hamming window function waveform  
1000 points in length with a scale of 100 and a start  
address of 1000.

SOURCE[1|2]:ARB:BUILT:hann

Source Specific Command

Description      Creates a Hann window function waveform.

Syntax            **SOURCE[1|2]:ARB:BUILT:hann**  
**[<START>[,<LENGTH>[,<SCALE>]]]**

|           |          |                              |
|-----------|----------|------------------------------|
| Parameter | <START>  | Start address*:<br>0~8388606 |
|           | <LENGTH> | Length*: 2~8388608           |
|           | <SCALE>  | Scale: ±32767                |

\* Start + Length  $\leq$  8388608

**Example**      **SOUR1:ARB:BUIL:hann 1000, 1000, 100**

Creates a Hann window function waveform 1000 points in length with a scale of 100 and a start address of 1000.

Source Specific

**SOURce[1|2]:ARB:BUILT:kaiser**      Command

**Description**      Creates a Kasier window function waveform.

**Syntax**      **SOURce[1|2]:ARB:BUILT:kaiser**  
**[<START>[, <LENGth>[, <SCALE>]]]**

|                  |          |                              |
|------------------|----------|------------------------------|
| <b>Parameter</b> | <START>  | Start address*:<br>0~8388606 |
|                  | <LENGth> | Length*: 2~8388608           |
|                  | <SCALE>  | Scale: $\pm 32767$           |

\* Start + Length  $\leq$  8388608

**Example**      **SOUR1:ARB:BUIL:kaiser 1000, 1000, 100**

Creates a Kaiser window function waveform 1000 points in length with a scale of 100 and a start address of 1000.

Source Specific

**SOURce[1|2]:ARB:BUILT:traing**      Command

**Description**      Creates a Triangle window function waveform.

**Syntax**      **SOURce[1|2]:ARB:BUILT:traing**  
**[<START>[, <LENGth>[, <SCALE>]]]**

|                            |          |                              |
|----------------------------|----------|------------------------------|
| Parameter                  | <START>  | Start address*:<br>0~8388606 |
|                            | <LENGTh> | Length*: 2~8388608           |
|                            | <SCALE>  | Scale: ±32767                |
| * Start + Length ≤ 8388608 |          |                              |

Example      **SOUR1:ARB:BUIL:traing 1000, 1000, 100**

Creates a Triangle window function waveform  
1000 points in length with a scale of 100 and a start  
address of 1000.

|                                |                 |
|--------------------------------|-----------------|
|                                | Source Specific |
| SOURce[1 2]:ARB:BUILt:tukeywin | Command         |

|             |                                           |
|-------------|-------------------------------------------|
| Description | Creates a Tukey window function waveform. |
|-------------|-------------------------------------------|

|        |                                                                                         |
|--------|-----------------------------------------------------------------------------------------|
| Syntax | <b>SOURce[1 2]:ARB:BUILt:tukey<br/>[&lt;START&gt;[,&lt;LENGTh&gt;[,&lt;SCALE&gt;]]]</b> |
|--------|-----------------------------------------------------------------------------------------|

|                            |          |                              |
|----------------------------|----------|------------------------------|
| Parameter                  | <START>  | Start address*:<br>0~8388606 |
|                            | <LENGTh> | Length*: 2~8388608           |
|                            | <SCALE>  | Scale: ±32767                |
| * Start + Length ≤ 8388608 |          |                              |

Example      **SOUR1:ARB:BUIL:tukey 1000, 1000, 100**

Creates a Tukey window function waveform 1000  
points in length with a scale of 100 and a start  
address of 1000.

| SOURce[1 2]:ARB:OUTPut |                                                                                              | Source Specific Command   |
|------------------------|----------------------------------------------------------------------------------------------|---------------------------|
| Description            | Marks a section of the ARB waveform to be output.                                            |                           |
| Syntax                 | <b>SOURce[1 2]:ARB:OUTPut</b><br><b>[&lt;START&gt;[,&lt;LENGth&gt;]]</b>                     |                           |
| Parameter              | <START>                                                                                      | Start address*: 0~8388606 |
|                        | <LENGth>                                                                                     | Length*: 2~8388608        |
| Example                | <b>SOUR1:ARB:OUTP100, 1000</b><br>Sets the ARB output section from point 100 to 1100.        |                           |
| Query Syntax           | <b>SOUR1:ARB:OUTP?</b>                                                                       |                           |
| Return                 | Returns the following string:                                                                |                           |
| Parameter              | Start:<START>,Length:<LENGth>                                                                |                           |
|                        | <START>                                                                                      | 0~8388606                 |
|                        | <LENGth>                                                                                     | 2~8388608                 |
| Example                | <b>SOUR1:ARB:OUTP?</b><br><b>0, 1024</b><br>The output section starts at 0 and ends at 1024. |                           |

SOURce[1|2]:ARB:RATE

Source Specific  
Command

|              |                                                                             |                                   |
|--------------|-----------------------------------------------------------------------------|-----------------------------------|
| Description  | Sets or queries the sample rate of the ARB waveform.                        |                                   |
| Syntax       | <b>SOURce[1 2]:ARB:RATE</b><br><b>{&lt;frequency&gt; MINimum MAXimum}</b>   |                                   |
| Parameter    | <frequency                                                                  | Sets the sample rate frequency in |
|              | >                                                                           | Hz.                               |
|              | MINimum                                                                     | 1μHz                              |
|              | MAXimum                                                                     | 250MHz                            |
| Example      | <b>SOUR1:ARB:RATE 20000</b><br>Sets the ARB rate to 20kHz.                  |                                   |
| Query Syntax | <b>SOUR1:ARB:RATE?</b>                                                      |                                   |
| Return       | <NRf>                                                                       | Returns the rate in Hz.           |
| Parameter    |                                                                             |                                   |
| Example      | <b>SOUR1:ARB:RATE?</b><br><b>+2.000000000000E+04</b><br>The rate is 20 kHz. |                                   |

SOURce[1|2]:ARB:GATE

Source Specific  
Command

|                         |                                                                                                                                                                                                                                                                                                                                           |                                                       |
|-------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------|
| Description             | <p>Sets or queries whether a high or low level TTL signal applied to the trigger input turns the output on or off when the ARB output trigger is in the Gated mode (for the selected channel).</p> <p>Using this command will set the ARB output trigger as Gate Pos or Gate Neg and disable the Ncycle or Infinite trigger settings.</p> |                                                       |
| Syntax                  | <b>SOURce[1 2]:ARB:GATE {POSitive NEGative}</b>                                                                                                                                                                                                                                                                                           |                                                       |
| Parameter               | POSitive                                                                                                                                                                                                                                                                                                                                  | Gated output when a high TTL level signal is applied. |
|                         | NEGative                                                                                                                                                                                                                                                                                                                                  | Gated output when a low TTL level signal is applied.  |
| Example                 | <b>SOUR1:ARB:GATE POS</b> <p>Configures the CH1 ARB waveform to be output when a positive TTL signal is applied to the CH1 trigger input.</p>                                                                                                                                                                                             |                                                       |
| Query Syntax            | <b>SOURce[1 2]:ARB:GATE?</b>                                                                                                                                                                                                                                                                                                              |                                                       |
| Return Parameter        | OFF                                                                                                                                                                                                                                                                                                                                       | Indicates that the trigger is in Ncycle mode.         |
|                         | POSitive                                                                                                                                                                                                                                                                                                                                  | Trigger gate polarity is negative.                    |
|                         | NEGative                                                                                                                                                                                                                                                                                                                                  | Trigger gate polarity is positive.                    |
| Example                 | <b>SOURce1:ARB:GATE?</b><br><b>OFF</b> <p>The ARB output trigger is in Ncycle mode.</p>                                                                                                                                                                                                                                                   |                                                       |
| SOURce[1 2]:ARB:NCYCles |                                                                                                                                                                                                                                                                                                                                           | Source Specific Command                               |

|                               |                                                                                                          |                                         |
|-------------------------------|----------------------------------------------------------------------------------------------------------|-----------------------------------------|
| Description                   | Sets how the ARB Ncycle mode is triggered                                                                |                                         |
| Syntax                        | <b>SOURce[1 2]:ARB:NCYCles</b><br><b>{INFinite MANual EXTernal}</b>                                      |                                         |
| Parameter                     | INFinite                                                                                                 | Continuous cycles                       |
|                               | MANual                                                                                                   | Manual trigger                          |
|                               | EXTernal                                                                                                 | External trigger                        |
| Example                       | <b>SOUR1:ARB:NCYC INF</b><br><br>Sets the number of ARB waveform output cycles to continuous (infinite). |                                         |
| Query Syntax                  | <b>SOURce[1 2]:ARB:NCYCles?</b>                                                                          |                                         |
| Return<br>Parameter           | OFF                                                                                                      | ARB output trigger is in the Gate mode. |
|                               | INF                                                                                                      | Continuous cycles                       |
|                               | MAN                                                                                                      | Manual trigger                          |
|                               | EXT                                                                                                      | External trigger                        |
| Example                       | <b>SOUR1:ARB:NCYC?</b><br><br><b>INF</b><br><br>The ARB waveform output is set to infinite.              |                                         |
| SOURce[1 2]:ARB:NCYCles:CYCle |                                                                                                          | Source Specific<br>Command              |
| Description                   | The arbitrary waveform output can be repeated for a designated number of cycles.                         |                                         |

|                  |                                                                                                      |                                    |
|------------------|------------------------------------------------------------------------------------------------------|------------------------------------|
| Syntax           | <b>SOURce[1 2]:ARB:NCYCles:CYCle</b><br><b>{&lt;cycles&gt; MINimum MAXimum}</b>                      |                                    |
| Parameter        | <cycles>                                                                                             | 1 ~ 8388607 cycles                 |
|                  | MINimum                                                                                              | Minimum number of cycles (1)       |
|                  | MAXimum                                                                                              | Maximum number of cycles (8388607) |
| Example          | <b>SOUR1:ARB:NCYC:CYCMAX</b><br><br>Sets the number of ARB waveform output cycles to the maximum.    |                                    |
| Query Syntax     | <b>SOURce[1 2]:ARB:NCYCles:CYCle?</b><br><b>{[MINimum MAXimum]}</b>                                  |                                    |
| Return Parameter | <NR3>                                                                                                | Number of Ncycles.                 |
| Example          | <b>SOUR1:ARB:NCYC:CYC?</b><br><br><b>+8.388607E+06</b><br><br>Sets the number of ncycles to 8388607. |                                    |

|                                       |                 |
|---------------------------------------|-----------------|
|                                       | Source Specific |
| <b>SOURce[1 2]:ARB:MANual:TRIGger</b> | Command         |

|             |                                                                                                                                                                                             |
|-------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Description | This command is used to manually trigger the ARB output for the selected channel. This command is the equivalent of pressing the trigger soft-key on the front panel for manual triggering. |
| Syntax      | <b>SOURce[1 2]:ARB:MANual:TRIGger</b>                                                                                                                                                       |
| Example     | <b>SOUR1:ARB:MAN:TRIG</b>                                                                                                                                                                   |



Manually triggers the ARB waveform.

追踪指令

Source Specific

SOURce[1|2]:COUPle:FREQuency:MODE Command

Description

Sets the frequency coupling mode for the AFG-3022 and AFG-3032 models. By default, frequency coupling is turned off.

Syntax

SOURce[1|2]:COUPle:FREQuency:MODE {OFF|OFFSet|RATio}

|           |        |                                                                   |
|-----------|--------|-------------------------------------------------------------------|
| Parameter | OFF    | Coupling off, independent output                                  |
|           | OFFSet | Holds the frequency difference at a constant offset value         |
|           | RATio  | Holds the frequency ratio between each channel to constant ratio. |

Example

SOUR1:COUP:FREQ:MODE OFF

Turns frequency coupling off.

Query Syntax

SOURce[1|2]:COUPle:FREQuency:MODE

|                  |      |                                  |
|------------------|------|----------------------------------|
| Return Parameter | OFF  | Coupling off, independent output |
|                  | OFFS | Set to constant offset value     |
|                  | RAT  | Set to constant ratio value.     |

Example

SOUR1:COUP:FREQ:MODE?

OFF

Indicates that frequency coupling is turned off.

Source Specific

SOURce[1|2]:COUPle:FREQuency:OFFSet Command

|                     |                                                                                                                                                                                                                                                                    |                                                                                                                                                                                             |
|---------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Description         | Sets the frequency coupling offset value. The default value is 0Hz. Applicable for the AFG-3022 and 3032 only.<br><br>Note: CH2 frequency = CH1 frequency + offset frequency. CH1 frequency is fixed regardless of whether the SOURce1 or SOURce2 command is used. |                                                                                                                                                                                             |
| Syntax              | <b>SOURce[1 2]:COUPle:FREQuency:OFFSet</b><br><b>{&lt;frequency&gt; MINimum MAXimum}</b>                                                                                                                                                                           |                                                                                                                                                                                             |
| Parameter           | <frequency><br>><br><br>MINimum<br>MAXimum                                                                                                                                                                                                                         | Frequency difference in hertz.<br><br>Range: -30MHz ~ 30MHz<br>(20MHz AFG-3022)<br><br>Resolution: 1uHz<br><br>Sets the frequency to the minimum.<br><br>Sets the frequency to the maximum. |
| Example             | <b>SOUR1:COUP:FREQ:OFFS 1000</b><br><br>Sets the frequency coupling to 1kHz.                                                                                                                                                                                       |                                                                                                                                                                                             |
| Query Syntax        | <b>SOURce[1 2]:COUPle:FREQuency:OFFSet</b><br><b>{[MINimum MAXimum]}</b>                                                                                                                                                                                           |                                                                                                                                                                                             |
| Return<br>Parameter | <NR3>                                                                                                                                                                                                                                                              | Offset frequency.                                                                                                                                                                           |
| Example             | <b>SOUR1:COUP:FREQ:OFFS?</b><br><br><b>+1.000E+03</b>                                                                                                                                                                                                              |                                                                                                                                                                                             |

Indicates that the frequency coupling offset is 1kHz.

Source Specific

SOURce[1|2]:COUPle:FREQuency:RATio Command

Description                Sets the frequency coupling ratio value for the selected channel. The default value is 1. Applicable for the AFG-3022 and AFG-3032 only.

                                 The frequency ratio is defined as: CH2 frequency / CH1 frequency. CH1 frequency is fixed regardless of whether the SOURce1 or SOURce2 command is used.

Syntax                      **SOURce[1|2]:COUPle:FREQuency:RATio**  
**{<ratio>|MINimum|MAXimum}**

|           |         |                                       |
|-----------|---------|---------------------------------------|
| Parameter | <ratio> | Range: 1000~0.001, resolution 0.001   |
|           | MINimum | Sets the ratio to the minimum (1000)  |
|           | MAXimum | Sets the ratio to the minimum (0.001) |

Example                    **SOUR1:COUP:FREQ:RAT 100**

                                 Sets the ratio value of CH1 to 100.

Query Syntax              **SOURce[1|2]:COUPle:FREQuency:RATio**  
**{[MINimum|MAXimum]}**

|           |       |                    |
|-----------|-------|--------------------|
| Return    | <NR3> | Returns the ratio. |
| Parameter |       |                    |

Example                    **SOUR1:COUP:FREQ:RAT?**

                                 +1.000E+02

Indicates that the ratio value for CH1 is 100.

| SOURce[1 2]:COUPle:AMPLitude |                                                                                                                                                                                                                                                 | Source Specific<br>Command    |
|------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------|
| Description                  | Sets or queries the amplitude coupling state. Amplitude coupling sets the amplitude of the selected channel to be the same as the other channel. By default amplitude coupling is turned off. Only applicable to the AFG-3022 and the AFG-3032. |                               |
| Syntax                       | <b>SOURce[1 2]:COUPle:AMPLitude {ON OFF}</b>                                                                                                                                                                                                    |                               |
| Parameter                    | ON                                                                                                                                                                                                                                              | Turns amplitude coupling on.  |
|                              | OFF                                                                                                                                                                                                                                             | Turns amplitude coupling off. |
| Example                      | <b>SOURce1:COUP:AMPL ON</b><br>Turns amplitude coupling on.                                                                                                                                                                                     |                               |
| Query Syntax                 | <b>SOURce[1 2]:COUPle:AMPLitude?</b>                                                                                                                                                                                                            |                               |
| Return                       | ON                                                                                                                                                                                                                                              | Amplitude coupling is on.     |
| Parameter                    | OFF                                                                                                                                                                                                                                             | Amplitude coupling is off.    |
| Example                      | <b>SOUR1:COUP:AMPL?</b><br>ON<br>Indicates that amplitude coupling is on.                                                                                                                                                                       |                               |

| SOURce[1 2]:TRACking:STATe |                                                                                                                                                                                                                                 | Source Specific Command             |
|----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------|
| Description                | Sets or queries the tracking state of the selected channel. Tracking will set the waveform shape, frequency and amplitude of one channel to be the same as the other channel. Only applicable to the AFG-3022 and the AFG-3032. |                                     |
| Syntax                     | <b>SOURce[1 2]:TRACking:STATe</b><br><b>{ON INVerted OFF}</b>                                                                                                                                                                   |                                     |
| Parameter                  | ON                                                                                                                                                                                                                              | Turns channel tracking on.          |
|                            | INVerted                                                                                                                                                                                                                        | Turns inverted channel tracking on. |
|                            | OFF                                                                                                                                                                                                                             | Turns channel tracking off.         |
| Example                    | <b>SOUR1:TRAC:STAT ON</b><br>Turns channel tracking on.                                                                                                                                                                         |                                     |
| Query Syntax               | <b>SOURce[1 2]:TRACking:STATe?</b>                                                                                                                                                                                              |                                     |
| Parameter                  | ON                                                                                                                                                                                                                              | Channel tracking is on.             |
|                            | INV                                                                                                                                                                                                                             | Inverted channel tracking is on.    |
|                            | OFF                                                                                                                                                                                                                             | Channel tracking is off.            |
| Example                    | <b>SOUR1:TRAC:STAT?</b><br>ON<br>Indicates that channel tracking is on.                                                                                                                                                         |                                     |

参考指令

|                       |                                                                          |                                            |
|-----------------------|--------------------------------------------------------------------------|--------------------------------------------|
| SOURce[1 2]:REFerence |                                                                          | Source Specific Command                    |
| Description           | Sets or queries the 10MHz reference source as internal or external.      |                                            |
| Syntax                | <b>SOURce[1 2]:REFerence {INTernal EXTernal}</b>                         |                                            |
| Parameter             | INTernal                                                                 | Sets the reference to the internal source. |
|                       | EXTernal                                                                 | Sets the reference to the external source. |
| Example               | <b>SOUR1:REF INT</b><br>Sets the reference to the internal source.       |                                            |
| Query Syntax          | <b>SOURce[1 2]:REFerence?</b>                                            |                                            |
| Parameter             | INT                                                                      | The reference is the internal source.      |
|                       | EXT                                                                      | The reference is the external source.      |
| Example               | <b>SOUR1:REF?</b><br>INT<br>Indicates that reference is set to internal. |                                            |

| SOURce[1 2]:REFerence:SYNChronous |                                                                                                                                                                    | Source Specific Command |
|-----------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------|
| Description                       | Allowsthe unit to synchronize with a 10MHz external reference signal. Equivalent to the setting the clock source to EXT Sync when using the front panel operation. |                         |
| Syntax                            | <b>SOURce[1 2]:REFerence:SYNChronous</b>                                                                                                                           |                         |



## 存储和调取指令

Up to 10 different instrument states can be stored to non-volatile memory (memory locations 0~9).

|             |                                                                                                                                                                     | Instrument<br>Command |
|-------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------|
| <b>*SAV</b> |                                                                                                                                                                     |                       |
| Description | Saves the current instrument state to a specified save slot. When a state is saved, all the current instrument settings, functions and waveforms are also saved.    |                       |
| Note        | The *SAV command doesn't save waveforms in non-volatile memory, only the instrument state.<br>The *RST command will not delete saved instrument states from memory. |                       |
| Syntax      | <b>*SAV {0 1 2 3 4 5 6 7 8 9}</b>                                                                                                                                   |                       |
| Example     | <b>*SAV 0</b><br>Save the instrument state to memory location 0.                                                                                                    |                       |

|             |                                                                      | Instrument<br>Command |
|-------------|----------------------------------------------------------------------|-----------------------|
| <b>*RCL</b> |                                                                      |                       |
| Description | Recall previously saved instrument states from memory locations 0~9. |                       |
| Syntax      | <b>*RCL {0 1 2 3 4 5 6 7 8 9}</b>                                    |                       |
| Example     | <b>*RCL 0</b><br>Recall instrument state from memory location 0.     |                       |

|                            |  | Instrument<br>Command |
|----------------------------|--|-----------------------|
| <b>MEMory:STATe:DElete</b> |  |                       |

|             |                                                 |
|-------------|-------------------------------------------------|
| Description | Delete memory from a specified memory location. |
|-------------|-------------------------------------------------|

|        |                                                  |
|--------|--------------------------------------------------|
| Syntax | <b>MEMory:STATe:DELeTe {0 1 2 3 4 5 6 7 8 9}</b> |
|--------|--------------------------------------------------|

|         |                       |
|---------|-----------------------|
| Example | <b>MEM:STAT:DEL 0</b> |
|---------|-----------------------|

Delete instrument state from memory location 0.

|                         |                       |
|-------------------------|-----------------------|
| MEMory:STATe:DELeTe ALL | Instrument<br>Command |
|-------------------------|-----------------------|

|             |                                               |
|-------------|-----------------------------------------------|
| Description | Delete memory from all memory locations, 0~9. |
|-------------|-----------------------------------------------|

|        |                                |
|--------|--------------------------------|
| Syntax | <b>MEMory:STATe:DELeTe ALL</b> |
|--------|--------------------------------|

|         |                         |
|---------|-------------------------|
| Example | <b>MEM:STAT:DEL ALL</b> |
|---------|-------------------------|

Deletes all the instrument states from memory locations 0~9.

|               |                            |
|---------------|----------------------------|
| MEMory:STATe? | Source Specific<br>Command |
|---------------|----------------------------|

|             |                                                                         |
|-------------|-------------------------------------------------------------------------|
| Description | Queries the memory state of memory locations 0~9 as “Valid” or “Empty”. |
|-------------|-------------------------------------------------------------------------|

|              |                      |
|--------------|----------------------|
| Query Syntax | <b>MEMory:STATe?</b> |
|--------------|----------------------|

|        |                               |
|--------|-------------------------------|
| Return | Returns the following string: |
|--------|-------------------------------|

|           |                                                                                                                                                                |
|-----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Parameter | 0:<state>,1:<state>,2:<state>,3:<state>,4:<state>,<br>5:<br><state>,6:<state>,7:<state>,8:<state>,9:<state><br><state>      Where state is “Empty” or “Valid”. |
|-----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|

Example

**MEMory:STATe?**

0:Valid,1:Empty,2:Empty,3:Empty,4:Empty,5:Empty,  
6:Empty,7:Empty,8:Empty,9:Empty

Indicates memory 0 is valid and all other memory  
locations are empty.

## 错误信息

---

The AFG-30XX has a number of specific error codes. Use the `SYSTem:ERRor` command to recall the error codes. For more information regarding the error queue, see page 457.

### Command Error Codes

---

#### -101 Invalid character

An invalid character was used in the command string. Example: #, \$, %.

`SOURce1:AM:DEPTH MIN%`

#### -102 Syntax error

Invalid syntax was used in the command string. Example: An unexpected character may have been encountered, like an unexpected space.

`SOURce1:APPL:SQUare, 1`

#### -103 Invalid separator

An invalid separator was used in the command string. Example: a space, comma or colon was incorrectly used.

`APPL:SIN 11000 OR SOURce1:APPL:SQUare`

#### -108 Parameter not allowed

The command received more parameters than were expected. Example: An extra (not needed) parameter was added to a command

`SOURce1:APPL? 10`

-109 Missing parameter

The command received less parameters than expected. Example: A required parameter was omitted.

SOURce1:APPL:SQUare█

-112 Program mnemonic too long

A command header contains more than 12 characters:

OUTP:SYNCHRONIZATION ON

-113 Undefined header

An undefined header was encountered. The header is syntactically correct. Example: the header contains a character mistake.

SOUR1:AMM:DEPT MIN

-123 Exponent too large

Numeric exponent exceeds 32,000. Example:

SOURce[1]:BURSt:NCYCles 1E34000

-124 Too many digits

The mantissa (excluding leading 0's) contains more than 255 digits.

-128 Numeric data not allowed

An unexpected numeric character was received in the command. Example: a numeric parameter is used instead of a character string.

SOURce1:BURSt:MODE 123

-131 Invalid suffix

An invalid suffix was used. Example: An unknown or incorrect suffix may have been used with a parameter.

SOURce1:SWEEp:TIME 0.5 SECS

-138 Suffix not allowed

A suffix was used where none were expected.

Example: Using a suffix when not allowed.

SOURce1:BURSt: NCYCles 12 **CYC**

-148 Character data not allowed

A parameter was used in the command where not allowed. Example: A discrete parameter was used where a numeric parameter was expected.

SOUR1:SWE:TRIG**ON**

-158 String data not allowed

An unexpected character string was used where none were expected. Example: A character string is used instead of a valid parameter.

SOURce1:SWEep:FUNCTio**n'TEN'**

-161 Invalid block data

Invalid block data was received. Example: The number of bytes sent with the DATA:DAC command doesn't correlate to the number of bytes specified in the block header.

-168 Block data not allowed

Block data was received where block data is not allowed. Example:

SOURce1:BURSt:NCYCles:CYCles**#10**

-170~177 expression errors

Example: The mathematical expression used was not valid.

## Execution Errors

---

---

**-211 Trigger ignored**

---

A trigger was received but ignored. Example: Triggers will be ignored until the function that can use a trigger is enabled (burst, sweep, etc.).

---

**-223 Too much data**

---

Data was received that contained too much data. Example: An arbitrary waveform with over 8388708 points cannot be used.

---

**-221 Settings conflict; turned off infinite burst to allow immediate trigger source**

---

Example: Infinite burst is disabled when an immediate trigger source is selected. Burst count set to 1,000,000 cycles.

---

**-221 Settings conflict; infinite burst changed trigger source to MANual**

---

Example: The trigger source is changed to immediate from manual when infinite burst mode is selected.

---

**-221 Settings conflict; burst period increased to fit entire burst**

---

Example: The function generator automatically increases the burst period to allow for the burst count or frequency.

---

**-221 Settings conflict; burst count reduced**

---

Example: The burst count is reduced to allow for the waveform frequency if the burst period is at its maximum.

---

**-221 Settings conflict; trigger delay reduced to fit entire burst**

---

Example: The trigger delay is reduced to allow the current period and burst count.

---

**-221 Settings conflict;amplitude units changed to Vpp due to high-Z load**

---

Example: If the output impedance is set to high, dBm units cannot be used. The units are automatically set to Vpp.

---

**-221 Settings conflict: made compatible with pulse function**

---

Example: When the function is changed to pulse, the output frequency is automatically reduced if over range.

---

**-221 Settings conflict;frequency reduced for ramp function**

---

Example: When the function is changed to ramp, the output frequency is automatically reduced if over range.

---

**-221 Settings conflict;frequency reduced for triangle function**

---

Example: When the function is changed to triangle, the output frequency is automatically reduced if over range.

---

**-221 Settings conflict;frequency made compatible with burst mode**

---

Example: When the function is changed to burst, the output frequency is automatically adjusted if over range.

---

**-221 Settings conflict;not able to modulate this function**

---

Example: A modulated waveform cannot be generated with noise or pulse waveforms.

---

**-221 Settings conflict;not able to sweep this function**

---

Example: A swept waveform cannot be generated with noise or pulse waveforms.



**-221 Settings conflict: Burst function can not be performed under current setting.**

---

Example: The burst function cannot be used with harmonic waveforms.

**-221 Settings conflict: ARB Ncycle function can not be performed under current setting.**

---

nNcycle function will be disabled.

**-221 Settings conflict: Sweep Gate function can not be performed under current setting.**

---

Gate function will be disabled.

**-221 Settings conflict: Function can not be performed under current setting.**

---

Function is disabled.

**-221 Settings conflict;pulse width decreased due to period**

---

Example: The pulse width has been adjusted to suit the period settings.

**-221 Settings conflict;amplitude changed due to function**

---

Example: The amplitude (VRM / dBm) has been adjusted to suit the selected function. For the AFG-30XX, a typical square wave has a much higher amplitude (5V Vrms) compared to a sine wave (~3.54) due to crest factor.

**-221 Settings conflict;FM deviation cannot exceed carrier**

---

Example: The deviation cannot be set higher than the carrier frequency

---

**-221 Settings conflict;FM deviation exceeds max frequency**

---

Example: If the FM deviation and carrier frequency combined exceeds the maximum frequency plus 100 kHz, the deviation is automatically adjusted.

---

**-221 Settings conflict;frequency forced duty cycle change**

---

Example: If the frequency is changed and the current duty cannot be supported at the new frequency, the duty will be automatically adjusted.

---

**-221 Settings conflict;frequency forced symmetrychange.**

---

Example: This error occurs when SYM is set larger than 100%.

---

**-221 Settings conflict;offset changed due to amplitude**

---

Example: The offset is not a valid offset value, it is automatically adjusted, considering the amplitude.

$$|\text{offset}| \leq \text{max amplitude} - V_{pp}/2$$

---

**-221 Settings conflict;amplitude changed due to offset**

---

Example: The amplitude is not a valid value, it is automatically adjusted, considering the offset.

$$V_{pp} \leq 2X (\text{max amplitude} - |\text{offset}|)$$

---

**-221 Settings conflict;low level changed due to high level**

---

Example: The low level value was set too high. The low level is set 1 mV less than the high level.

---

**-221 Settings conflict;high level changed due to low level**

---

Example: The high level value was set too low. The high level is set 1 mV greater than the low level.

---

**-222 Data out of range;value clipped to upper limit**

---

Example: The parameter was set out of range. The parameter is automatically set to the maximum value allowed.

SOURce[1]:FREQuency 30.1MHz.

---

**-222 Data out of range;value clipped to lower limit**

---

Example: The parameter was set out of range. The parameter is automatically set to the minimum value allowed.

SOURce[1]:FREQuency 0.1μHz.

---

**-222Data out of range: pulse width limited by period.**

---

Example: The pulse width is limited by the period according to the formula below.

$$\text{Period} \geq \text{Width} + 0.625 * [(\text{Rise Time} - 0.6\text{nS}) + (\text{Fall Time} - 0.6\text{nS})]$$

To resolve the error, set the duty to the smallest possible value and then increase the frequency until the duty changes accordingly.

---

**-222 Data out of range: pulse rise/fall time limited by pulse width**

---

Example: The rise/fall time is limited by the pulse width according to the formula below.

$$\text{Width} - 0.625 * [(\text{Rise Time} - 0.6\text{nS}) + (\text{Fall Time} - 0.6\text{nS})] \geq 0$$

---

**-222 Data out of range;period;**

---

Example: If the period was set to a value out of range, it is automatically set to an upper or lower limit.

---

**-222 Data out of range;frequency;**

---

Example: If the frequency was set to a value out of range, it is automatically set to an upper or lower limit.

---

**-222 Data out of range;user frequency; value clipped to upper limit**

---

Example: If the frequency is set to a value out of range for an arbitrary waveform using SOURce[1 | 2]: APPL:USER, it is automatically set to the upper limit.

---

**-222 Data out of range;ramp frequency; value clipped to upper limit**

---

Example: If the frequency is set to a value out of range for a ramp waveform using, SOURce[1 | 2]: APPL: RAMP, it is automatically set to the upper limit.

---

**-222 Data out of range;pulse frequency; value clipped to upper limit**

---

Example: If the frequency is set to a value out of range for a pulse waveform using, SOURce[1 | 2]: APPL:PULS, it is automatically set to the upper limit.

---

**-222 Data out of range;burst period;**

---

Example: If the burst period was set to a value out of range, it is automatically set to an upper or lower limit.

---

**222 Data out of range;burst count;**

---

Example: If the burst count was set to a value out of range, it is automatically set to an upper or lower limit.

---

**-222 Data out of range; burst period limited by length of burst; value clipped to upper limit**

---

Example: The burst period must be greater than burst count divided by the frequency + 200 ns. The burst period is adjusted to satisfy these conditions.  
$$\text{burst period} > 200 \text{ ns} + (\text{burst count} / \text{burst frequency}).$$

---

**-222 Data out of range; burst count limited by length of burst; value clipped to lower limit**

---

Example: The burst count must be less than burst period \* the waveform frequency when the the trigger source is set to immediate (SOURCE[1 | 2]:BURSt:TRIGger IMM). The burst count is automatically set to the lower limit.

---

**-222 Data out of range;amplitude;**

---

Example: If the amplitude was set to a value out of range, it is automatically set to an upper or lower limit.

---

**-222 Data out of range;offset;**

---

Example: If the offset was set to a value out of range, it is automatically set to an upper or lower limit.

---

**-222 Data out of range;frequency in burst mode;**

---

Example: If the frequency was set to a value out of range in burst mode. The burst frequency is automatically set to an upper or lower limit, taking the burst period into account.

---

**-222 Data out of range;frequency in FM;**

---

Example: The carrier frequency is limited by the frequency deviation (SOURce[1]: FM:DEV). The carrier frequency is automatically adjusted to be less than or equal to the frequency deviation.

---

**-222 Data out of range;FM deviation; value clipped to ...**

---

Example: The frequency deviation is outside of range. The deviation is automatically adjusted to an upper or lower limit, depending on the frequency.

---

**-222 Data out of range;trigger delay; value clipped to upper limit**

---

Example: The trigger delay was set to a value out of range. The trigger delay has been adjusted to the maximum (85 seconds).

---

**-222 Data out of range;trigger delay limited by length of burst; value clipped to upper limit**

---

Example: The trigger delay and the burst cycle time combined must be less than the burst period.

---

**-222 Data out of range;duty cycle;**

---

Example: The duty cycle is limited depending on the frequency.

| Duty Cycle | Frequency      |
|------------|----------------|
| 40%~60%    | 25 MHz ~ 30MHz |
| 20%~80%    | < 25 MHz       |

**-222 Data out of range; duty cycle limited by frequency; value clipped to upper limit**

---

Example: The duty cycle is limited depending on the frequency. When the frequency is greater than 25MHz, the duty cycle is automatically limited to 60%.

**-313 Calibration memory lost;memory corruption detected**

---

Indicates that a fault (check sum error) has occurred with the non-volatile memory that stores the calibration data.

**-314 Save/recall memory lost;memory corruption detected**

---

Indicates that a fault (check sum error) has occurred with the non-volatile memory that stores the save/recall files.

**-315 Configuration memory lost;memory corruption detected**

---

Indicates that a fault (check sum error) has occurred with the non-volatile memory that stores the configuration settings.

**-350 Queue overflow**

---

Indicates that the error queue is full (over 20 messages generated, and not yet read). No more messages will be stored until the queue is empty. The queue can be cleared by reading each message, using the \*CLS command or restarting the function generator.

## Query Errors

---

### **-410 Query INTERRUPTED**

---

Indicates that a command was received but the data in the output buffer from a previous command was lost.

### **-420 Query UNTERMINATED**

---

The function generator is ready to return data, however there was no data in the output buffer. For example: Using the APPLY command.

### **-430 Query DEADLOCKED**

---

Indicates that a command generates more data than the output buffer can receive and the input buffer is full. The command will finish execution, though all the data won't be kept.

## Arbitrary Waveform Errors

---

### **-770 Nonvolatile arb waveform memory corruption detected**

---

Indicates that a fault (check sum error) has occurred with the non-volatile memory that stores the arbitrary waveform data.



**-781 Not enough memory to store new arb waveform; bad sectors**

---

Indicates that a fault (bad sectors) has occurred with the non-volatile memory that stores the arbitrary waveform data. Resulting in not enough memory to store arbitrary data.

**-787 Not able to delete the currently selected active arb waveform**

---

Example: The currently selected waveform is being output and cannot be deleted.

**800 Block length must be even**

---

Example: As block data (DATA:DAC VOLATILE) uses two bytes to store each data point, there must be an even number of bytes for a data block.

## SCPI 状态寄存器

The status registers are used to record and determine the status of the function generator.

The function generator has a number of register groups:

Questionable Status Registers

Standard Event Status Registers

Status Byte Register


As well as the output and error queues.

Each register group is divided into three types of registers: condition registers, event registers and enable registers.

### Register types

|                    |                                                                                                                                                                                                                                                                                                                          |
|--------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Condition Register | The condition registers indicate the state of the function generator in real time. The condition registers are not triggered. I.e., the bits in the condition register change in real time with the instrument status. Reading a condition register will not clear it. The condition registers cannot be cleared or set. |
| Event Register     | The Event Registers indicate if an event has been triggered in the condition registers. The event registers are latched and will remain set unless the *CLS command is used. Reading an event register will not clear it.                                                                                                |
| Enable Register    | The Enable register determines which status event(s) are enabled. Any status events that are not enabled are ignored. Enabled events are used to summarize the status of that register group.                                                                                                                            |

AFG-30XX Status System



## Questionable Status Register

|             |                                                                                    |     |            |
|-------------|------------------------------------------------------------------------------------|-----|------------|
| Description | The Questionable Status Registers will show if any faults or errors have occurred. |     |            |
| Bit Summary | Register                                                                           | Bit | Bit Weight |
|             | Voltage overload                                                                   | 0   | 1          |
|             | Over temperature                                                                   | 4   | 16         |
|             | Loop unlock                                                                        | 5   | 32         |
|             | Ext Mod Overload                                                                   | 7   | 128        |
|             | Cal Error                                                                          | 8   | 256        |
|             | External Reference                                                                 | 9   | 512        |

## Standard Event Status Registers

|             |                                                                                                                                       |
|-------------|---------------------------------------------------------------------------------------------------------------------------------------|
| Description | The Standard Event Status Registers indicate when the *OPC command has been executed or whether any programming errors have occurred. |
|-------------|---------------------------------------------------------------------------------------------------------------------------------------|

|       |                                                                                                                                                                                                             |
|-------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Notes | <p>The Standard Event Status Enable register is cleared when the *ESE 0 command is used.</p> <p>The Standard Event Status Event register is cleared when the *CLS command or the *ESR? command is used.</p> |
|-------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

| Bit Summary | Register               | Bit                                                                                                                                                              | Bit Weight |
|-------------|------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|
|             | Operation complete bit | 0                                                                                                                                                                | 1          |
|             | Query Error            | 2                                                                                                                                                                | 4          |
|             | Device Error           | 3                                                                                                                                                                | 8          |
|             | Execution Error        | 4                                                                                                                                                                | 16         |
|             | Command Error          | 5                                                                                                                                                                | 32         |
|             | Power On               | 7                                                                                                                                                                | 128        |
| Error Bits  | Operation complete     | The operation complete bit is set when all selected pending operations are complete. This bit is set in response to the *OPC command.                            |            |
|             | Query Error            | The Query Error bit is set when there is an error reading the Output Queue. This can be caused by trying to read the Output Queue when there is no data present. |            |
|             | Device Error           | The Device Dependent Error indicates a failure of the self-test, calibration, memory or other device dependent error.                                            |            |
|             | Execution Error        | The Execution bit indicates an execution error has occurred.                                                                                                     |            |
|             | Command Error          | The Command Error bit is set when a syntax error has occurred.                                                                                                   |            |
|             | Power On               | Power has been reset.                                                                                                                                            |            |

## The Status Byte Register

|             |                                                                                                                                                                                                                                                                                                                                          |                                                                                                                                                                     |            |
|-------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|
| Description | <p>The Status Byte register consolidates the status events of all the status registers. The Status Byte register can be read with the *STB? query or a serial poll and can be cleared with the *CLS command.</p> <p>Clearing the events in any of the status registers will clear the corresponding bit in the Status Byte register.</p> |                                                                                                                                                                     |            |
| Notes       | <p>The Status byte enable register is cleared when the *SRE 0 command is used.</p> <p>The Status Byte Condition register is cleared when the *CLS command is used.</p>                                                                                                                                                                   |                                                                                                                                                                     |            |
| Bit Summary | Register                                                                                                                                                                                                                                                                                                                                 | Bit                                                                                                                                                                 | Bit Weight |
|             | Error Queue                                                                                                                                                                                                                                                                                                                              | 2                                                                                                                                                                   | 4          |
|             | Questionable Data                                                                                                                                                                                                                                                                                                                        | 3                                                                                                                                                                   | 8          |
|             | Message Available                                                                                                                                                                                                                                                                                                                        | 4                                                                                                                                                                   | 16         |
|             | Standard Event                                                                                                                                                                                                                                                                                                                           | 5                                                                                                                                                                   | 32         |
|             | Master Summary / Request Service                                                                                                                                                                                                                                                                                                         | 6                                                                                                                                                                   | 64         |
| Status Bits | Error Queue                                                                                                                                                                                                                                                                                                                              | There are error message(s) waiting in the error queue.                                                                                                              |            |
|             | Questionable data                                                                                                                                                                                                                                                                                                                        | The Questionable bit is set when an “enabled” questionable event has occurred.                                                                                      |            |
|             | Message Available                                                                                                                                                                                                                                                                                                                        | The Message Available bit is set when there is outstanding data in the Output Queue. Reading all messages in the output queue will clear the message available bit. |            |

|                                    |                                                                                                                                                                                                           |
|------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Standard Event                     | The Event Status bit is set if an “enabled” event in the Standard Event Status Event Register has occurred.                                                                                               |
| Master Summary/Service Request bit | <p>The Master Summary Status is used with the *STB? query. When the *STB? query is read the MSS bit is not cleared.</p> <p>The Request Service bit is cleared when it is polled during a serial poll.</p> |

## Output Queue

|             |                                                                                                                                                    |
|-------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| Description | The Output queue stores output messages in a FIFO buffer until read. If the Output Queue has data, the MAV bit in the Status Byte Register is set. |
|-------------|----------------------------------------------------------------------------------------------------------------------------------------------------|

## Error Queue

|             |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|-------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Description | <p>The error queue is queried using the SYSTem:ERRor? command. The Error queue will set the “Error Queue” bit in the status byte register if there are any error messages in the error queue. If the error queue is full the last message will generate a “Queue overflow” error and additional errors will not be stored. If the error queue is empty, “No error” will be returned.</p> <p>Error messages are stored in the error queue in a first-in-first-out order. The errors messages are character strings that can contain up to 255 characters.</p> |
|-------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|


# 附录

## 保险丝更换


---

### 步骤

1. 拔去电源线并使用螺丝刀取出保险丝座



2. 更换保险丝



### 额定值

AFG-3022 & AFG-3032: T1A/250V  
AFG-3021& AFG-3031: T0.63A/250V



# AFG-3021, AFG-3022, AFG-3031 & AFG-3032 规格

此规格适合+20℃~+30℃，热机 30 分钟以上。

| 一般规格 |          | AFG-3021                 | AFG-3031 | AFG-3022 | AFG-3032 |
|------|----------|--------------------------|----------|----------|----------|
|      | 通道       | 1                        | 1        | 2        | 2        |
|      | 仪器机壳     | 绝缘                       | 绝缘       | 绝缘       | 绝缘       |
|      | 信号接地     | —                        | —        | 绝缘       | 绝缘       |
| 波形   |          |                          |          |          |          |
|      | 标准波形     | 正弦波,方波,斜波,脉冲波,噪声波,DC, 谐波 |          |          |          |
| 任意波形 |          |                          |          |          |          |
|      | ARB 功能   | 内置                       |          |          |          |
|      | 采样率      | 250 MSa/s                |          |          |          |
|      | 重建率      | 125MHz                   |          |          |          |
|      | 波形长度     | 8M 点                     |          |          |          |
|      | 幅值分辨率    | 16 bits                  |          |          |          |
|      | 非易失性存储器  | 10 组 8M 波形(1)            |          |          |          |
|      | 用户定义输出部分 | 从 2~8M 点任选               |          |          |          |
|      | 触发       | 外部                       |          |          |          |

|       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 内置任意波 | Sine, Square, Ramp, Sinc,ExpRise, ExpFall, DC, Pulse, Abstan, Havercosine, Sinever, Abssin, Haversine, Stair_down, Abssinehalf, N_pulse, Stair_UD, Ampalt, Negramp, Stair_up, Attalt, Rectpuls1, Stepresp, Diric_even, Roundhalf, Trapezia, Diric_odd, Sawtoot, Tripuls1, Gauspuls1, Sinetra, Dlorentz, Ln, Sqrt, Since, Lorentz, Xsquare, Gauss, Arccos, Arctan, Sech, Arccot, Arctanh, Sinh, Arccsc, Cosh, Tan, Arcsec, Cot, Tanh, Arcsin, Csc, Arcsinh, Sec, Barthannwin, Chebwin, Kaiser, Bartlett, Flattopwin, Triang, Blackman, Hamming, Tukeywin, Bohmanwin, Hann |
|-------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|         |         |                           |        |       |       |
|---------|---------|---------------------------|--------|-------|-------|
| 频率特性    |         |                           |        |       |       |
| 范围      | 正弦波     | 20MHz                     | 30MHz  | 20MHz | 30MHz |
|         | 方波      | 20MHz                     | 30MHz  | 20MHz | 30MHz |
|         | 三角波, 斜波 | 1MHz                      |        |       |       |
| 分辨率     |         | 1μHz                      |        |       |       |
| 精确度     | 稳定度     | ±1 ppm                    | 0~50℃  |       |       |
|         |         | ±0.3 ppm                  | 18~28℃ |       |       |
|         | 老化率     | ±1 ppm/1 year             |        |       |       |
|         | 容差      | ≤1 μHz                    |        |       |       |
| 输出特性(2) |         |                           |        |       |       |
| 幅值      | 范围      | 1 mVpp~10 Vpp(接 50Ω)      |        |       |       |
|         |         | 2 mVpp~20 Vpp(开路)         |        |       |       |
|         | 精确度     | ±1%设置值±1 mVpp             |        |       |       |
|         |         | (1 kHz/into 50Ω, 无 DC 偏移) |        |       |       |
|         | 分辨率     | 0.1 mV 或 4 digits         |        |       |       |

|       |            |                                                                                                                                           |
|-------|------------|-------------------------------------------------------------------------------------------------------------------------------------------|
|       | 平坦度        | ±0.1dB: <10 MHz<br>±0.2 dB: 10 MHz~30 MHz<br>(正弦波 1 kHz/into 50Ω)                                                                         |
|       | 单位         | Vpp, Vrms, dBm,                                                                                                                           |
|       | 偏移         | 范围                                                                                                                                        |
| 波形输出  | 精确度        | 1%设置值+ 2 mV + 0.5%幅值                                                                                                                      |
|       | 阻抗         | 50Ω 典型值 (固定)<br>> 10MΩ (输出关闭)                                                                                                             |
| 同步输出  | 保护         | 短路保护<br>过载继电器自动禁用主输出                                                                                                                      |
|       | 接地绝缘       | 42Vpk max.                                                                                                                                |
|       | 电平         | TTL-兼容(限 3031 / 3021) into>1kΩ                                                                                                            |
|       | 阻抗         | 50Ω 标称                                                                                                                                    |
|       | 接地绝缘       | 42Vpk max.<br>(same ground as CH1 output)                                                                                                 |
| 正弦波特性 |            |                                                                                                                                           |
|       | 谐波失真(5)    | -60 dBc DC ~ 1 MHz, Ampl<3 Vpp<br>-55 dBc DC ~ 1 MHz, Ampl>3 Vpp<br>-45 dBc 1MHz ~ 5 MHz, Ampl>3 Vpp<br>-30 dBc 5MHz ~ 30 MHz, Ampl>3 Vpp |
|       | 总谐波失真      | < 0.2%+0.1mVrms<br>DC~20 kHz                                                                                                              |
|       | 伪波(非谐波)(5) | -60 dBc DC~1 MHz<br>-50 dBc 1MHz~20MHz<br>-50 dBc + 6 dBc/octave 1MHz~30MHz(仅 AFG-3031/3032)                                              |
|       | 相位噪声       | < -110dBc/Hz (典型值), 15kHz offset, fc=10MHz                                                                                                |
| 方波特性  |            |                                                                                                                                           |
|       | 上升/下降时间    | <8 ns(3)                                                                                                                                  |
|       | 过激信号       | <5%                                                                                                                                       |

|           |                                  |        |          |        |
|-----------|----------------------------------|--------|----------|--------|
| 不对称性      | 1%周期 +1 ns                       |        |          |        |
| 可变占空比     | 20.0%~                           | 20.0%~ | 20.0%~   | 20.0%~ |
|           | 80.0%:                           | 80.0%: | 80.0%:   | 80.0%: |
|           | ≤ 20 MHz                         |        | ≤ 25 MHz |        |
|           | ≤ 20 MHz                         |        | ≤ 25 MHz |        |
|           | 40.0%~                           |        | 40.0%~   |        |
|           | 60.0%:                           |        | 60.0%:   |        |
|           | 25~                              |        | 25~      |        |
|           | 30MHz                            |        | 30MHz    |        |
|           |                                  |        |          |        |
| 抖动        | 0.01%+525ps < 2 MHz              |        |          |        |
|           | 0.1%+75ps > 2 MHz                |        |          |        |
| 斜波特性      |                                  |        |          |        |
| 线性度       | < 0.1%峰值输出                       |        |          |        |
| 可调对称性     | 0%~100% (0.1%分辨率)                |        |          |        |
| 脉冲波特性     |                                  |        |          |        |
| 频率        | 1uHz ~                           | 1uHz ~ | 1uHz ~   | 1uHz ~ |
|           | 20MHz                            | 25MHz  | 20MHz    | 25MHz  |
| 宽度        | 20ns ~ 999.83ks                  |        |          |        |
|           | Width - 0.625 * [(上升时间 - 0.6ns)  |        |          |        |
|           | + (下降时间 - 0.6ns)] ≥ 0            |        |          |        |
|           | Period ≥ Width+ 0.625 * [(上升时间 - |        |          |        |
|           | 0.6nS)+(下降时间 - 0.6ns)]           |        |          |        |
| 占空比设置范围   | 0.017%~99.983%                   |        |          |        |
| 周期        | 40ns ~ 1000000s                  |        |          |        |
| 上升时间和下降时间 | 9.32ns ~ 799.9ks                 |        |          |        |
| 分辨率       | 0.0001%                          |        |          |        |
| 过激        | < 5%                             |        |          |        |
| 抖动        | 50ps 典型值 (<10kHz)                |        |          |        |
| 噪声        |                                  |        |          |        |
| 噪声类型      | 高斯噪声                             |        |          |        |

|       |  |      |                                                  |              |              |              |
|-------|--|------|--------------------------------------------------|--------------|--------------|--------------|
|       |  | 噪声带宽 | 100MHz 等带宽                                       |              |              |              |
| 谐波    |  |      |                                                  |              |              |              |
|       |  | 谐波阶数 | ≤ 8                                              |              |              |              |
|       |  | 谐波类型 | 偶次, 奇次, 全部, 自定义<br>所有谐波可设置幅值和相位                  |              |              |              |
| AM 调制 |  |      |                                                  |              |              |              |
|       |  | 载波波形 | 正弦波、方波、三角波、斜波、脉冲波、Arb                            |              |              |              |
|       |  | 调制波形 | 正弦波、方波、三角波、正/负斜波                                 |              |              |              |
|       |  | 调制频率 | 2mHz~20kHz                                       |              |              |              |
|       |  | 深度   | 0%~120.0%                                        |              |              |              |
|       |  | 调制源  | 内部/外部                                            |              |              |              |
| FM 调制 |  |      |                                                  |              |              |              |
|       |  | 载波波形 | 正弦波、方波、三角波、斜波                                    |              |              |              |
|       |  | 调制波形 | 正弦波、方波、三角波、正/负斜波                                 |              |              |              |
|       |  | 调制频率 | 2mHz~20kHz                                       |              |              |              |
|       |  | 峰值偏移 | DC~30MHz(1 uHz 分辨率)<br>(AFG-3021/3022: DC~20MHz) |              |              |              |
|       |  | 调制源  | 内部/外部                                            |              |              |              |
| PWM   |  |      |                                                  |              |              |              |
|       |  | 载波波形 | 方波                                               |              |              |              |
|       |  | 调制波形 | 正弦波、方波、三角波、正/负斜波                                 |              |              |              |
|       |  | 调制频率 | 2mHz~20kHz                                       |              |              |              |
|       |  | 偏移   | 0% ~ 100.0%脉冲宽度, 0.1%分辨率                         |              |              |              |
|       |  | 调制源  | 内部/外部                                            |              |              |              |
| FSK   |  |      |                                                  |              |              |              |
|       |  | 载波波形 | 正弦波、方波、三角波、斜波                                    |              |              |              |
|       |  | 调制波形 | 50%占空比方波                                         |              |              |              |
|       |  | 内部频率 | 2mHz~100kHz                                      |              |              |              |
|       |  | 频率范围 | DC~<br>20MHz                                     | DC~30M<br>Hz | DC~<br>20MHz | DC~30M<br>Hz |

| 调制源    |          | 内部/外部                                                 |                   |                |                   |
|--------|----------|-------------------------------------------------------|-------------------|----------------|-------------------|
| Sum 调制 |          |                                                       |                   |                |                   |
|        | 载波波形     | 正弦波、三角波、斜波、脉冲波、噪声                                     |                   |                |                   |
|        | 调制波形     | 正弦波、方波、三角波、正/负斜波                                      |                   |                |                   |
|        | 比例       | 0%~100%载波幅值, 0.01%分辨率                                 |                   |                |                   |
|        | 调制频率     | 2mHz~20kHz                                            |                   |                |                   |
|        | 调制源      | 内部/外部                                                 |                   |                |                   |
| PM     |          |                                                       |                   |                |                   |
|        | 载波波形     | 正弦波、三角波、斜波                                            |                   |                |                   |
|        | 调制波形     | 正弦波、方波、三角波、正/负斜波                                      |                   |                |                   |
|        | 相位偏移设置范围 | 0°~360°, 0.1°分辨率                                      |                   |                |                   |
|        | 调制频率     | 2mHz~20kHz                                            |                   |                |                   |
|        | 调制源      | 内部                                                    |                   |                |                   |
| 扫描     |          |                                                       |                   |                |                   |
|        | 波形       | 频率扫描: 正弦波、方波、三角波、斜波<br>幅值扫描: 正弦波、方波、三角波、斜波、脉冲波、噪声、ARB |                   |                |                   |
|        | 类型       | 频率, 幅值                                                |                   |                |                   |
|        | 功能       | 线性或对数                                                 |                   |                |                   |
|        | 方向       | 上或下                                                   |                   |                |                   |
|        | 起始/停止频率  | 波形范围内的任何频率                                            |                   |                |                   |
|        | 扫描时间     | 1ms~500s (1ms 分辨率)                                    |                   |                |                   |
|        | 保持时间     |                                                       |                   |                |                   |
|        | 返回时间     |                                                       |                   |                |                   |
|        | 触发模式     | 单次、外部、内部                                              |                   |                |                   |
|        | 触发源      | 内部/外部                                                 |                   |                |                   |
| Burst  |          |                                                       |                   |                |                   |
|        | 波形       | 正弦波、方波、三角波、斜波、脉冲波、噪声                                  |                   |                |                   |
|        | 频率       | 1μHz~<br>20MHz                                        | 1μHz~30<br>MHz(4) | 1μHz~<br>20MHz | 1μHz~30<br>MHz(4) |

|                     |          |                                                      |
|---------------------|----------|------------------------------------------------------|
|                     | Burst 计数 | 1~1,000,000 次循环或无限                                   |
|                     | 起始/停止相位  | -360.0°~+360.0° (0.1° 分辨率)                           |
|                     | 内部周期     | 1us~500s                                             |
|                     | 门限来源     | 外部触发(脉冲波形仅用在门限模式)                                    |
|                     | 触发源      | 单次、外部或内部                                             |
|                     | 触发延迟     | N-Cycle, 无限: 0us~100s(1us 分辨率)                       |
| 外部调制输入              |          |                                                      |
|                     | 类型       | AM, FM, PWM, Sum                                     |
|                     | 电压范围     | ± 5V 全量程                                             |
|                     | 输入阻抗     | 10kΩ                                                 |
|                     | 频率       | DC~20kHz                                             |
|                     | 接地绝缘     | 42Vpk max.<br>(same ground as corresponding channel) |
| 调制输出(AFG-3021/3031) |          |                                                      |
|                     | 类型       | AM, FM, PWM, PM, Sum, 扫描                             |
|                     | 幅值       | ≥ 1Vpp                                               |
|                     | 阻抗       | > 10kΩ 典型值                                           |
| 外部触发输入              |          |                                                      |
|                     | 类型       | FSK, Burst, Sweep, N Cycle ARB                       |
|                     | 输入电平     | TTL 兼容                                               |
|                     | 斜率       | 上升或下降(可选)                                            |
|                     | 脉冲宽度     | >100ns                                               |
|                     | 输入频率     | DC~1MHz                                              |
|                     | 输入阻抗     | 10kΩ, DC 耦合                                          |
| 延迟                  | 扫描       | <10us (典型值)                                          |
|                     | Burst    | <100ns (典型值)                                         |
| 抖动                  | 扫描       | 2.5 us                                               |
|                     | Burst    | 1 ns; except pulse, 300 ps                           |
| 10 MHz 参考输出         |          |                                                      |
|                     | 输出电压     | 1 Vp-p/50Ω 方波                                        |
|                     | 输出阻抗     | 50Ω, AC 耦合                                           |

|             |                                                                                         |
|-------------|-----------------------------------------------------------------------------------------|
| 输出频率        | 10MHz                                                                                   |
| 10 MHz 参考输入 |                                                                                         |
| 输入电压        | 0.5Vp-p~5Vp-p                                                                           |
| 输入阻抗        | 1kΩ, 不平衡, AC 耦合                                                                         |
| 最大允许输入      | ± 10Vdc                                                                                 |
| 输入频率        | 10MHz ± 10Hz                                                                            |
| 波形          | 正弦波或方波(50±5%占空比)                                                                        |
| 接地绝缘        | 42Vpk max                                                                               |
| 外部同步        |                                                                                         |
| 相位延迟(max.)  | 串联: 39+(N-2)*39 ±25nS<br>并联: (N-1)*6 ±25nS<br>(其中 N=连接台数)                               |
| 最多连接台数      | 串联: 4<br>并联: 6                                                                          |
| 适用功能        | 正弦波、方波、三角波、脉冲波、斜波、谐波、MOD、扫描、Burst                                                       |
| 存储/调取       | 10 组内存空间                                                                                |
| 接口          | GPIOB(选配), LAN, USB                                                                     |
| 屏幕          | 4.3" TFT LCD, 480 × 3 (RGB) × 272                                                       |
| 一般规格        |                                                                                         |
| 电源          | AC100 - 240V, 50 - 60Hz                                                                 |
| 功率损耗        | AFG-3032 & AFG-3022: 85 VA<br>AFG-3021& AFG-3031: 50VA<br>温度: 18 ~ 28℃<br>工作温度: 0 ~ 40℃ |
| 操作环境        | 相对湿度: ≤ 80%, 0 ~ 40℃<br>≤ 70%, 35 ~ 40℃<br>安装等级: CAT II                                 |
| 海拔          | 2000 m                                                                                  |



|                    |                                                                                            |
|--------------------|--------------------------------------------------------------------------------------------|
| 污染程度               | EN 61010 Degree 2, 室内使用                                                                    |
| 储存温度               | -10~70℃, 湿度: ≤70%                                                                          |
| 尺寸                 | 265(W) x 107(H) x 374(D)                                                                   |
| 重量                 | 约 3.5kg                                                                                    |
| Safety Designed to | EN61010-1                                                                                  |
| EMC Tested to      | EN 61326, EN 55011                                                                         |
| 附件                 | 测试线(AFG-3021/3031: GTL-110×1,<br>AFG-3022/3032: GTL-110×2), 使用手册 CD × 1, 快速指南 × 1, 电源线 × 1 |

- (1). 可存储 10 组波形(每组波形最多 8M 点)
- (2). 对于 0℃~28℃ 范围内的操作环境，每改变 1℃，输出幅值和偏移规格增加 1/10(1 年规格)
- (3). 高频时边沿时间缩短
- (4). 25MHz 以上的正弦波和方波仅可以使用“无限次”burst 计数
- (5).低幅值的谐波失真和伪噪声限定在-70 dBm floor

# EC Declaration of Conformity

We  
**GOOD WILL INSTRUMENT CO., LTD.**  
No.7-1, Jhongsing Rd., Tucheng City, Taipei County 236, Taiwan  
**GOOD WILL INSTRUMENT (SUZHOU) CO., LTD.**  
No. 69, Lushan Road, Suzhou New District Jiangsu, China

declares that the below mentioned product  
**AFG-3021, AFG-3031, AFG-3022, AFG-3032**  
Are herewith confirmed to comply with the requirements set out in the Council Directive on the Approximation of the Law of Member States relating to Electromagnetic Compatibility(2004/108/EC & 2014/30/EU) and Low Voltage Equipment Directive (2006/95/EC &2014/35/EU). For the evaluation regarding the Electromagnetic Compatibility and Low Voltage Directive, the following standards were applied:







◎EMC






|                                                           |                                                                                            |  |
|-----------------------------------------------------------|--------------------------------------------------------------------------------------------|--|
| <b>EN 61326-1 :</b><br><b>EN 61326-2-1:</b>               | Electrical equipment for measurement, control and laboratory use — EMC requirements (2013) |  |
| Conducted and Radiated Emissions<br>EN 55011:2009+A1:2010 | Electrostatic Discharge<br>EN 61000-4-2: 2009                                              |  |
| Current Harmonic<br>EN61000-3-2:2014                      | Radiated Immunity<br>EN 61000-4-3:2006+A1:2008+A2:2010                                     |  |
| Voltage Fluctuation<br>EN 61000-3-3:2013                  | Electrical Fast Transients<br>EN61000-4-4:2012                                             |  |
| -----                                                     | Surge Immunity<br>EN 61000-4-5: 2006                                                       |  |
| -----                                                     | Conducted Susceptibility<br>EN 61000-4-6: 2014                                             |  |
| -----                                                     | Power Frequency Magnetic Field<br>EN61000-4-8:2010                                         |  |
| -----                                                     | Voltage Dips/ Interrupts<br>EN 61000-4-11: 2004                                            |  |



◎Safety




|                                                                                                             |
|-------------------------------------------------------------------------------------------------------------|
| <b>Low Voltage Directive 2006/95/EC &amp;2014/35/EU</b>                                                     |
| Safety Requirements<br><b>EN 61010-1:2010 (Third Edition)</b><br><b>EN 61010-2-030:2010 (First Edition)</b> |



ARB 内置波形

| 基础       |                      |                                                                                     |
|----------|----------------------|-------------------------------------------------------------------------------------|
| 正弦波      | $y = \sin(x)$        |    |
| 方波       | 50% 占空比方波            |    |
| 斜波       | 50% 对称               |    |
| Sinc     | $y = \text{sinc}(x)$ |    |
| Exp Rise | 指数上升                 |   |
| Exp Fall | 指数下降                 |  |
| DC       | DC 波                 |  |
| 脉冲       | 自定义频率和占空比            |  |

|             |                                                                       |                                                                                              |
|-------------|-----------------------------------------------------------------------|----------------------------------------------------------------------------------------------|
| 常见 1        |                                                                       |                                                                                              |
| Absatan     | $y =  \text{atan}(x) $<br>atan(x)的绝对值                                 |             |
| Havercosine | $y = (1 - \sin(x))/2$<br>Havercosine 功能                               |             |
| Sinever     | 分段正弦功能                                                                |             |
| Abssin      | $y =  \sin(x) $<br>绝对值                                                | sin(x)的<br> |
| Haversin    | $y = (1 - \cos(x))/2$<br>Haversine 功能                                 |             |
| Stair_down  | Step down                                                             |            |
| Abssinehalf | $y = \sin(x), 0 < x < \pi$<br>$y = 0, \pi < x < 2\pi$<br>Half_wave 功能 |           |
| N_pulse     | 负脉冲                                                                   |           |
| Stair_ud    | Step up 和 step down                                                   |           |

|          |                          |                                                                                   |
|----------|--------------------------|-----------------------------------------------------------------------------------|
| Ampalt   | $y=e(x).\sin(x)$<br>振荡上升 |  |
| Negramp  | $y=-x$<br>Line segment   |  |
| Stair_up | Step up                  |  |








|           |                                                                      |                                                                                     |
|-----------|----------------------------------------------------------------------|-------------------------------------------------------------------------------------|
| 常见 2      |                                                                      |                                                                                     |
| Attalt    | $y=e(-x).\sin(x)$<br>振荡下降                                            |    |
| Rectpuls  | 采样非周期矩形                                                              |    |
| Stepresp  | 单位阶跃函数                                                               |   |
| Diric     | Even<br>$f(x)=-1^{(x*(n-1)/2*\pi)}$<br>$x=0,\pm2*\pi,\pm4*\pi,\dots$ |  |
| Roundhalf | $y=\sqrt{1-x^2}$<br>半圆                                               |  |

|          |                                                                   |                                                                                   |
|----------|-------------------------------------------------------------------|-----------------------------------------------------------------------------------|
| Trapezia | 分段函数                                                              |  |
| Diric    | Odd<br>$f(x)=\sin(nx/2)/n*\sin(x/2)$<br>$x=\pm\pi,\pm3\pi, \dots$ |  |
| Sawtoot  | 锯齿或三角波                                                            |  |
| Tripuls  | 采样非周期三角形                                                          |  |
| Gauspuls | $f(x)=a*e^{-(x-b)^2/c^2}$<br>高斯调制正弦脉冲                             |  |
| Sinetra  | 分段函数                                                              |  |



| Math     |                                 |                                                                                              |
|----------|---------------------------------|----------------------------------------------------------------------------------------------|
| Dlorentz | lorentz 功能的倒数<br>$2x/(k*x^2+1)$ | $y=-$<br> |
| Ln       | 对数功能                            |           |

|         |                               |                                                                                   |
|---------|-------------------------------|-----------------------------------------------------------------------------------|
| Sqrt    | $y=\sqrt{x}$                  |  |
| Sinec   | $y=\sin(x)/x$                 |  |
| Lorentz | Lorentz 功能<br>$y=1/(k*x^2+1)$ |  |
| Xsquare | 抛物线                           |  |
| Gauss   | 高斯贝尔曲线                        |  |




| Trig   |      |                                                                                     |
|--------|------|-------------------------------------------------------------------------------------|
| Arccos | 反余弦  |   |
| Arctan | 反正切  |  |
| Sech   | 双曲正割 |  |

|         |       |                                                                                     |
|---------|-------|-------------------------------------------------------------------------------------|
| Arccot  | 反余切   |    |
| Arctanh | 双曲反正切 |    |
| Sinh    | 双曲正弦  |    |
| Arccsc  | 反余割   |    |
| Cosh    | 双曲余弦  |    |
| Tan     | 正切    |    |
| Arcsec  | 反正割   |   |
| Cot     | 余切    |  |
| Tanh    | 双曲正切  |  |



|         |       |                                                                                   |
|---------|-------|-----------------------------------------------------------------------------------|
| Arcsin  | 反正弦   |  |
| Csc     | 余割    |  |
| Arcsinh | 双曲反正弦 |  |
| Sec     | 正割    |  |

|             |                            |                                                                                     |
|-------------|----------------------------|-------------------------------------------------------------------------------------|
| 视窗          |                            |                                                                                     |
| Barthannwin | Modified Bartlett-Hann 视窗  |    |
| Chebywin    | Chebyshev 视窗功能             |   |
| Kaiser      | Kaiser 视窗功能                |  |
| Bartlett    | Bartlett 视窗与三角视窗非常相似，如三角函数 |  |

|            |                 |                                                                                    |
|------------|-----------------|------------------------------------------------------------------------------------|
| Flattopwin | Flattopwin 视窗功能 |   |
| Triang     | Triang 视窗功能     |   |
| Blackman   | Blackman 视窗功能   |   |
| Hamming    | Hamming 视窗功能    |   |
| Tukeywin   | Tukey 视窗功能      |   |
| Bohmanwin  | Bohman 视窗功能     |   |
| Hann       | Hann 视窗功能       |  |

# 索引

|                                 |          |                                |     |
|---------------------------------|----------|--------------------------------|-----|
| Amplitude coupling .....        | 183      | safety instructions.....       | 9   |
| Arbitrary waveforms.....        | 190      | Equipment category.....        | 10  |
| Built-In.....                   | 191      | Ethernet interface.....        | 233 |
| display .....                   | 198      | Firmware .....                 | 168 |
| navigation .....                | 202      | Frequency coupling .....       | 181 |
| overview .....                  | 204      | Front panel diagram .....      | 15  |
| editing.....                    | 205      | Function keys                  |     |
| inserting.....                  | 191      | key overview .....             | 16  |
| saving.....                     | 221      | Fuse replacement.....          | 405 |
| Beeper.....                     | 170      | safety instruction .....       | 8   |
| Built-in ARB waveforms .....    | 414      | GPIO                           |     |
| Caution symbol.....             | 6        | remote control interface ..... | 232 |
| Channel tracking.....           | 184      | Ground                         |     |
| Cleaning the instrument.....    | 9        | symbol.....                    | 6   |
| Declaration of conformity ..... | 413      | Help menu.....                 | 29  |
| Default settings .....          | 68       | interface.....                 | 230 |
| Digital inputs .....            | 28       | LAN interface.....             | 233 |
| Display                         |          | Language selection .....       | 169 |
| diagram .....                   | 23       | List of features.....          | 12  |
| Display brightness .....        | 171      | Menu Tree .....                | 51  |
| Display suspend .....           | 171      | Modulation.....                | 89  |
| Disposal                        |          | AM.....                        | 91  |
| symbol .....                    | 7        | Burst .....                    | 146 |
| Disposal instructions.....      | 10       | FM.....                        | 100 |
| DSO link.....                   | 175, 180 | PM.....                        | 115 |
| Dual channel .....              | 178      | PWM.....                       | 128 |
| amplitude coupling .....        | 183      | SUM.....                       | 121 |
| channel tracking .....          | 184      | Multi-unit sync                |     |
| dso link .....                  | 175, 180 | connection .....               | 186 |
| frequency coupling .....        | 181      | setup .....                    | 188 |
| output impedance .....          | 179      | Operation                      |     |
| phase .....                     | 178      | Amplitude .....                | 87  |
| EN61010                         |          | Channel selection.....         | 71  |
| measurement category .....      | 7        | DC Wave .....                  | 84  |
| pollution degree .....          | 9        | Frequency .....                | 85  |
| Environment                     |          | Harmonic Characteristics ..... | 83  |
|                                 |          | Harmonic Order.....            | 81  |

|                               |          |                                 |          |
|-------------------------------|----------|---------------------------------|----------|
| Harmonic Wave .....           | 80       | GPIO .....                      | 163      |
| Noise Wave .....              | 80       | LAN .....                       | 164      |
| Offset .....                  | 88       | LAN host name .....             | 166      |
| Pulse duty .....              | 78       | SCPI registers .....            | 399      |
| Pulse rise & fall time .....  | 76, 77   | screen lock .....               | 236      |
| Pulse width .....             | 75       | Syntax .....                    | 240      |
| Ramp .....                    | 79       | terminal connection .....       | 235      |
| Sine .....                    | 72       | USB .....                       | 167      |
| Square .....                  | 73       | Screen lock .....               | 236      |
| Triangle .....                | 74       | Secondary System Settings ..... | 158      |
| Operation keys                |          | Remote interface .....          | 163      |
| key overview .....            | 16       | System and Settings .....       | 168      |
| Operation menu .....          | 70       | Service operation               |          |
| Output indicators .....       | 17       | about disassembly .....         | 7        |
| Output terminals .....        | 18       | Set output impedance .....      | 174, 179 |
| Phase settings .....          | 178      | Setting up the instrument ..... | 24       |
| Power on/off                  |          | Software .....                  | 168      |
| safety instruction .....      | 8, 10    | Specifications .....            | 406      |
| Power up .....                | 25       | Syncing multiple units .....    | 186      |
| Quick reference .....         | 26       | Tracking .....                  | 184      |
| Rear panel diagram .....      | 20       | UK power cord .....             | 11       |
| Reference clock .....         | 172      | Updating Software and firmware  |          |
| remote control                |          | .....                           | 168      |
| interface configuration ..... | 230, 237 | USB                             |          |
| Remote interface .....        | 229      | remote control interface .....  | 230      |
| Error messages .....          | 386      | Warning symbol .....            | 6        |
| functionality check .....     | 235      |                                 |          |